## USING NITROGEN-14 NUCLEAR QUADRUPOLE RESONANCE AND ELECTRIC FIELD GRADIENT INFORMATION FOR THE STUDY OF RADIATION EFFECTS

Ву

### LOUIS HENRY ISELIN

A DISSERTATION PRESENTED TO THE GRADUATE SCHOOL
OF THE UNIVERSITY OF FLORIDA IN PARTIAL FULFILLMENT
OF THE REQUIREMENTS FOR THE DEGREE OF
DOCTOR OF PHILOSOPHY

UNIVERSITY OF FLORIDA

1995

UNIVERSITY OF FLORIDA LIBRARIES

Copyright 1995

bу

Louis H Iselin

This dissertation is presented in faith for the glory of God the Father, Son and Holy Spirit, for the mystery of life and what we will become.

This work is dedicated to my loving wife, Huong, and our darling daughter, Megan Rochelle. The time and effort put in graduate school are only early steps along the way towards the future. It is also dedicated to the memory of the two men for whom I was named, my grandfathers: Louis Max Iselin, whom I never knew, and Henry August Trinkaus, who was a great inspiration to me. He taught me that the worth of a man was not determined by how much education he had but in what he did and what he stood for.

My continuing professional career is dedicated to the many teachers in the public schools in Jonesboro, Arkansas, who encouraged me and pushed me to excel, especially G. Frazier, E. Frazier, D. Hammett, R. Patterson, and K. Bridger.

#### ACKNOWLEDGEMENTS

I am pleased to acknowledge the support and guidance of my graduate research advisor, Dr. David E. Hintenlang, and the rest of my committee. Thanks are extended to Dr. Samim Anghaie and Dr. E. Raymond Andrew for representing the Department of Nuclear Engineering Sciences. I extend my gratitude to Dr. Ulrich H. Kurzweg and Dr. Michael T. Olexa for representing the College of Engineering and the University of Florida at large, respectively. A special debt is acknowledged to Dr. Robert A. Marino of Hunter College of the City University of New York for providing specialized guidance on the theoretical and experimental aspects of NQR. The gracious assistance of Drs. Dirk van Ormondt and Ron de Beer of the Technical University of Delft is acknowledged. They sent me a copy of HSVD and helped me get it up and running. Thanks to the advice of Dr. Alexander Koukoulas of Paprican I was able to get the NQR equipment functioning reliably. I would be remiss if I did not acknowledge the many times that Mr. James M. Ogles assisted me with computer problems and provided stimulating conversation.

This research was partially supported by the Department of Energy Office of Energy Research under contract DE-FG07-89ER12890. Research also partially performed under appointment to the Nuclear Engineering and Health Physics Fellowship program administered by the Oak Ridge Institute for Science and Education for the U.S. Department of Energy. Research assistantships were provided at the end of my fellowship period by Dr. David E. Hintenlang and Dr. Genevieve S. Roessler under projects that were part of the Florida Radon Research Program funded by the Florida Department of Community Affairs with assistance from the U.S. Environmental Protection Agency.

## TABLE OF CONTENTS

					page
ACKNOWLEDGEMENTS			٠.		. iv
ABSTRACT					. ix
CHAPTERS					
1 INTRODUCTION					. 1
Background					
Radiolysis of Water					. 4
Radiation Chemistry of Solids					. 5
Material of Choice					
Method of Choice					
Radiation Effects					. 7
Objectives	٠.			٠.	. 8
2 THEORETICAL BACKGROUND					10
Theory of NQR					10
Nuclear Electric Quadrupole Moment					10
Electric Field Gradient					- 11
Quadrupole Hamiltonian and Associated Energy Levels					13
Hamiltonian Constant					15
Energy Levels					16
Townes and Dailey Theory					19
Spin Relaxation Times					27
Lineshapes					29
3 EQUIPMENT, EXPERIMENT, AND PROCEDURES					31
Summary Description of Equipment					31
Equipment Specifications	٠.		•	٠.	34
Continuous Wave Frequency Source and Monitor	٠.		•	٠.	34
Goted Amplifier	٠.	٠.	•	٠.	25

		Dage
	Coils and the Impedance Matching Network	. 36
	Broadband Receiver with Phase Sensitive Detector	. 37
	Digital Oscilloscope and Personal Computer	. 38
	Experimental Technique	. 39
	Sample Preparation	. 39
	Irradiation of Samples	. 39
	Pulse Selection	. 41
	Data Collection	
	Analytical Techniques	
	Fourier Transform	
	Singular Value Decomposition Methods	43
	Nonlinear Least Squares Curve Fitting	45
	Levenberg-Marquart Method	47
	Errors in Fitted Parameters	48
	Procedures	
	Data File Manipulation	
	Use of Fourier Transform	52
	HSVD Applied to Data	52
	Nonlinear Curve Fitting of Data	53
	•	
4	RESULTS	54
	Theoretical Results	54
	NQR Linewidth Analysis	54
	NQR Linewidth Analysis Test for <sup>14</sup> N	58
	Experimental Results	59
	Pulse Optimization	59
	Pure Urea and Urea-d <sub>4</sub>	73
	Effect of Gamma Rays on Urea-Water	76
	Effect of Water on Urea	79
	Pulsed <sup>14</sup> N NQR of Urea-H <sub>2</sub> O <sub>2</sub> and Urea-Rock Salt	81
5	DISCUSSION	82
	Theoretical Deviles	
	Theoretical Results	82
	NQR Linewidth Analysis	82
	NQR Linewidth Analysis Test for <sup>14</sup> N	85
	EFG Widths for Sodium Nitrite	86
	Experimental Results	88
	Pulse Optimization	88
	NQR of Pure Urea Compounds	90
	Effect of Gamma Rays on Urea-Water	93

	page
Review of Higgin's Original Data	
Effect of Water on Urea	
Pulsed <sup>14</sup> N NQR of Urea-H <sub>2</sub> O <sub>2</sub> and Urea-Rock Salt	. 97
6 CONCLUSIONS	. 98
APPENDICES	
A FORTRAN PROGRAMS	106
B EXAMPLE FILES	122
C PETERSEN'S SODIUM NITRITE DATA	133
D HIGGINS' UREA-WATER DATA	164
REFERENCES	172
BIOGRAPHICAL SKETCH	179

Abstract of Dissertation Presented to the Graduate School of the University of Florida in Partial Fulfillment of the Requirements for the Degree of Doctor of Philosophy

## USING NITROGEN-14 NUCLEAR QUADRUPOLE RESONANCE AND ELECTRIC FIELD GRADIENT INFORMATION FOR THE STUDY OF RADIATION EFFECTS

By

Louis Henry Iselin

December, 1995

Chairman: David E. Hintenlang

Major Department: Nuclear Engineering Sciences

Nitrogen-14 nuclear quadrupole resonance (NQR) was used in an attempt to detect the effects of ionizing radiation on organic material. Previously reported resonances for urea were detected at 2913.32  $\pm$  0.01 kHz and 2347.88  $\pm$  0.08 kHz with associated  $T_2$ \* values 780  $\pm$  20  $\mu$ s and 523  $\pm$  24  $\mu$ s, respectively. The previously unreported  $\nu$  line for urea- $d_4$  was detected at 2381  $\pm$  0.04 Khz and used to determine accurately for the first time the values for the nuclear quadrupole coupling constant  $\chi$  (3548.74  $\pm$  0.03 kHz) and the asymmetry parameter  $\eta$  (0.31571  $\pm$  0.00007) for urea- $d_4$ . The inverse linewidth parameter  $T_2$ \* for  $\nu_+$  was measured at 928  $\pm$  23  $\mu$ s and for  $\nu_-$  at 721  $\pm$  12  $\mu$ s. Townes and Dailey analysis was performed and urea- $d_4$  exhibits a 0.004 increase in lone pair electronic density and a slight

decrease in N-H bond electronic density, as compared to urea, probably due to the mass difference.

A relationship is proposed, referred to as NQR linewidth analysis, between the dynamic spin relaxation times T2 and T2 and the widths of the distributions of the NQR parameters. This is the NQR version of the well known nuclear magnetic resonance (NMR) relationship that relates the linewidth to a function of the spin-spin relaxation time and the magnetic field inhomogeneity. The electric field gradient inhomogeneity in NQR is substituted for the magnetic field inhomogeneity in NMR. Linewidth analysis is presented as a tool for possible use in future NQR work in all areas, not just radiation effects. This relationship is tested using sodium nitrite T2 and  $T_2$  values for  $\nu_+$  and  $\nu_-$  as a function of temperature; a most rigorous test for  $^{14}N$ NQR as the T2 and T2 values for v4 are unavailable for any nitrogen-14 containing compound. Linewidth analysis successfully meets its own requirement that the  $\nu_+$  and v. resonance lines yield the same results for the difference of the inverted time constants  $T_2$  and  $T_2^*$  for each line. By assuming that the  $\nu$  resonance line would yield results similar to the other two lines, the natural width of  $\chi$  for sodium nitrite is estimated to be 150-950 Hz in the temperature range from 77 to 470 K.

Urea recrystallized in the presence of water was observed to have a  $T_2$ \* decreased from the dry, polycrystalline form value of 780  $\mu$ s to 550  $\pm$  50  $\mu$ s, regardless of gamma ray exposure up to 900 Gy. Urea:water ratios were tested in the range of 0.1 to 1.3 by molar weight. Observations of previous studies on urea-water

conducted in this laboratory by Higgins and Hintenlang were not able to be replicated and are not supported by this work.

#### CHAPTER 1 INTRODUCTION

There is a need for more understanding of the interaction between ionizing radiation and biological systems and the chemical processes by which that interaction takes place. In health physics, the final measure of interest for ionizing radiation is the damage done to a biological system, usually a person. Current radiation protection standards and practices rely on a correlation between the radiation dosimetry parameters at high doses and high dose rates (extrapolated down from 250 mGy to the smallest measurable dose) and any observed biological effects. As the doses and dose rates are lowered, the observed correlation weakens. The sequence of interaction is known to be

# PHYSICAL → CHEMICAL → BIOLOGICAL. [1-1]

While researchers actively pursue radiation dosimetry (physics) and radiation biology, the intermediate chemical effects in this sequence are studied to a much lesser degree. More information is needed in the area from physical energy deposition to chemical change. While an absorbed dose can be measured very accurately and precisely in some special cases, the biological effects due to that dose cannot be known with any reasonable certainty except in the high dose and high dose rate limit. The conversion factor for radiation protection, quality factor (Q), is a gross approximation to a

varying factor of biological damage for different radiations, relative biological effectiveness (RBE). Even though the RBE can be experimentally determined for a given radiation and a given biological effect in the biological system in question, the amount of natural biological variation in the given biological system demonstrates that RBE is still a crude measure of radiation effect on a biological system. This work focuses on the concept of a relative chemical effect by ionizing radiation on the chemical structure of an organic system by investigating changes in the bonding configuration surrounding nitrogen-14 atoms. The chosen system is a simple complex of an organic and water. The complex is chosen so that the indirect effects of the radiation-water interaction will be present on the organic and the organic is still in the solid phase and not in solution.

Although most radiation chemistry research is in aqueous solution, some work has been done in the area of chemical radiation effects on solids [Swallow 1960].

Magnetic resonance techniques are able to measure relatively small changes in chemical structures. The technique used most often to detect the presence of radiolytic products in solids is electron spin resonance (ESR). In most cases, single crystal studies are emphasized so that the structure of the radical can be determined [Box 1977; Rogers and Kispert 1968; Tolkachev 1972]. The primary advantage to the use of ESR is that only the products contribute to the signal. The primary disadvantage is that only paramagnetic products can be detected with this method. It

 $<sup>^{\</sup>rm I}$  ESR is also know as electron paramagnetic resonance (EPR) and recently as electron magnetic resonance (EMR).

has been generally assumed, however, that the paramagnetic products are those primarily responsible for biological interactions. Electron nuclear double resonance (ENDOR) has also been used [Box 1977] to study radiation effects on some organics.

Nuclear magnetic resonance (NMR) has been used by a few researchers [Panin 1985; Panin et al. 1987; Thomasson 1990] to explore radiation effects at the chemical level, but all have focused on solutions, usually Fricke dosimetry or polymers.

Nuclear quadrupole resonance (NQR) has been used to study the effects of radiation on <sup>35</sup>Cl containing compounds [Duchesne et al. 1955, 1956; Milia and Hadjoudis 1968; Vargas et al. 1978] and, since 1989 at the University of Florida, to study the effects of radiation on <sup>14</sup>N containing compounds [Iselin and Hintenlang 1990, 1991, 1992; Higgins 1990; Hintenlang and Higgins 1992; Jamil and Hintenlang 1993; Hintenlang, et al. 1992; Jamil 1992]. NQR does not require magnets which can degrade the signal due to inhomogeneities in the applied magnetic field; the internal fields created by the physical makeup of the <sup>14</sup>N containing compound is exploited instead.

## Background

It is generally believed that the indirect effects of ionizing radiation are the primary causes of biological damage. These indirect effects are the result of free radicals, radical ions, and ions reacting with biological materials to cause breaks in existing molecules or to form new compounds which the organism may not be able to repair or isolate. Since biological organisms are primarily composed of water, the

radiolysis of water has always been the theoretical starting point in discussions of radiation effects on biological systems.

## Radiolysis of Water

The interactions of ionizing radiations with water either lead to the water being ionized or left in an excited state. Since excitations have never been shown unequivocally to play a significant role in the radiation chemistry of aqueous solutions [Buxton 1987], they will be disregarded. On a time scale of 10<sup>-16</sup> seconds, an electron can be separated from a water molecule. In the presence of other water molecules, the ionized water molecule becomes a hydronium ion and a hydroxyl ion in the 10<sup>-14</sup> second time scale. The free electron will be solvated in 10<sup>-12</sup> seconds and the three products will begin to diffuse away from the radiation track. By 10<sup>-7</sup> seconds, the primary products will be formed: hydrated electrons, hydrogen radicals, hydroxyl radicals, hydrogen gas, hydrogen peroxide and hydronium ions. Primary cellular damage is believed to be caused by hydrogen peroxide, hydroperoxide and superoxide [Ewing 1983] which are part of the secondary (or steady-state) product yield.

As long as the ionizing radiation is photons or electrons, the energy of the incoming radiation has not been shown to make a difference in the yields of radiolytic products. All photons and electrons are considered equal at the level of energy deposited in the material by interactions which involve energy transfer to the electrons

in the medium being irradiated. This equivalence does not hold for other radiations which interact with the target material by other mechanisms.

## Radiation Chemistry of Solids

The primary differences between the radiation chemistry of liquids and solids are due to the increased density of solids and the accompanying forces of interaction between the constituent atoms. About 85% of interaction electrons recombine for a G-value<sup>2</sup> for escape from the parent cation of  $\sim 0.3$ . The G-value for electron trapping is  $\sim 3.0$  for most solids, but trapping in crystalline organics does not normally occur [Willard 1987].

The radicals formed in a solid can be stable over a period of months or more. There is much evidence that new compounds are formed upon dissolving an irradiated organic solid in water [Swallow 1960]. Certain radiolytic products may be more stable in crystals with water of hydration than in anhydrous crystals, and such products may be favored in crystals where hydrogen bonding is important in determining the crystalline structure [Rogers and Kispert 1968].

## Material of Choice

Of all available compounds containing nitrogen, urea is one of the most studied by <sup>14</sup>N NQR. Not only has pure polycrystalline urea been studied, but also

<sup>&</sup>lt;sup>2</sup> G-values are a measure of yield or removal defined as the number of a chemical species created or destroyed for each 100 eV of energy absorbed in the material or solution.

urea complexes, substituted ureas, and structurally related guanidine compounds. In spite of all of this work, the  $\nu$  line of urea- $d_4$  has not been previously reported. Urea's crystalline structure has been investigated since 1902. The current lattice parameters are due to Swaminathan et al. [1984]. The crystal is held together by hydrogen bonding between the oxygen atoms and neighboring hydrogen atoms.

The spontaneous hydrolysis of urea occurs via the elimination reaction:

$$(NH_2)_2C=O + H_2O(\alpha) \rightarrow H-N=C=O + NH_3 + H_2O(\beta)$$
. [1-2]

The Greek letters denote that the water molecules on each side of the reaction have different constituent atoms [Blakeley et al. 1982]. The unimolecular decomposition reaction

$$(NH_2)_2C=O \rightarrow H-N=C=O + NH_3$$
 [1-3]

as studied by theoretical means has a large energy of activation (72.0 kcal mol<sup>-1</sup>) which precludes this reaction in favor of the hydrolysis reaction given in Eqn. [1-2] with a smaller energy of activation (35 kcal mol<sup>-1</sup>) [Koizumi et al. 1988].

## Method of Choice

The resonance method of NQR was first reported by Dehmelt and Krüger in 1950 and <sup>14</sup>N NQR was first reported by Watkins and Pound in 1952. Since that time, it has been used by physicists and chemists and has developed mostly in the shadow of NMR. The ease with which experimenters in the former Soviet Union could build NQR spectrometers in-house led to NQR being the method of choice for taking and confirming crystallographic measurements [Kitigorodskii 1960]. General descriptions of NQR have been given by many experts in the field. Most theoretical descriptions of the dynamic spin interactions in NQR have borrowed heavily from NMR.

#### Radiation Effects

Vargas and co-workers [1978] reported linear shifts in <sup>35</sup>Cl resonance frequencies and relaxation times in chlorates with <sup>60</sup>Co gamma irradiation. It is believed that the NQR spectral parameters of <sup>14</sup>N containing biologically significant organics should similarly change upon irradiation in an observable way. One paper [Hintenlang and Higgins 1992] demonstrates that effects are observable in at least one such compound, hydrated urea. Observing these changes will require the development of a systematic analytical method since biologically significant organic chemicals frequently have a complex structure and therefore complex NQR resonance spectra.

Currently published work on using <sup>14</sup>N NQR techniques to study radiation effects is limited to the reports of this laboratory. The basic knowledge on how to carry out NQR experiments is detailed in one document [Iselin 1992] and well characterized methods for analysis of the resulting magnetic resonance spectra have reached publication [de Beer and van Ormondt 1992. Iselin 1992].

#### Objectives

The goal of this work is to directly measure and quantify the effects of ionizing photons on an original, biologically significant substance, using <sup>14</sup>N NQR as the measuring tool and urea-water as the subject material. The specific objectives in this work are as follows:

- 1) Propose and test a method for quantifying changes in NQR signals.
- 2) Demonstrate the validity of NQR measurements taken on the Ritec spectrometer system by detecting and quantifying one or more unreported resonances as well as resonances previously described in the literature.
- 3) Follow up the work of Higgins and Hintenlang by replicating their measurements of the <sup>14</sup>N NQR spin-spin relaxation times for urea-water and extending the range of <sup>60</sup>Co gamma ray absorbed doses above 300 Gy.
- 4) Compare and correlate changes in the NQR experimentally derived quantities of urea-water to gamma ray dose to quantify the broadening of the electric field gradient at the nitrogen sites.
- 5) Make recommendations for further study in this area.

The following chapters will expand on the theory and experiments used in NQR. Chapter 2 gives the derivation of the NQR energy levels and resulting transition frequencies and also explores the relationship between theoretical and experimental quantities. Chapter 3 overviews and then details the different parts of the NQR spectrometer system, the experimental techniques, and several data analysis

techniques. Chapter 4 gives the results of the theoretical and experimental work while Chapter 5 provides the discussion. Conclusions and recommendations are given in Chapter 6. The four appendices expand on details in the text: Appendix A is a listing of the FORTRAN programs used, Appendix B gives parts of sample data and analysis files, Appendix C reports the Petersen data used, and Appendix D details Higgins' original work.

## CHAPTER 2 THEORETICAL BACKGROUND

## Theory of NOR

Nuclear quadrupole resonance is the branch of radiofrequency (RF) resonance spectroscopy which investigates the interaction between the nuclear electric quadrupole moment and the electric field gradient (EFG) produced by the electronic charge distribution about the nucleus of interest in a solid state material. This chapter will discuss the various theoretical components of NQR and their relationship to experiment, both for the static secular equations for transition energies and the dynamic spin systems which are excited by the RF interaction. Townes and Dailey theory, a static model for NQR, is also presented.

# Nuclear Electric Quadrupole Moment

The traditional semi-classical definition of the nuclear electric quadrupole moment, Q, is

$$eQ = \iiint (3z^2 - r^2) \varrho_{m_1 = 1}(\vec{x}) d^3x$$
 [2-1]

where e is the fundamental charge,  $\varrho_{m_l=I}(\vec{x})$  is the nuclear charge density when it is in the  $m_t=I$  state, and the triple integral is taken over the nuclear volume. Note that I

is the spin quantum number,  $m_I$  is the magnetic spin quantum number, and the z axis is the axis along which  $m_I$  is the projection of I. This form for the quadrupole moment is usually based on the Taylor series expansion about the nucleus for a charge distribution on an external electric field or on the multipole expansion in Cartesian coordinates of the electric potential V(z) [for example, see Jackson 1975].

A simple quantum mechanical derivation has be given [Wong 1990] using the correspondence principle. The quadrupole operator is defined as

$$e\hat{Q} = e(3\hat{z}^2 - \hat{r}^2)$$
 [2-2]

so that the quantum mechanical operator has the same form as the classical definition.

The quadrupole moments are then the expectation values of the appropriate nuclear wavefunctions

$$\langle e\hat{Q}_{m_l} \rangle = \langle Im_l | e\hat{Q} | Im_l \rangle$$
 [2-3]

for each  $m_I$  and the primary quadrupole moment is when  $m_I = I$ .

$$\langle e\hat{Q}_{I}\rangle = \langle II|e\hat{Q}|II\rangle$$
 [2-4]

Equation [2-4] in Dirac notation is the quantum mechanical equivalent to the classical expression given in Eq. [2-1].

#### Electric Field Gradient

Any electric field,  $\vec{E}$ , can be written as the negative gradient of a scalar potential, V,

$$\vec{E} = -\nabla V. \tag{2-5}$$

Component by component this means that

$$E_{x} = -\frac{\partial V}{\partial x}$$
  $E_{y} = -\frac{\partial V}{\partial y}$   $E_{z} = -\frac{\partial V}{\partial z}$ . [2-6]

The electric field gradient is then, in general,

$$\frac{\partial E_i}{\partial x_j} = -\frac{\partial^2 V}{\partial x_i \partial x_j}.$$
 [2-7]

It is important to note that since there is no preferred direction in space, an EFG tensor is symmetric about the main diagonal

$$V_{ij} = \frac{\partial^2 V}{\partial x_i \partial x_j} = \frac{\partial^2 V}{\partial x_j \partial x_i} = V_{ji}$$
 [2-8]

and the orientation of the axes is arbitrary, but defined by convention such that

$$\left|\frac{\partial^2 V}{\partial x^2}\right| \le \left|\frac{\partial^2 V}{\partial y^2}\right| \le \left|\frac{\partial^2 V}{\partial z^2}\right|$$
 [2-9]

in the principal axes representation where the terms not on the main diagonal are all identically zero. The component of the EFG in the z direction is then renamed eq.

$$eq = \frac{\partial^2 V}{\partial z^2}$$
 [2-10]

Of interest to NQR is the EFG at the nucleus due to the bonding structure of the surrounding electrons. Each different electronic configuration, including nonbonded, has a unique structure associated with it. The various charge distributions created by the electrons lead to different electric fields and therefore different electric field gradients at the nuclear site.

Since the electronic charge density at the nucleus is zero in the classical limit, the electric potential obeys Laplace's equation.

$$\frac{\partial^2 V}{\partial x^2} + \frac{\partial^2 V}{\partial y^2} + \frac{\partial^2 V}{\partial z^2} = \nabla^2 V = 0$$
 [2-11]

Deviations from axial symmetry are measured by the asymmetry parameter,  $\eta$ , which is defined by

$$\eta = \frac{\frac{\partial^2 V}{\partial x^2} - \frac{\partial^2 V}{\partial y^2}}{\frac{\partial^2 V}{\partial z^2}}.$$
 [2-12]

Equation [2-9] and Eq. [2-12] limit the possible values of the asymmetry parameter to

$$0 \le \eta \le 1$$
. [2-13]

# Quadrupole Hamiltonian and Associated Energy Levels

The strength of the interaction between the nuclear quadrupole moment and the principal EFG for a particular substance is given in the literature by  $\chi$ , the Nuclear Quadrupole Coupling Constant (NQCC).

$$\chi = \frac{e^2 qQ}{h}$$
 [2-14]

The NQCC is usually reported in units of megahertz (Mhz). This NQCC represents the constant term of the NQR interaction for a given nucleus, as will be seen below.

The traditional Hamiltonian for NQR is

$$\hat{\mathcal{H}}_{Q} = \frac{e^{2}qQ}{4I(2I-1)} \left[ 3\hat{I}_{x}^{2} - I(I+1) + \eta (\hat{I}_{x}^{2} - \hat{I}_{y}^{2}) \right]$$
 [2-15]

where I is the spin of the nucleus in question and  $f_t$  is the spin operator for the tth direction. Substituting the spin raising and lowering operators,

$$\hat{I}_{x} = \hat{I}_{x} \pm i\hat{I}_{y} \tag{2-16}$$

the Hamiltonian is

$$\hat{\mathcal{H}}_{Q} = \frac{e^{2}qQ}{4I(2I-1)} \left[ 3\hat{I}_{z}^{2} - I(I+1) + \frac{\eta}{2}(\hat{I}_{+}^{2} + \hat{I}_{-}^{2}) \right].$$
 [2-17]

This form of the Hamiltonian can be constructed by starting at the operator form

$$\mathcal{H}_{Q} = \vec{I} \vec{Q} \vec{I}$$
 [2-18]

where  $\vec{I}$  is the nuclear spin tensor and  $\vec{Q}$  is the quadrupole energy tensor (QET).

After expanding the matrix form in the principal axes representation in the same orientation as the EFG components (Eq. [2-9]) and noting that the components of the QET  $Q_{\psi}$  are proportional to the EFG components  $V_{\psi}$ , the results lead to the complete Hamiltonian down to an arbitrary constant.

$$\mathcal{H}_{Q} = A \left[ 3I_{z}^{2} - I(I+1) + \eta \left( \hat{I}_{x}^{2} - \hat{I}_{y}^{2} \right) \right]$$
 [2-19]

This constant, A, will now be further examined.

## Hamiltonian Constant

The classical definition of an arbitrary quadrupole moment is

$$Q_{i,j} = \iiint (3x_i x_j - \delta_{ij} r^2) \rho(\vec{x}) d^3x$$
 [2-20]

where i,j,k cycle through x,y,z,  $\delta_{ij}$  is the Kronecker delta,  $P(\vec{x})$  is a density function, and the triple integral is taken over the appropriate volume. Note that Eq. [2-20] becomes Eq. [2-1] when i=j=k and the density  $\rho$  is the nuclear charge density in the appropriate state. The energy associated with a classical quadrupole moment of charge in an electric potential has been given by Slichter [1990].

The classical Hamiltonian has the form

$$\hat{\mathcal{H}} = \frac{1}{6} \sum_{ij} V_{ij} \hat{Q}_{ij}$$
 [2-21]

with the quadrupole operator as

$$\hat{Q}_{ij} = e \sum_{p}^{Z} (3x_{ip}x_{jp} - \delta_{ij}r_{p}^{2})$$
 [2-22]

The sum in Eq. [2-22] is over the protons and  $r_p$  is the distance from the center of the nucleus to the proton. Since this operator can be shown to be a linear combination of

irreducible tensor operators, the Wigner-Eckart Theorem can be used to demonstrate that

$$\langle Im_I|\hat{Q}_{ij}|Im_I^{\prime}\rangle = A\langle Im_I|\frac{3}{2}(I_iI_j+I_jI_i)-\delta_{ij}I^2|Im_j\rangle \qquad [2-23]$$

which becomes

$$\langle e\hat{Q}_{I}\rangle = A\langle 3I_{z}^{2}-I^{2}\rangle$$
  
=  $AI(2I-1)$  [2-24]

This means that the constant has the form, incorporating the eq term.

$$A = \frac{e^2 q Q}{4I(2I-1)} \,. \tag{2-25}$$

This equates Eq. [2-19] with Eq. [2-15]. Note that the derivation of the constant used classical arguments. These classical arguments were necessary since a quantum mechanical operator is only defined to within an arbitrary constant.

## **Energy Levels**

To get the energy levels from the Hamiltonian, we will solve Schrödinger's equation for the energy eigenvalues.

$$\mathcal{H}|Im_{j}\rangle = E_{m}|Im_{j}\rangle \qquad [2-26]$$

In matrix form, Eq. [2-15] becomes, for the case I=1,

$$\mathfrak{H}_{Q} = \begin{bmatrix} A & 0 & \eta A \\ 0 & -2A & 0 \\ \eta A & 0 & A \end{bmatrix}.$$
 [2-27]

The secular equations are found from

$$\det \left[ \hat{\mathcal{H}}_{O} - EI \right] = 0$$
 [2-28]

or

$$\begin{vmatrix} A - E & 0 & \eta A \\ 0 & -2A - E & 0 \\ \eta A & 0 & A - E \end{vmatrix} = 0.$$
 [2-29]

The eigenvalues are

$$E = (1+\eta)A, -2A, (1-\eta)A$$
 [2-30]

and the energy levels are

$$E_0 = -2A$$
 [2-31] 
$$E_{+1} = (1 \pm \eta)A.$$

The three possible transitions are

$$v_{+} = \frac{(3+\eta)A}{2\pi\hbar}$$
  $v_{-} = \frac{(3-\eta)A}{2\pi\hbar}$   $v_{d} = \frac{2\eta A}{2\pi\hbar}$  [2-32]

or

$$v_{+} = \frac{(3+\eta)e^{2}qQ}{4h}$$
  $v_{-} = \frac{(3-\eta)e^{2}qQ}{4h}$   $v_{d} = \frac{e^{2}qQ\eta}{2h}$ . [2-33]

These can be rearranged to give NQCC and the asymmetry parameter when any two of the three transitions are known. In terms of  $\nu_+$  and  $\nu_-$ , they are

$$\chi = \frac{2}{3} (v_+ + v_-)$$
 [2-34]

and

$$\eta = 3 \frac{(\nu_+ - \nu_-)}{(\nu_+ + \nu_-)}.$$
 [2-35]




Figure 2-1 Energy level diagram for spin I = 1 showing the three possible transitions.

In a pulsed NQR experiment, a burst of RF energy is added to the sample at the proper frequency to stimulate one or more of the three transitions,  $\nu_+$ ,  $\nu_-$ , or  $\nu_d$ . As the system relaxes it radiates energy at the resonance frequency. The NQCC and asymmetry parameter can be determined using Eq. [2-34] and Eq. [2-35] after measuring the correct values of  $\nu_+$  and  $\nu_-$  for the sample.

#### Townes and Dailey Theory

Two parameters are obtained from NQR experiments:  $\chi$  and  $\eta$ . These two parameters can be related to the electronic densities around the target nucleus through an idea suggested by Townes in 1948 and elaborated upon by Townes and Dailey in 1949. While more complete quantum chemical pictures of the electronic structure are available at the current time, this simplified model provides acceptable accuracy for a model that only has two free parameters, especially if a series of compounds with a bonding trend are compared. This discussion will follow the outline of the various workers from Bray's group at Brown University [Marino 1969, Subbarrao 1978].

In an NQR experiment, a given target nucleus is surrounded by its own electrons, other nuclei, and their electrons. Each of these charged particles contributes to the EFG at the target nucleus. This is shown symbolically in Eq. [2-36] with T representing the target nucleus and N representing the neighboring nuclei.

$$q^{T} = q_{e^{-}}^{T} + q_{e^{+}}^{N} + q_{e^{-}}^{N}$$
 [2-36]

The electronic terms must be dealt with quantum mechanically but the nuclear term can be treated classically.

The main approximation in the theory is to ignore contributions to the EFG except those from the electrons of the target nucleus itself. The majority contribution is from the valence electrons since the s orbitals and any other closed orbital will be spherically symmetrical or nearly so. The exception to this spherical symmetry would be if there are polarization effects in the closed shell and they are ignored due to their

small size, although they could be compensated for with the Sternheimer shielding factor, if necessary. The ignored terms are the contributions to the EFG from other nuclei, the electrons of other nuclei, the overlap electronic densities, and any electrons of the target nuclei besides the valence electrons.

To determine the contribution from each electron, recall that classically a charge of -e a distance of r from the nucleus produces a potential of

$$V(r) = -\frac{e}{r}.$$
 [2-37]

The EFG component in the principal z direction,  $V_{zz}$  (see Eq. [2-10]) is

$$V_{z}(r) = -e \frac{(3\cos^2\theta - 1)}{r^3}$$
 [2-38]

where  $\theta$  is the angle between the z axis and r. Quantum mechanically, the correct value is the expectation value given by

$$eq = \langle V_{zz} \rangle = -e \left( \frac{3\cos^2\theta - 1}{r^3} \right).$$
 [2-39]

The approximations by Townes and Dailey are justified to a great extent by the  $r^3$  relationship between the distance to the electron and the corresponding small contribution to the EFG.

The second major approximation is to treat the molecular wave functions of the electrons as linear combinations of atomic orbitals (LCAO) with the form

$$|\psi\rangle = \sum_{j} a_{j} \phi_{j}. \qquad [2-40]$$

In general, atomic orbitals are separable into a function of r and the spherical harmonics  $Y_{-}^{I}$ .

$$\phi = f(r) Y_m^l(\theta, \phi)$$
 [2-41]

Calculation of  $q_{zz}$  thus becomes

$$q_{zz} = \frac{3m^2 - l(l+1)}{2l-1} \frac{2}{2l+3} \left\langle \frac{1}{r^3} \right\rangle.$$
 [2-42]

The only important case for nuclei like  ${}^{2}\mathrm{H}$  or  ${}^{14}\mathrm{N}$  is l=1 for the p electrons. The  $p_{z}$  electrons with m=0 contribute the most to  $q_{zz}$  with

$$q_{zz}|_{p_z} = -\frac{4}{5} \left\langle \frac{1}{r^3} \right\rangle \equiv q_p. \qquad [2-43]$$

The  $p_x$  and  $p_y$  electrons with  $m = \pm 1$  yield a value of

$$q_{zz}|_{p_z} = q_{zz}|_{p_y} = \frac{2}{5} \left(\frac{1}{r^3}\right) \equiv -\frac{1}{2}q_p.$$
 [2-44]

Notice that Laplace's equation (Eq. [2-11]) is satisfied with

$$q_{xx} = q_{yy} = -\frac{1}{2}q_{xx}.$$
 [2-45]

Using  $n_x$ ,  $n_y$ , and  $n_z$  to represent the orbital occupation numbers for the corresponding p electrons, the following relationships can be written for each molecular orbital (MO):

$$q_{xx} = [n_x - \frac{1}{2}(n_x + n_y)]q_p$$
 [2-46]

$$q_{yy} = [n_y - \frac{1}{2}(n_z + n_x)]q_p$$
 [2-47]

$$q_{xx} = [n_x - \frac{1}{2}(n_y + n_z)]q_p$$
. [2-48]

By summing over all present MOs, the general relationship for the NQCC can be obtained.

$$e^2qQ = \sum_i [n_{xi} - \frac{1}{2}(n_{xi} + n_{yi})]e^2q_pQ$$
 [2-49]

Following the usual convention, this is rearranged to give

$$\frac{e^2 q Q}{e^2 q_u Q} = \alpha = n_z - \frac{1}{2} (n_x + n_y)$$
 [2-50]

and

$$\frac{[e^2q_{xx}Q - e^2q_{yy}Q]}{e^2q_{y}Q} = \alpha \eta = \frac{3}{2}(n_x - n_y).$$
 [2-51]

The quantity  $e^2q_pQ$  is the NQCC for a single 2p electron and it cannot be measured experimentally in nitrogen due to Hund's Rule on the filling order of orbitals. Since each of the three 2p orbitals in atomic nitrogen has one electron, the total wave function is spherically symmetric. Spherical symmetry means that there is no quadrupole interaction since there is no energy level splitting. Different authors

have assumed different values for  $e^2q_pQ$ , always in the range suggested by other measurement methods. These values have been in the range of 8 MHz to 14 MHz. Popular values are 8.4 MHz [Subbarao 1978] and 10 MHz [Oja 1973, Hintenlang and Higgins 1992]. For this work, a value of 10 MHz will be used. It is noted that this arbitrariness in the value of  $e^2q_pQ$  means that the resultant occupation numbers derived from the Townes and Dailey analysis are themselves somewhat arbitrary. Trends in the occupation number values will have greater validity than their actual numerical values.

As an example of how Townes and Dailey theory can be used, consider the compound urea. Values for NQR parameters of urea have been known since 1959 [Chiba et al., Minematsu]; current values [this work] are

$$\chi = 3507.47 \pm 0.006 \text{ kHz}$$
 and  $\eta = 0.32242 \pm 0.00015$ . [2-52]

To apply the Townes and Dailey theory, first examine the symmetry of the molecule. Urea is known to be planar with the nitrogen lone pair electrons out of the plane and the amide groups relatively symmetrical about the C-N bond. Assign the x-y plane to the molecule with the carbon atom along the y axis. The bonding in urea is known to correspond closely to  $sp^2$  hybridization. A set of  $sp^2$  orbitals that match the given geometry with each bond angle set to  $120^\circ$  are as follows

$$\psi_{NC} = \frac{1}{\sqrt{3}}s + \sqrt{\frac{2}{3}}p_y, \text{ and}$$
 [2-53]




Figure 2-2 Crystal structure of Urea [Values from Caron and Donohue 1964]

$$\psi_{NH} = \frac{1}{\sqrt{3}} s \pm \frac{1}{\sqrt{2}} p_x - \frac{1}{\sqrt{2}} p_y \qquad [2-54]$$

where  $\Psi_{NH}$  gives the two wavefunctions for the two N-H bonds. The needed occupation numbers for these orbitals are  $\sigma_x$ ,  $\sigma_{NC}$ , and  $\sigma_{NH1}$  (=  $\sigma_{NH2}$ ). These will be shortened to  $\pi$ ,  $\sigma_C$ , and  $\sigma_M$  for convenience. The occupation numbers for the  $p_x$ ,  $p_y$  and  $p_z$  orbitals of nitrogen, labelled  $n_z$ ,  $n_z$  and  $n_z$ , respectively, are given as

$$n_x = \frac{2}{3}\sigma_C + \frac{1}{3}\sigma_H$$
,  $n_y = \sigma_H$ , and  $n_z = \pi$ . [2-55]

We know from Eq. [2-43] and Eq. [2-44] that each  $p_z$  electron adds  $q_p$  to the EFG and each  $p_{z,y}$  electron adds - $\frac{1}{2}q_p$  to the EFG. Equation [2-50] for the case of urea becomes

$$\alpha = \pi - \overline{\sigma} = \pi - \frac{2}{3}\sigma_H - \frac{1}{3}\sigma_C \qquad [2-56]$$

and Eq. [2-51] becomes

$$\alpha \eta = \sigma_H - \sigma_C. \qquad [2-57]$$

Before using these relationships, one must check to see if they are reasonable. Checking the convention given in Eq. [2-9], it is reasonable that the lone pair  $\pi$  has the largest contribution to the EFG. Since we have three unknown parameters and only two knowns, it has been customary to assign to one of the parameters the known value for that parameter in a related compound. For urea, the assigned value is  $\sigma_H = 1.33$ , the value for ammonia. Using the three known values, the orbital occupation numbers for urea are

$$\sigma_C = \sigma_H - \frac{\chi}{\chi_p} \eta = 1.33 - \frac{3507.47}{10000} 0.32242 = 1.217$$
 [2-58]

and

$$\pi = \alpha + \overline{\sigma} = \sigma_H + \frac{\chi}{\chi_p} \left(1 - \frac{\eta}{3}\right) = 1.643.$$
 [2-59]

These values are for comparison to ammonia and related compounds only since the value of  $\sigma_H$  was set to the value for ammonia.

The exact values for  $\chi$  and  $\eta$  may be difficult to calculate if the values for the transition frequencies are uncertain. One source of uncertainty is where the center frequency of the resonance occurs. Since NQR can be performed on a polycrystalline sample as well as a single crystal, there may be (and usually are) some resonance sites which have slightly different resonance frequencies. The shape of the resonance distribution is usually Lorentzian, Gaussian, or some combination of the two. As RF energy is added to the system in pulses, the nonideal pulse shape distribution is folded into the resonance distribution. That means that some of the resonance sites are at different frequencies and some at the same frequency are not affected by the pulse. These differences for each site combine to give a complex resonance picture. The pulses are controlled by their voltage (height), a measure of how much energy is transferred to the system by each pulse, and their width, a measure of how long the pulse lasts. For a pulse of a given height, the longer the pulse the more the nuclear spin vector is forced to rotate in response to the pulse. A pulse which gives the

maximum FID amplitude during an NQR experiment is called an effective 90° pulse. 

An effective 180° pulse therefore yields no output signal (or gives a minimum) yet does interact with the spin system. This section has been done by analogy to NMR due to the complex mathematics involved that do not add to this work and cannot be explicitly calculated for the cases presented here. These subjects are additionally dealt with in more detail in the following sections.

#### Spin Relaxation Times

The population distributions of spins in NOR obey Boltzmann's distribution

$$\frac{N_1}{N_0} = e^{-\frac{\Delta E}{kT}}$$
 [2-60]

where  $\Delta E$  is the difference in the energy levels,  $E_1 - E_0$ , k is Boltzmann's constant, and T is the absolute temperature. At a transition frequency of 3 MHz at the temperature of liquid nitrogen (LN<sub>2</sub>), 77 K, the ratio of  $N_0$  to  $N_1$  becomes

$$N_0: N_1 \approx e^{-1.870 \times 10^{-6}} \approx 0.99999813$$
. [2-61]

Thus the two energy levels are almost equal in population when the system is at thermal equilibrium. If we take a model spin system with  $\sim 10^8$  spins (much smaller than the typical spin system encountered in <sup>14</sup>N NQR), then the excess number of spins in the lower energy level,  $N_0 - N_1$ , would be  $\sim 100$ . We can represent the net

<sup>&</sup>lt;sup>1</sup> This definition is used to provide an analogy to the NMR experiment. The actual spin system dynamics are more complex in NQR than in NMR. The Bloch equations used for NMR do not apply to I=1 NQR or any other system which has more than one transition energy (Sanctuary and Krishnan 1993).

behavior of this spin system at thermal equilibrium at the temperature of  $LN_2$  with no spins in the upper level and 100 in the lower level.

We can excite this spin system and then model the time dependent relaxation of the system by  $g_1(t)$ . The exact form of  $g_1(t)$  depends on the way the spin system couples to the lattice for the removal of the excess energy. For excited spins to deexcite to the lower level, they must give up their excess energy to the lattice. The time in which the function  $g_1(t)$  decays from  $g_1(0)$  to  $g_1(0)/e$  (where e is the base of the natural logarithm) is represented by a characteristic time constant,  $T_1$ , the spin-lattice relaxation time, such that

$$g_1(T_1) = \frac{g_1(0)}{g}$$
. [2-62]

The spin-lattice relaxation time can be measured by the two pulse method of inversion-recovery which uses an *effective* 180° pulse followed by an *effective* 90° pulse after a time delay of duration  $\tau$ . The spin-lattice relaxation time is determined from a fit of the echo amplitude as a function of  $\tau$ .

Another way for an individual spin to give up its excess energy is to transfer the excess energy to another spin. This does not change the total energy of the spin system. The excited spin system's ability to transfer energy between spins can be modeled by a function  $g_3(t)$ , which has a characteristic time constant  $T_2$ , referred to as the spin-spin relaxation time. The spin-spin relaxation time is defined in an analogous manner to the spin-lattice relaxation time in Eq. [2-60]. Note that the physical relationship between  $g_1(t)$  and  $g_2(t)$  requires that

$$T_2 \leq T_1. \tag{2-63}$$

This is because a  $T_2$  longer than  $T_1$  would be meaningless since  $T_2$  is defined only when the system is in an excited state.

The other vital spin relaxation time is the effective spin-spin relaxation time  $T_2^*$  also known as the inverse linewidth parameter because it is inversely proportional to the full width at half maximum (FWHM) of the resonance line. The inverse linewidth parameter is the easiest dynamic NQR parameter to determine as it is the characteristic time constant of a free induction decay (FID) produced by a single effective 90° pulse.

#### Lineshapes

Fourier analysis is often used for the analysis of real linear systems where the basis set consists of any combination of sinusoids. These sinusoids can be of the form  $\cos(2\pi f t + \phi)$  or  $e^{12\pi f t}$ , where i is  $\sqrt{-1}$ . When the lineshapes are Lorentzian [refer to  $g_2(t)$  in the previous section], magnetic resonance spectra can be fit to the following model:

$$v(t) = \sum_{i=1}^{N} A_i \cos(2\pi f_{d_i} t + \phi_i) e^{-\frac{t}{T_{2i}^*}}$$
 [2-64]

where v(t) is the data signal, N is the number of resonance sites,  $A_l$  is the amplitude of the ith site,  $f_l$  is the measured difference frequency between the resonance

frequency and the applied reference frequency,  $\phi_i$  is the phase angle, and  $T_{2i}^*$  is the inverse linewidth parameter. This implies a Fourier transform (FT) of a sum of Lorentzian lineshapes.

When the FT has been calculated, the magnetic resonance parameters can be identified from the location of the resonance peaks and the associated linewidths. In the absorption spectrum (cosine part of the transform), the centroid of a peak is the difference frequency identified in Eq. [2-62]. The inverse linewidth parameter is inversely proportional to the full width at half of the maximum value (FWHM). The exact relationship is determined by the precise lineshape. For a Lorentzian line, the relationship is

$$T_2^* = \frac{2}{FWHM(\omega)} = \frac{1}{\pi FWHM(\nu)}$$
 [2-65]

In taking magnetic resonance data, the phase information is often lost. Phase here has two different meanings. First, the model given in Eq. [2-62] has a phase  $\phi_i$  for each individual site. These values are often distorted in the electronic detection of the resonance signals. The presence of this physical phase leads to a second phase and this is from the imaginary part of the resulting Fourier transform. When the FT is complex, the real part is the amplitude transform and the imaginary part gives the phase. With all phase information lost in the NQR spectrometer, the FT becomes not corrected for phase distortion. This distortion can cause shifts in line positioning and line widths when the FT absorption spectrum is estimated.

# CHAPTER 3 EQUIPMENT, EXPERIMENT, AND PROCEDURES

A <sup>14</sup>N NQR radiation effects study involves comparing the <sup>14</sup>N NQR spectral parameters from unirradiated samples to those of irradiated samples. This chapter starts with a summary of the experiment. That is followed by a short description of the primary components in the pulsed NQR spectrometer system [Oja and Petersen 1973, Petersen and Oja 1974]. After the irradiation technique is detailed, a description is also given of the experimental NQR techniques used.

# Summary Description of Equipment

Approximately 15 g of the polycrystalline solid to be studied is placed in a sample vial. The sample vial is put inside a primary sample coil wound from magnet wire in such a way as to maximize the response of the coil in the desired frequency range. A secondary coil is wound with twice the inductance of the primary coil to be put in the impedance matching network to allow for fine tuning of the frequency response of the equipment. The primary coil and sample are placed in an aluminum can for shielding from undesired RF interference and then submerged in a dewar of liquid nitrogen (LN<sub>2</sub>). The dewar, matching network, and preamplifier are placed in a glove bag filled with dry nitrogen gas to purge the water vapor from around the dewar. Ice buildup on the cables and dewar is known to cause arcing and is avoided

by using the dry nitrogen. Although the glove bag is not "air tight" it still keeps the humidity level around the dewar down to an acceptable level.

The RF source is a continuous wave (CW) high resolution frequency source. The output of the CW source is fed to a gated amplifier while being monitored with a universal counter in frequency mode. The gated amplifier allows either single or dual pulse sequences to be applied to the sample coil through the impedance matching network. The gated amplifier is capable of providing variable pulse widths, delay times, and sequence intervals. The gated amplifier is phase locked to a broadband receiver. The resonance signal from the sample coil is first amplified in a chargesensitive, high-impedance pre-amp. When the pulses from the gated amplifier are being sent to the coil, the receiver is locked off by diode switching. After the pulse is sent, the receiver is turned on again by diode switching to accept any signal from the sample. This switching is necessary to avoid damaging the receiver or losing the < 100 mV return signal because the pulses are ~1400 V. The receiver uses phase sensitive detection to discriminate between the return signal and electronic noise. The output from the receiver is sent to a digital oscilloscope for signal averaging and storage. The digital waveforms can be transferred to a personal computer for analysis. A diagram of the experimental setup is shown in Fig. 3-1.




Figure 3-1 Diagram of experimental setup [Higgins 1990, Iselin 1992]

## Equipment Specifications

#### Continuous Wave Frequency Source and Monitor

The CW RF source is a Matec¹ Model 110 High Resolution Frequency Source with an output range of 0.5 Hz to 5 MHz. According to the manufacturer,² the stability of the square wave output is better than 6 significant figures. The short term stability of the oscillator is rated at 2 parts in 10², with a temperature dependence of 1 part in 10<sup>6</sup> per °C change in ambient room temperature. The RF source has been left on continually according to the manufacturer's suggestion for maximum stability. The observed stability is ±3 Hz over a 4 hr period if the frequency source has had >24 hrs to stabilize at the reference frequency. If the frequency has been changed in the last 12 hours, the frequency source has a tendency to drift back towards its previous setting and is stable to only ±30 Hz for a 4 hr period.

The output of the CW source is monitored using a Hewlett-Packard<sup>3</sup> Model 5314A Universal Counter. The maximum frequency resolution<sup>4</sup> for this counter is 0.1 Hz in the frequency range from 10 Hz to 10 MHz. The mode used for data collection had a frequency resolution of  $\pm 10$  Hz, which is about 3 parts in  $10^7$  at 3 MHz.

<sup>&</sup>lt;sup>1</sup> Matec Instruments, Inc., Hopkinton, MA 01748.

<sup>&</sup>lt;sup>2</sup> Matec High Resolution Frequency Source Model 110 Operation and Service Manual, Matec Instruments, Inc.

<sup>3</sup> Hewlett-Packard, Santa Clara, CA 95051.

<sup>&</sup>lt;sup>4</sup> Hewlett-Packard Operating and Service Manual 5314A Universal Counter.

## Gated Amplifier

The gated amplifier is a RITEC<sup>5</sup> High Power Gated RF Amplifier Model RX 1-2500C. The amplifier<sup>6</sup> requires a positive trigger mechanism and a CW signal of 1 V rms as input and outputs 2.5 kW RF pulses at the CW input frequency into a 50  $\Omega$  load. Standard operating frequency range is from 100 kHz to 5 MHz. Maximum rated pulse widths are ~550  $\mu$ s with a 0.1% duty cycle. The RF signal is output in either single or dual pulses of ~0.2  $\mu$ s to ~550  $\mu$ s in width with a time delay between pulses of from 0.01 ms to 200 ms. The pulse sequences can be automatically repeated at intervals of from 0.1 x 10° to 1 x 10° ms.

The controls of the pulse sequence interval are a knob, which ranges from 0.1 to 1 by increments of 0.1, and a wheel counter, which controls the power of ten exponent. The knob control is marked for intervals larger than the actual intervals. Calibration values are posted on the amplifier next to the controls and are given in Table 3-1. The time required for 1000 pulses is timed and the result is the calibrated value for each setting. External triggers and gates can be optionally applied if desired. The amplifier has an RF pulse output monitor for the user to view the shape and amplitude of the pulses on channel two of the oscilloscope during setup without effecting the signal to the load. The pulse width and pulse separation controls have demonstrated a tendency to drift if the top multiple settings are used. This makes two

<sup>&</sup>lt;sup>5</sup> RITEC, Inc., Warwick, RI 02886.

<sup>&</sup>lt;sup>6</sup> RITEC Manual for the N.Q.R. spectrometer system.

Table 3-1 Pulse sequence interval calibration

C.W. Level Multiplier Knob Marking	Actual Value
0.1	0.061
0.2	0.118
0.3	0.203
0.4	0.293
0.5	0.353
0.6	0.422
0.7	0.510
0.8	0.598
0.9	0.693
1	0.772

pulse experiments tricky at best and unreliable if pulse widths of >40  $\mu$ s or pulse delays of >20 ms are needed.

# Coils and the Impedance Matching Network

The sample coils were made in the laboratory from coated 16 gauge magnet wire wrapped around an empty sample vial to ensure that the coil is of the proper size. The coils were then coated in epoxy to retain their shape. Details of the coil design are given in Iselin [1992] with formulas taken from Wheeler [1928], Smith [1941], and Fukushima and Roeder [1981]. With a particular set of sample vial size, spectrometer system, and applied frequency, the only unconstrained variable is the Q of the coil. The higher the Q value, the more sensitive the coil to the resonance signal, but a higher Q value also means that the coil will require a longer time to recover from a pulse and will have a narrower resonance frequency range. A

workable solution is to have a low Q value that is still high enough for successful experimentation. For a given wire size, the only independent variable is the number of turns in the coil due to the way our coils were wound without a spacing wire.

In addition to the sample coil, a secondary coil was wound to go in the impedance matching network. This secondary coil should have approximately twice the inductance of the primary coil. Multiple sample coils were wound with the highest Q coils being kept for actual work. The secondary coils are not required to have as high a Q as the sample coils.

#### Broadband Receiver with Phase Sensitive Detector

The RITEC model BR-640 broadband receiver? was designed for a linear response over its entire operating range from 100 kHz to 50 MHz. The receiver is capable of signal amplification of from -12 dB to 64 dB in 4 dB steps. The receiver digitizes the resonance signal at the frequency of the applied RF and then amplifies the signal. The noise is mostly out of phase with the RF and will be filtered. Any in-phase signal will be passed through the filtering at the beat frequency between the reference frequency (applied RF) and the resonance frequency. These beat frequencies are seen in the subsequent Fourier transform of the output signal and not the original resonance frequencies. The following filters are built into the receiver: 100 kHz, 500 kHz, and 1 MHz high pass filters and 3 MHz or 12 MHz low pass

<sup>&</sup>lt;sup>7</sup> RITEC Manual for the N.O.R. spectrometer system.

filters. Any high/low combination of filters is available for use. The settings used in this work were low pass at 1 MHz and high pass at 12 MHz.

# Digital Oscilloscope and Personal Computer

Multiple sweeps are averaged to further increase the signal-to-noise ratio by minimizing the effects of random noise. The averaged spectra are viewed on a Nicolet<sup>8</sup> Digital Oscilloscope Model 4094C with model 4180 storage control plug-in module and an F-43 dual floppy diskette data storage plug-in module. The Nicolet is externally triggered by the gated amplifier, is capable of averaging up to 32767 sweeps, and can digitize the data at dwell times from 5 ns per point up to 10 s per point for up to 15767 different points. The final spectra are saved to 5¼" DSDD floppy disks in a proprietary format which can store up to 20 spectra of 15767 points on a single floppy disk. The spectra can also be exported to a personal computer via HENRY, a data transfer software package supplied by Nicolet. The transfer is via a null modem board installed on the Nicolet to a serial port on the computer. The usual settings on the oscilloscope were 10 µS per point at 100 mV full scale.

<sup>8</sup> Nicolet Instrument Corp., Madison, WI 53711-0288.

<sup>9</sup> HENRY - 4094, version 1.2, Part # 177-001600.

## Experimental Technique

### Sample Preparation

The sample vials  $^{10}$  to be filled were first numbered and weighed while empty on an electronic balance.  $^{11}$  Fifteen grams ( $\pm 0.5$  g) of the sample material were placed in each vial. If a solvent was added, it was measured with a disposable pipette. Deionized ultrafiltered water  $^{12}$  was the only solvent used in this work. The vial lids were replaced tightly and sealed with plastic tape.  $^{13}$  This tape eventually cracks under the repeated thermal stress of cooling to LN<sub>2</sub> temperature and warming back up to room temperature and must be replaced routinely.

## Irradiation of Samples

The irradiator used was built by the J. L. Sheppard Company and reported by Hanrahan. The only modifications from the article were an added safety interlock on the irradiator door to prevent accidental exposures and additional external shielding. The source was originally a nominal 400 Ci (15 TBq) of 60Co. With the encapsulated source in the shielded position, the shield door can be opened. For irradiation, the source is lowered to the center of the irradiation chamber and touches the chamber

 $<sup>^{10}</sup>$  Kimble Opticlear (23 x 85 mm) vials with screw cap, available from Fisher Scientific, Orlando, FL 32809.

<sup>&</sup>lt;sup>11</sup> Ohaus Model GA200D, Ohaus Corp., Florham, NJ 07832.

<sup>&</sup>lt;sup>12</sup> FisherChemical W2-4 Lot No. 903294, Fisher Scientific, Fair Lawn, NJ 07410.

<sup>&</sup>lt;sup>13</sup> Scotch brand tape series 23-2087-9 by 3M, St. Paul, MN 55144.

floor. Samples can be placed in the chamber at any location except directly under the source, to prevent sample breakage. The baseline calibration of the irradiator was by Fricke dosimeter in 1989<sup>14</sup> and was 0.52 Gy s<sup>1</sup> @ 5 cm (3100 rad min<sup>1</sup> @ 2"). A more recent calibration was reported by Jamil [1992] as 0.25 Gy s<sup>1</sup> @ 5 cm (1500 rad min<sup>1</sup> @ 2"). The irradiator was originally under the control of Dr. P. M. Achey in the Microbiology and Cell Science department and is presently under the control of Prof. J. S. Tulenko in the Department of Nuclear Engineering Sciences at the University of Florida.

The samples were placed in a circle on a wooden board marked with the distance from the source position. The samples were placed on the outer edge of the circle marked as 2 inches from the source. The samples were turned 180° after the first half of the irradiation time, starting with all vial labels in and finishing with all labels facing away from the source. This was done to provide uniform energy deposition by minimizing self-shielding effects in the sample. Active dosimetry for data runs was performed by adding a sample vial with a radiachromic imaging film<sup>15</sup> inside. The reading from the film, containing an aminotriphenylmethane derivative radiation sensitive dye, was used as a check on the irradiation levels as compared to Jamil's calibration with a decay correction. All radiachromic film results, consistent

<sup>&</sup>lt;sup>14</sup> Notes from Dr. P. M. Achey, Department of Microbiology and Cell Science, University of Florida.

<sup>15</sup> GAFCHROMIC<sup>™</sup> dosimetry media D-200, FWT radiachromic radiation measurements, Far West Technology, Goleta, CA 93017.

with Jamil after correcting for radioactive decay of the source strength, yielded 0.20 Gy  $s^1 @ 5$  cm (1200 rad min<sup>-1</sup> @ 2").

### Pulse Selection

The selection of pulse height and width for a set of experimental runs is based on the fact that the a shorter pulse width can be used with a higher voltage (height) to achieve the desired spin system interaction. A large pulse height is desirable as it allows for a shorter pulse width to provide a pulse with the desired spin system interaction, usually an effective 90° pulse. With the coils in place and tuned according to the manufacturer's instructions, the maximum voltage that can be applied without arcing at either the coil or the matching network is found by slowly increasing the voltage. With the pulse height set, the amplitude of the FID is monitored as the pulse width is increased. The first maximum value for the FID is the effective 90° pulse and the first zero or minimum is the effective 180° pulse.

#### Data Collection

With the equipment set up as in Fig. 3-1, the oscilloscope, gated amplifier, and receiver can be powered on but the high voltage should remain off. The frequency source is adjusted to the desired frequency setting. After a brief warmup period, including a self-test for the Nicolet oscilloscope, the "Receive Tuning" knob on the matching network is adjusted by viewing the noise on channel A and turning

the knob of the variable capacitor until the noise signal has maximum amplitude. This setting provides the maximum sensitivity to the input frequency. The usual settings for channel A during setup are  $\pm$ "100" mV full scale and "10  $\mu$ s" dwell time

The high voltage switch on the gated amplifier is then turned on and the high voltage pulse is viewed on channel B of the oscilloscope. A sequence interval of  $10^3$  is best for viewing the pulses. Gate #1 on the oscilloscope must be on; the pulse width should be set initially near "20  $\mu$ s" for urea-type compounds. The pulse is being viewed through a 91:1 step down and the high voltage should be adjusted to "1.06" on the high voltage ten-turn potentiometer. This setting gives good repeatability with little chance of arcing under all conditions. The resulting pulse is  $\sim$  1400 V peak-to-peak. The usual settings for channel B during setup are " $\pm$ 40 V" full scale and "<5 ns" interpolated dwell time.

Data were collected for various sweep counts and pulse repetition rates. Due to the strong signal from the  $\nu_{\star}$  line of urea, 1000 sweeps were averaged to form a data run with 0.6 x 10<sup>4</sup> ms between sweeps. The low intensity of the  $\nu_{\star}$  line of urea only allowed 200 sweeps with 0.8 x 10<sup>5</sup> ms between sweeps due to time and stability constraints. Temperature was maintained at 77 K in a dewar which kept the sample submerged in LN<sub>2</sub> for up to 12 hours.

#### Analytical Techniques

The analytical techniques to be used to analyze the raw data are the modulussquared Fourier transform, state space singular value decomposition, and nonlinear
least squares curve fitting. The techniques are presented in this order so that the
amount of information available at each step in the analysis is increased and the next
step's result will be a more accurate estimate of the physical parameters: the
resonance amplitude, the resonance frequency, the relative phase, and the inverse
linewidth parameter. Only a brief description of each technique is given here. For a
more detailed explanation, see Iselin [1992]. After describing each technique, the
data manipulation using these techniques will be described.

#### Fourier Transform

The best way to avoid phase errors is to calculate the modulus-squared Fourier transform, otherwise called the power spectrum or power spectral density (PSD).

While the PSD is a mixture of the absorption and dispersion spectra, it does allow the experimenter to locate individual peaks in the frequency domain and to approximate the relative amplitudes of each frequency component. Known resonance sites can be identified as well as peaks due entirely to noise. The locations and line widths are only approximate when using the PSD, so their values should be considered only first approximations and not reported as actual experimentally determined values.

#### Singular Value Decomposition Methods

#### Analytical Techniques

The analytical techniques to be used to analyze the raw data are the modulussquared Fourier transform, state space singular value decomposition, and nonlinear
least squares curve fitting. The techniques are presented in this order so that the
amount of information available at each step in the analysis is increased and the next
step's result will be a more accurate estimate of the physical parameters: the
resonance amplitude, the resonance frequency, the relative phase, and the inverse
linewidth parameter. Only a brief description of each technique is given here. For a
more detailed explanation, see Iselin [1992]. After describing each technique, the
data manipulation using these techniques will be described.

## Fourier Transform

The best way to avoid phase errors is to calculate the modulus-squared Fourier transform, otherwise called the power spectrum or power spectral density (PSD).

While the PSD is a mixture of the absorption and dispersion spectra, it does allow the experimenter to locate individual peaks in the frequency domain and to approximate the relative amplitudes of each frequency component. Known resonance sites can be identified as well as peaks due entirely to noise. The locations and line widths are only approximate when using the PSD, so their values should be considered only first approximations and not reported as actual experimentally determined values.

#### Singular Value Decomposition Methods

The linear algebra method of singular value decomposition (SVD) is a powerful analytical tool which has only been applied to magnetic resonance data since 1985 [Barkhuijsen et al.]. The SVD theorem [Hill 1986] states that any matrix A with m rows and n columns  $(m \times n)$  can be factored as

$$A = U \wedge V^{\dagger}$$
 [3-1]

where U is  $m \times n$  with orthonormal columns,  $\Lambda$  is  $n \times n$  diagonal with positive, real values in the upper left and zeroes elsewhere, and  $V^{\dagger}$  is the Hermitian conjugate of an  $n \times n$  othogonal matrix. The positive non-zero values on the diagonal of  $\Lambda$  are called the singular values of A.

## Hankel Singular Value Decomposition

A non-iterative SVD procedure for retrieving harmonics was developed by Kung and co-workers and published in 1983 using state space concepts. This method was implemented for magnetic resonance time domain spectra via linear algebra and published under the name Hankel Singular Value Decomposition (HSVD) by Barkhuijsen et al. in 1987. The name Hankel is used because the HSVD method takes advantage of the Hankel structure of the manipulated data matrix: all elements on a cross diagonal (running from lower left to upper right) have the same value. The model function is modified to

$$x_n = \sum_{k=1}^{K} c_k z_k^n$$
 [3-2]

where  $x_n$  is the nth data point up to the final Nth point, K is the number of signal poles present in the signal (two poles for each exponentially damped sinusoid),  $c_k$  is the kth complex coefficient which includes the associated phase information, and the  $z_k$ s are the signal poles defined as

$$z_{L} = e^{\left[\left(-\frac{1}{T_{2}^{*}} + i\omega_{s}\right)\Delta f\right]}.$$
 [3-3]

Once the signal poles are found, the frequencies and relaxation times can be determined and then the coefficients are found by a fit to the data. For further details, see Barkhuijsen et al. [1987], Iselin [1992], or de Beer and van Ormondt [1992].

## Nonlinear Least Squares Curve Fitting

In nonlinear least squares, the goal is to find the values of the parameters which maximize the probability that the values of the fitted parameters are best. This is the Maximum Likelihood Method. Following de Beer and van Ormondt [1992], assume a model function  $\hat{x}_n$ , n=1,...,N (N data points) that exactly represents a noiseless real measurement  $x_n$ , n=1,...,N. Noise is added to the data  $x_n$  so that  $x_n$ .  $\hat{x}_n = \epsilon_n$ , where  $\epsilon_n$  equals the noise contribution to the nth data point. The distribution of the noise is given as Gaussian with  $\sigma_r$  as the noise standard deviation.

The joint probability function P for the entire measurement is the product of the individual probabilities for each data point and is given as

$$P(\epsilon) = P(x-\hat{x}) = \prod_{n=1}^{N} p_n(x_n - \hat{x}_n).$$
 [3-4]

When given a data set x and asked to determine x, the values of the model parameters, P(x-x) is called the likelihood function and the model parameters found are the Maximum Likelihood estimates. The log-likelihood function defined as

$$L(x-\hat{x}) = \ln[P(x-\hat{x})]$$
 [3-5]

is often used in place of the likelihood function because of its particular form in the case of Gaussian noise:

$$L(x-\hat{x}) = -N\ln[2\pi\sigma^2] - \frac{1}{2\sigma_r^2} \sum_{n=1}^{N} (x_n - \hat{x}_n)^2.$$
 [3-6]

Maximizing the log-likelihood function also maximizes the likelihood function. This is the basis for minimizing the sum squared error when curve fitting. The log-likelihood function merit function is usually reported as  $\chi^2$  and shortened to

$$\chi^2 = \frac{1}{\sigma^2} \sum_{n=1}^{N} (x_n - \hat{x}_n)^2.$$
 [3-7]

## Levenberg-Marquart Method

The Levenberg-Marquart method [Levenberg 1944, Marquart 1963, Davies and Whitting 1972, Press et al. 1989, Iselin 1992] is a hybrid of the method of steepest descent and Newton's method. Far (in relative terms) from the minimum, the method of steepest descent is used to target the minimum. As the minimum is approached, Newton's method is used. This is accomplished by introducing a varying factor into the Hessian matrix to weight the main diagonal. The parameter is raised to favor the method of steepest descent and then lower once the desired minimum is approached to use the faster convergence of Newton's method.

In practice, the Hessian matrix is usually approximated under Rao's (or Fisher's) "scoring" approximation [Rao 1973] which shortens the computation time while retaining good convergence characteristics [Maybeck 1979]. The Hessian matrix is replaced by the negative of the Fisher Information Matrix, also referred to by Rao and Maybeck as the conditional information matrix

$$\frac{\partial^2 L}{\partial \alpha^2} \approx -F = E \left\{ \frac{\partial^2 L}{\partial \alpha^2} \right\}$$
 [3-8]

where L is the log-likelihood function from Eq. [3-6] and  $E\{\cdot\}$  means take the expectation value (also see Eq. [3-9] below). The approximation being made is that the Hessian matrix for a particular data set can be adequately represented by an average over all of the data points. The modified Hessian matrix represented by the Fisher Information Matrix has no second derivative terms, only the product of first

derivative terms. The form and function of the Fisher Information Matrix will be addressed further in the discussion on errors in the fitted parameters.

In general, there is never a guarantee of finding the values of the unknowns which give the global minimum for the merit function. There is no way to determine if the minimum values found are global or local. The search space may be very uneven near the global minimum and the search method may not quite reach that point.

#### Errors in Fitted Parameters

Estimating the standard deviation of a fitted parameter can be difficult. The two main sources of error are the experimental error and the analysis error. The experimental error can be approximated by replicating all experiments several times under identical conditions and determining the variation in the parameter values. The analysis errors can be approximated by giving the Cramér-Rao Lower Bounds [Fréchet 1943, Darmois 1945, Rao 1945, Cramér 1946]. While a program is available for estimating Cramér-Rao Lower Bounds for HSVD, the most useful error analysis is of the errors in the final curve fitting using the Levenberg-Marquart method, since the nonlinear least squares curve fit is a Maximum Likelihood method. The nonlinear least squares curve fitting program used in this work automatically calculates the Cramér-Rao Lower Bounds of each fitted parameter.

Following Norton [1986] (and [de Beer and van Ormondt 1992]), the lower limit for the covariance matrix for the  $\alpha$  parameters, from 1 to J, used in  $\alpha$  can be

shown to be the inverse of the Fisher Information Matrix F:

$$F = E \left\{ \frac{\partial L}{\partial \alpha} \left( \frac{\partial L}{\partial \alpha} \right)^T \right\}$$
 [3-9]

where  $^{T}$  means take the transpose. It can be shown that the Fisher Information Matrix can be simplified to

$$F = -E \left\{ \frac{\partial^2}{\partial \alpha^2} L \right\} = -E \left\{ \frac{\partial^2 L}{\partial \alpha_k \partial \alpha_j} \right\}, \quad j,k=1,...,J.$$
 [3-10]

The partial derivatives of L with respect to the components  $\alpha_i$  and  $\alpha_k$  are as follows

$$\frac{\partial L}{\partial \alpha_j} = \frac{1}{\sigma_r^2} \sum_{i=1}^N (x_i - \hat{x}_i) \frac{\partial \hat{x}_i}{\partial \alpha_j}$$
 [3-11]

and

$$\frac{\partial^{2} L}{\partial \alpha_{k} \partial \alpha_{j}} = -\frac{1}{\sigma_{r}^{2}} \sum_{i=1}^{N} \left[ \frac{\partial \hat{x}_{i}}{\partial \alpha_{k}} \frac{\partial \hat{x}_{i}}{\partial \alpha_{j}} - (x_{i} - \hat{x}_{i}) \frac{\partial^{2} \hat{x}_{i}}{\partial \alpha_{k} \partial \alpha_{j}} \right].$$
 [3-12]

Note that the second derivative matrix given in Eq. [3-12] is the full Hessian matrix.

The negative sign in Eq. [3-12] is negated by the negative sign in Eq. [3-10] and the Fisher Information Matrix becomes

$$F = E \left\{ \frac{1}{\sigma_r^2} \sum_{i=1}^{N} \left[ \frac{\partial \hat{x}_i}{\partial \alpha_k} \frac{\partial \hat{x}_i}{\partial \alpha_j} - (x_i - \hat{x}_i) \frac{\partial^2 \hat{x}_i}{\partial \alpha_k \partial \alpha_j} \right] \right\}$$
 [3-13]

The expectation value of Eq. [3-13] removes all terms containing  $\epsilon_i$  and thus Eq. [3-13] becomes

$$F = \frac{1}{\sigma_r^2} \sum_{i=1}^{N} \left[ \frac{\partial \hat{x}_i}{\partial \alpha_k} \frac{\partial \hat{x}_i}{\partial \alpha_j} \right].$$
 [3-14]

This is the result that makes Rao's "scoring" approximation attractive. Once the Maximum Likelihood parameters have been found, the lower bounds on the errors of those parameters can be found by inverting the Fisher Information Matrix, according to the Cramér-Rao Inequality [Norton 1986]:

$$Cov(\alpha) \geq F^{-1}$$
. [3-15]

## Procedures

## Data File Manipulation

The spectra were transferred from the Nicolet to a Zenith<sup>16</sup> PC/AT model 325 microcomputer via Henry. This transfer requires that there be a configuration file in the root directory of the computer named 4094.CNF. The configuration file is created by 4094CFG.EXE, a file supplied with HENRY, which questions the user about the hardware setup. The Henry transfer program used is named 4094LTU.EXE. The transfer can either be to the directory containing 4094LTU.EXE

<sup>&</sup>lt;sup>16</sup> Zenith Data Systems Corporation, St. Joseph, MI 49085.

or another directory if the above executable file is in the path or is called by a batch file which is in the path. The file names were chosen in such a way to always be able to identify the location of the original spectrum on the Nicolet formatted data disks.

Before performing any data analysis, the PRN files are viewed in a graphing program such as Lotus 1-2-3°17 to determine how many initial points to remove to eliminate the detection response to the initial pulse. The data spectra always contain a square pulse which is the response to any input pulses. It was arbitrarily chosen to delete the initial points up to the first zero crossing of the FID signal. For a signal such as urea, this represents the loss of 4 to as many as 20 valid data points. Before running any of the data analysis programs, the data files must be converted into the proper format. FFT requires that the data are in time and voltage columns as in the OUT file format produced by CONVERT. CONVERT changes the PRN condensed format of eight columns of voltage data with time described by start time and time increment into two columns of time versus voltage. HSVD requires a binary format in blocks of 64 points. The PXLTA and CXLTA programs convert the PRN and OUT files, respectively, to a formatted form with blocks of 64 points in ASCII text. ASBIN reads this block formatted data to produce the HSVD-required binary formatted data blocks. The nonlinear curve fitting programs read in the data from the OUT formatted files. Examples of all computer programs are in Appendix A; examples of all file types are in Appendix B.

<sup>&</sup>lt;sup>17</sup> Lotus Development Corporation, Cambridge, MA 02142

## Use of Fourier Transform

When searching for an unreported transition, the PSD FFT is useful to help locate the peak and to differentiate real resonances from noise (If the peak shifts exactly in response to a frequency shift it is most probably a resonance and not noise.). With a simple FID, like that of urea, the PSD FFT is not always run on each data set unless a question arises that can best (or most quickly) be answered by viewing the frequency domain. When needed, the data sets are converted to the OUT file format by CONVERT, retaining every data point. The FFT program is then run on each data set producing the PSD FFT.

## HSVD Applied to Data

The HSVD program requires no starting guesses, so HSVD can be run after the data have been properly formatted by PXLTA and then converted to binary format by ASBIN. The HSVD inputs are the number of data points, the value of the Hankel parameter, L (here the number of data columns), and the number of singular values expected. The HSVD model associates two singular values with each resonance site. If the PSD FFT noise peak at low frequency is very large, there will be associated noise singular values which cannot be ignored. For urea, two singular values are usually enough unless dc noise (zero frequency) is present. If too many singular values are used, then HSVD will attempt to fit the peaks by overlapping Lorentzian peaks even if the data are not perfectly Lorentzian. An example of the actual output

file from HSVD, HSVSCR.PAR, is shown in Appendix A. Since linear algebra methods are not always Maximum Likelihood methods in the presence of noise, nonlinear curve fitting is necessary to find the Maximum Likelihood values of the NQR parameters.

## Nonlinear Curve Fitting of Data

The values returned for the resonance peaks by HSVD are excellent starting values for nonlinear least squares curve fitting programs. Since the stability of nonlinear curve fitting programs depends on the starting values being as correct as possible, these values are exactly what is needed. The PSD FFT results were used to approximate the frequency and amplitude values, but the lack of phase information often makes the analysis difficult if not impossible if there are multiple peaks. The final results of the data analysis are based on the Levenberg-Marquart results. All data analysis errors in the parameters are assumed to be the minimums given by Eq. [3-15] as no systematic errors were identified.

# CHAPTER 4

This chapter reports the results of the original extension to NQR analysis theory and all experiments and the analyses from fitting the data to the various models. The original data are FIDs of urea, urea-water, and urea-d<sub>4</sub>. Only the urea and urea-water were subjected to ionizing radiation. Irradiations were done at room temperature and 77 K with all NQR data taken at 77 K with the sample submerged in LN<sub>2</sub>. NQR experiments on urea-rock salt and urea-hydrogen peroxide which failed to detect a resonance site are also described. The sodium nitrite data used to test the method of linewidth analysis is from Petersen's doctoral work [1975, 1976].

#### Theoretical Results

#### NOR Linewidth Analysis

An expression used to describe the spin dynamics in experimental NMR can be applied to experimental NQR to yield information on the widths of electric field gradient (EFG) parameters. The width of the primary EFG component is usually assumed from the width of the resonance lines, although one previous NQR work used spin dynamics with the width of the EFG parameters assumed constant [Zussman 1973]. This assumption is not necessarily true.

In NMR, the inverse linewidth parameter  $T_2^*$  and the spin-spin relaxation time  $T_2$  are related through the inhomogeneity in the magnetic field  $(H_0)$  used to split the energy levels. The equation used to describe this relationship for a resonance line having a Lorentzian shape [Farrar and Becker 1971] can be written as

$$\frac{1}{T_2^*} = \frac{1}{T_2} + \frac{\gamma(\Delta H_0)}{2}$$
 [4-1]

(with  $\gamma$  as the gyromagnetic ratio), but has appeared in the literature in an approximate form with no constants, i.e.  $\gamma=2$ , for the general case [Fukushima and Roeder 1981]. The relationship for a resonance line having a Gaussian shape is

$$\frac{1}{T_2^*} = \frac{1}{T_2} + \frac{\gamma(\Delta H_0)}{4\sqrt{\ln 2}}.$$
 [4-2]

The Gaussian case will not be explicitly considered since it only differs from the Lorentzian case by a constant. In NQR, the energy level splitting is produced internally and no external magnetic fields are necessary; thus, the relationship between  $T_2^*$  and  $T_2$  for NQR is different than Eq. [4-1]. Since the last term in Eq. [4-1] is simply a measure of the spread of the angular frequency of the transition that is not due to the spin system dynamics, the equivalent equation for NQR would be

$$\frac{1}{T_2^*} = \frac{1}{T_2} + \frac{\Delta \omega_Q}{2}.$$
 [4-3]

Referring to Eq. [2-33], the angular frequency for an NQR transition  $\omega_Q$  is a function of the quadrupole moment eQ of the target nucleus, Planck's constant h, and the EFG parameters eq and  $\eta$ . Since these EFG parameters are the only parts of  $\omega_Q$  which are not constants, any width in  $\omega_Q$  not due to the spin system interactions must be a direct result of widths in the EFG parameters. The asymmetric splitting of the energy levels in NQR (with  $\eta \neq 0$ ), gives rise to multiple versions of Eq. [4-3], one for each observable transition.

For I=1, three variations of Eq. [4-3] are available for inspection, corresponding to the  $\omega_4$  difference line,

$$\frac{1}{T_2^*} = \frac{1}{T_2} + \frac{\pi e Q}{2h} \Delta [eq \eta], \qquad [4-4]$$

the  $\omega$  line,

$$\frac{1}{T_2^*} = \frac{1}{T_2} + \frac{\pi e Q}{4h} \Delta [eq(3-\eta)], \qquad [4-5]$$

and the  $\omega_{+}$  line.

$$\frac{1}{T_2^*} = \frac{1}{T_2} + \frac{\pi e Q}{4h} \Delta [eq(3+\eta)].$$
 [4-6]

Since the quadrupole energy tensor is symmetrical and traceless, there are only two degrees of freedom for the three versions of Eq. [4-3]. These two degrees of freedom are usually represented by eq and  $\eta$  or by  $\chi$  and  $\chi\eta$ . The equations for  $\omega$ , Eq. [4-5], and  $\omega_+$ , Eq. [4-6], are expected to yield identical results since they differ only by a sign change inside the term with an associated width. The validity of this implied requirement

$$\left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_{\Lambda} = \left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_{\Lambda}$$
 [4-7]

will be tested in the next chapter.

Rearranging Eq. [4-4] gives a directly measurable relationship for the width of the EFG function  $[V_x - V_y]$ , the numerator of  $\eta$ , as

$$\Delta[eq\eta] = \frac{2h}{\pi eQ} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)_d$$
 [4-8]

where the subscript denotes the line to which the time constants are associated,  $\omega_a$  in the case of Eq. [4-8]. Often the  $\omega_a$  line is at too low a frequency to be observed by traditional methods; however, advances in NQR detection methods and instrumentation have brought this relationship within the reach of experimenters through SQUID NQR [Conner 1990].

The other independent variable to be considered here is eq. Determining the width of this variable requires prior knowledge of the shape of the EFG distribution.

An upper limit on the width can be obtained by assuming the widths to be completely correlated so as to add arithmetically [Taylor 1982]

$$\Delta [eq]_{\max} \leq \frac{h}{3\pi eQ} \left[ 2 \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)_{\pm} - \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)_{d} \right]. \tag{4-9}$$

If the spreads in the EFG components are independent and uncorrelated, then the widths add in quadrature [Taylor 1982] and the result is

$$\Delta[eq] = \frac{2h}{3\pi eQ} \sqrt{4 \left(\frac{1}{T_2^*} - \frac{1}{T_2}\right)_4^2 - \left(\frac{1}{T_2^*} - \frac{1}{T_2}\right)_d^2}.$$
 [4-10]

For any case,  $\omega_Q$  can be separated experimentally into its two components: spin dynamic width and EFG component width, for any given substance and transition starting with Eq. [4-1] for a Lorentzian lineshape, Eq. [4-2] for a Gaussian lineshape or an analogous equation for other lineshapes. By experimentally measuring the  $T_2$  and  $T_2^*$  dynamic spin system time constants of NQR transitions, information on the widths of the EFG parameters can be determined. This method extends the traditional method of estimating the total width of eq (or  $\chi$ ) from the width of the resonance lines.

## NOR Linewidth Analysis Test for 14N

Since experimental values for  $T_2$  and  $T_2$ \* are unavailable for the  $\nu_4$  line for any  $^{14}N$  containing compound, the NQR linewidth analysis method previously proposed cannot be *fully* tested. The best available test is to use available data from the literature to determine if it is true that  $\nu_+$  and  $\nu_-$  give comparable results as described above. For this test, Petersen's data set on sodium nitrite was chosen. Values for  $T_2$  and  $T_2$  for the  $\nu_+$  and  $\nu_-$  lines were determined as a function of temperature from 77 K to over 400 K. The data were taken from Petersen's doctoral work in 1975 that was subsequently published in 1976. The data were originally presented on semi-log graphs of time constant vs. temperature. The data points presented here were

digitized from graphs sent by Petersen since the original data files were erased from computer storage in early 1992. Figures 4-1 through 4-4 are the original digitized data points on linear graphs. They are followed by smooth curves representing the data. The mean squared errors for the smooth curves given in Figs. 4-5 and 4-6 are 0.00827 for  $T_2$  and 0.151 for  $T_2$ \* of the  $\nu_+$  line and in Figs. 4-7 and 4-8 are 0.294 for  $T_2$  and 0.0199 for  $T_2$ \* of the  $\nu_-$  line, respectively. Note the difference in  $\nu_-$  axis scaling in each pair of figures; the first is linear and the second is logarithmic. The data could not be "fit" in a traditional fashion since there is no theoretical model to describe the data. The smooth curves simply reduce the scatter.

## Experimental Results

# Pulse Optimization

The initial experiment on the NQR spectrometry system is to set the pulse height and width for the substances to be probed. By trial and error it was determined that the maximum voltage that could be repeated almost indefinitely was around 1400 V to the coil or about 1.06 on the ten turn potentiometer on the amplifier. To provide a standard that would interact with as uniform a magnetic field as possible, samples of HMT and urea were made with paraffin filling the upper and lower one third of the sample vial. This eliminates any end effects but does not

 $<sup>^{\</sup>rm I}$  Personal Communication with Dr. Gary Petersen, RITEC, Inc., Warwick, RI 02886.

<sup>&</sup>lt;sup>2</sup> The data were originally presented by Petersen only on logarithmic graphs.




Figure 4-1 Petersen's data for the  $\nu_+$  line of sodium nitrite.




Figure 4-2 Petersen's data for the  $\nu_+$  line of sodium nitrite.




Figure 4-3 Petersen's data for the  $\nu_1$  line of sodium nitrite.




Figure 4-4 Petersen's data for the  $\nu$ , line of sodium nitrite.




Figure 4-5 Smoothed values of Petersen's data for  $T_2$  (upper line) and  $T_2$ \* (lower line) for the  $\nu_+$  line of sodium nitrite on a linear scale.




Figure 4-6 Smoothed values of Petersen's data for  $T_2$  (upper line) and  $T_2$ \* (lower line) for the  $\nu_+$  line of sodium nitrite on a logarithmic scale.




Figure 4-7 Smoothed values of Petersen's data for  $T_2$  (upper line) and  $T_2$ \* (lower line) for the  $\nu$ , line of sodium nitrite on a linear scale.




Figure 4-8 Smoothed values of Petersen's data for T<sub>2</sub> (upper line) and T<sub>2</sub>\* (lower line) for the  $\nu$ , line of sodium nitrite on a logarithmic scale.

change possible radial effects on the magnetic field. These pulse calibration standards were used in addition to a full vial of crushed urea. Using HMT at room temperature as an initial standard, the pulse width was varied and the height of the FID was measured with the frequency set exactly 10 kHz above resonance. Attempts to observe changes in the FID while on resonance were unsuccessful. For this purpose, the height of the FID was the average difference on voltage from the top of the first peak to the bottom of the first valley to the top of the second peak for each FID. The results for HMT are given in Fig. 4-9. This graph demonstrates that the FID amplitude does indeed change in a measurable way with pulse width. Switching to the urea standards at 77 K gave the results shown in the next three figures. The frequency was again set 10 kHz above resonance. Figure 4-10 was taken at a pulse height voltage of 1200 V and Fig. 4-11 was taken at 1400 V, both using the urea standard consisting of a full vial. Figure 4-12 was taken at 1360 V using the urea calibration standard. The error in each measurement in Figs. 4-9 through 4-12 is 10-15%. Based on these graphs, the decision was made to use 20 μs pulse widths to obtain urea FIDs. All efforts to record consistent data with pulses longer than 1.5 times the FID maximum failed. This eliminated the possibility of performing experiments which require more than a single pulse such as spin echoes for measuring T2.




Figure 4-9 HMT FID Amplitude at 1400 V and Room Temperature.




Figure 4-10 Urea FID Amplitude at 1200 V at 77 K.




Figure 4-11 Urea FID Amplitude at 1400 V at 77 K.




Figure 4-12 Urea FID Amplitude at 1360 V at 77 K.

## Pure Urea and Urea-d.

Of all available compounds containing nitrogen, urea is one of the most studied by  $^{14}N$  NQR, with HMT probably being the most studied. Not only has pure polycrystalline urea been studied [Chiba et al. 1959, Minematsu 1959, Guibé 1960, Widman 1963, O'Konskia and Torizuka 1969, Zussman 1973, Oja 1973, Higgins 1990, Hintenlang et al. 1992], but also urea complexes [Negita et al. 1977, 1981, Murgich and Santana R. 1981], substituted ureas [Smith and Cotts 1964, Dinesh and Rogers 1972, Sauer and Bray 1973, Chen and Dodgen 1976], and structurally related guanidine compounds [Oja 1969a, 1969b, 1973]. The  $\nu_+$  resonance of urea routinely detected previously (not shown) was observed at 2913.32  $\pm$  0.01 kHz and the  $\nu_-$  resonance shown in Fig. 4-13 was observed at 2347.88  $\pm$  0.08 kHz. These urea resonances were found at frequencies consistent with those previously reported. The  $T_2^*$  values for urea given in Table 4-1 agree reasonably well ( $\pm$ 25%) with those given by Zussman [1973] at 77 K.

Urea- $d_4$  has significance in that the substitution of deuterium (I=1) for light hydrogen ( $I=\frac{1}{2}$ ) in the amide groups raises the mass of the molecule leading to a difference in its NQR frequency temperature dependance. The center of the  $\nu_+$  resonance (2941.65  $\pm$  0.01 kHz) of urea- $d_4$  was found at a frequency consistent with previous reports [Widman 1963]. The  $\nu_-$  resonance of urea- $d_4$  was identified for the first time at 2381.46  $\pm$  0.04 kHz. The inverse linewidth parameters ( $\Gamma_2$ ) for the resonance lines are given in Table 4-1, along with the calculated  $\chi$  and  $\eta$ , and compared to urea.




Figure 4-13 FID of urea. Resonance shown is v..




Figure 4-14 FID of urea-d4. Resonance shown is v.

Table 4-1 Nuclear quadrupole coupling constants, asymmetry parameters, and inverse linewidth parameters for urea and urea-d<sub>4</sub>.

NQR Parameter	urea	urea-d <sub>4</sub>
х	3548.74 ± 0.03 kHz	$3507.47 \pm 0.06 \text{ kHz}$
η	0.32242 ± 0.00015	$0.31571 \pm 0.00007$
$\nu_+$ ${T_2}^*$	780 ± 20 μS	$928 \pm 23 \mu S$
ν. Τ <sub>2</sub> *	523 ± 24 μS	$721 \pm 12 \mu S$

Errors given are the propagated fitting errors.

Different samples may yield T2 values that differ by as much as 10%.

## Effect of Gamma Rays on Urea-Water

It has previously been reported by this laboratory that  $^{60}$ Co  $\gamma$ -ray irradiations on urea-water leads to a decrease in the inverse linewidth parameter with increasing radiation dose [Higgins 1990, Hintenlang and Higgins 1992, Hintenlang et al. 1992]. Based on the original data and original analyses, the exact relationship was shown to correspond to a linear increase in linewidth by Iselin and Hintenlang<sup>3</sup>. This relationship is shown in Fig. 4-15. Repeated attempts to replicate this effect have been unsuccessful. Figure 4-16 illustrates the results of these attempts; the error in each datum is  $\pm 7.5\%$  or 150 Hz.

<sup>&</sup>lt;sup>3</sup> The NQI Newsletter. 1(3):39; 1994. Published under the auspices of the International Symposium on Nuclear Quadrupole Interactions by R. A. Marino, Hunter College of CUNY, 695 Park Ave., New York, NY 10021.




Figure 4-15 Reported increase in the urea  $\nu_+$  linewidth after exposure to increasing amounts of  $^{60}$ Co  $\gamma$  rays.




Figure 4-16 Data from an attempt to replicate the reported <sup>60</sup>Co radiation effect on the urea-water  $\nu_+$  inverse linewidth parameter.

## Effect of Water on Urea

An experiment was carried out to determine if the changes reported by Higgins and later by Hintenlang could be attributed to the water added to the urea. Samples of urea were bottled as per Higgins with varying amounts of water to see if the amount of water caused a shift in T2\*. Each sample's mass was determined and the molar amount calculated for determining the proper amount of water for the desired molar ratio for each sample. The urea and water were heated in a microwave just until the point of boiling. The sample vial was immediately removed from the oven and capped. The sample was then shaken to insure complete dissolution of the urea in the water. The samples were placed on their sides on an insulated surface to cool slowly. The cooling method differed from the method that Higgins was observed using. Higgins removed samples from the microwave and then placed a wooden dowel in the center of the solution so that the samples would have a hollow core. In both cases, the void space in the sample vials was needed to assure that the vials did not burst upon thawing from 77 K. The results are shown in Fig. 4-17. The value of  $T_3$  drops from the baseline value of 780  $\mu$ s for pure urea to below 650  $\mu$ s. The smallest amount of water that could be added to a sample was 9 molar percent. Using less than this amount caused the sample to become heterogeneous in nature with a part of the sample remaining unchanged. Since the urea samples must be heated quickly to avoid the urea + water reaction, there is no time for mixing the samples during heating to spread the water molecules throughout the urea sample.




Figure 4-17 Effect of adding water to the  $\nu$ + line of urea. ( $\sigma = -45 \mu s$ )

#### Pulsed 14N NOR of Urea-H2O2 and Urea-Rock Salt

Since the  $^{14}N$  NQR spectrum of urea- $\mathrm{H}_2\mathrm{O}_2$  is known [Negita et al. 1977], and the structure is believed to be similar to urea-water due to the presence of hydrogen bonding in both "compounds", the decision was made to attempt to use urea- $\mathrm{H}_2\mathrm{O}_2$  for comparison. The literature on urea-hydrogen peroxide stated clearly that the material had to be stored below 35 °C or degradation would occur. At higher temperatures, the hydrogen peroxide is not contained in the urea matrix. Initial data runs were taken and analyzed. The  $\nu_+$  line was detected at 2922 kHz as published [Negita et al. 1977]. Careful and continued experimentation led to the discovery that the material was not as stable, even when kept refrigerated, as believed from reports in the literature. After finding that samples could not be stored for repeated analysis, further experiments with urea- $\mathrm{H}_2\mathrm{O}_2$  were dropped.

Early work in the literature on the use of NQR to study radiation effects involved <sup>35</sup>Cl containing compounds. The decision was made to attempt to use a <sup>35</sup>Cl-and <sup>14</sup>N containing compound to see if photon radiation effects could be observed. Being familiar with the <sup>14</sup>N NQR of urea compounds, urea-rock salt was chosen as a candidate material. The <sup>14</sup>N NQR frequencies have been reported by Negita et al. [1977] with resonance lines at 3592, 3599, 3596, and 3602 kHz. Although the method of preparation for urea-rock salt is given by Negita et al. [1977], two attempts to manufacture the complex were unsuccessful. The urea  $\nu_+$  resonance line was faintly observed at the extreme limits of detection, but no urea-rock salt transitions could be detected.

### CHAPTER 5 DISCUSSION

This chapter gives a discussion of the results of the original extension to NQR analysis theory and the various experiments and analyses that were carried out.

Several approximations to the NQR linewidth analysis method are given. From the testing of the method, the EFG widths for Petersen's sodium nitrite data are given. The pulse width calibration reveals the limitations of the NQR spectrometer, but the urea-d<sub>4</sub> v. line is still detected for the first time and characterized to show less electronic shifting upon deuteration than would be expected compared to other compounds. Townes and Dailey theory is used to analyze the results. Further EFG comparison is made to other urea compounds. The negative radiation effects study is analyzed by comparing the effect of adding water to urea and a further look at some of Higgins' original data.

## Theoretical Results

# **NOR Linewidth Analysis**

For <sup>14</sup>N NQR, measuring  $T_2$  for  $\nu_+$  and  $\nu_-$  or acquiring any information about the  $\nu_4$  line may be difficult or practically impossible. Several approximations to the

linewidth analysis method given here are readily assumable and each simplifies the amount of information needed experimentally.

The first is to assume that  $T_2 >> T_2^*$  for all transitions so that  $1/T_2$  can be neglected. For most  $^4N$  containing compounds, this is the case. In this case,

$$\Delta[eq\eta] \approx \frac{2h}{eQ} \left(\frac{1}{\pi T_2^*}\right)_d$$
 [5-1]

and

$$\Delta [eq]_{\max} < \frac{h}{3eQ} \left[ 2 \left( \frac{1}{\pi T_2^{\bullet}} \right)_{\underline{s}} - \left( \frac{1}{\pi T_2^{\bullet}} \right)_{\underline{s}} \right].$$
 [5-2]

The primary result of this approximation is that twice the linewidth of the  $v_d$  transition is proportional to the average width of  $V_{xx}$  and  $V_{yy}$ . Note that if the linewidths of all three transitions are similar in magnitude, then the width of eq is proportional to the linewidth and the width of  $\chi$  is approximately one third of the linewidth. The only drawback to this approximation is that although the absolute value of the width is given, the error in the values can be substantially increased if the assumptions are poor.

The second approximation involves relative values of the EFG widths and is given by assuming that  $T_2$  is relatively constant for all transitions under all experimental conditions. The main concerns in this case will be that temperature and pressure remain constant throughout. If, for example, a change in the EFG widths is

present before and after irradiation of the sample, then the differences  $\delta_{2-1}$  could be written as

$$\delta_{eq\eta} = \Delta_2[eq\eta] - \Delta_1[eq\eta] = \frac{2h}{eQ} \left[ \left( \frac{1}{\pi T_2^*} \right)_{d2} - \left( \frac{1}{\pi T_2^*} \right)_{d1} \right]$$
 [5-3]

and

$$\delta_{eq} = \frac{h}{3eQ} \left[ 2 \left( \frac{1}{\pi T_{2_2}^*} - \frac{1}{\pi T_{2_1}^*} \right) - \left( \frac{1}{\pi T_{2_2}^*} + \frac{1}{\pi T_{2_1}^*} \right)_d \right].$$
 [5-4]

The errors in this second case will depend solely on the measurement errors in determining the linewidths.

A third approximation, the one used in this work, is to assume that

$$\left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_* = \left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_- = \left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_d.$$
 [5-5]

Note that this applies to all three transitions and not just  $\nu_+$  and  $\nu_-$  as given by Eq. [4-7]. This assumption is reasonable if the EFG is isotropic. In this case, Eq. [4-8] simplifies to

$$\Delta[eq\eta] = \frac{2h}{\pi eQ} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)$$
 [5-6]

and leads to

$$\Delta[\chi \eta] = \frac{2}{\pi} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right),$$
 [5-7]

while Eq. [4-9] simplifies to

$$\Delta[eq]_{\max} \leq \frac{h}{3\pi eQ} \left(\frac{1}{T_2^*} - \frac{1}{T_2}\right)$$
 [5-8]

and leads to

$$\Delta[\chi]_{\max} < \approx \frac{1}{3\pi} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right).$$
 [5-9]

This approximation allows  $T_2^*$  and  $T_2$  data for a single transition to take the place of missing data from the other two transitions. In the case of a pure, homogeneous material, this may be an acceptable approximation. When inhomogeneities are introduced into the material, the error introduced may become unacceptable. Since there is no significant data on the  $\nu_d$  line for any  $^{14}N$  containing material, the errors introduced by this approximation cannot be tested at this time.

## NOR Linewidth Analysis Test for 14N

To get the Petersen data in the form necessary for testing the linewidth analysis method, the time constants must be inverted. The propagation of error in inversion, starting with an experimental value x with associated standard deviation  $\sigma_x$  is given by

$$y = \frac{1}{x}, \ \sigma_y = \frac{\sigma_x}{x^2} = \sigma_x y^2.$$
 [5-10]

The calculated values of the differences of the inverted time constants and the associated errors are given in tabular form in Appendix C. The data curves were expanded to 200 points, interpolated from the originals using cubic splines, and smoothed with a smoothing parameter of 0.25 using the Cleveland-Devlin [1988] algorithm for locally weighted regression. Figure 5-1 shows the final comparison of the  $\nu_{\star}$  line and the  $\nu_{\star}$  line before constants are scaled into the values.

Within the known error bars, there is no difference between the  $\nu_+$  and  $\nu_-$  lines for the differences of the inverted time constants, as tested. Thus, using the best available data, Eq. [4-5] and Eq. [4-6] give the same results as required by NQR linewidth analysis. This does not prove the validity of the method, only affirm that the data do not discredit it.

To provide a complete, thorough test of the NQR linewidth analysis method for  $^{14}N$  NQR, the values of  $T_2$  and  ${T_2}^*$  for all resonance lines, especially  $\nu_6$ , of several groups of related compounds would be required. To acquire this data, high- $T_c$  superconductors would be required to build SQUID NQR spectrometers that run at temperatures of 77 K or higher. At lower temperatures, the relaxation times increase exponentially.

## EFG Widths for Sodium Nitrite

Using the experimental values for T<sub>2</sub> and T<sub>2</sub>\* from Petersen and the assumption that the three transition lines will all have the same inhomogeneity characteristics, the




Figure 5-1 Difference of the inverted time constants for sodium nitrite. The broken lines represent the data for  $\nu_+$ .

EFG width given as  $\Delta[\chi]$  or  $\Delta[eq]$  can be calculated. Since the experimental errors are smaller for the  $\nu$ , line, that data set will be used in the calculation of Eq. [2-81]. The result is shown in Fig. 5-2. The value<sup>1</sup> of the quadrupole moment for <sup>14</sup>N, used in the right-hand y axis in Fig. 5-2 is  $1.6 \times 10^{-26}$  cm<sup>2</sup>. Values for  $\Delta[\chi\eta]$  are not calculated as they would be proportional to  $\Delta[\chi]$ , a result of the assumption that all three resonance lines have equal inhomogeneity as defined as the difference of the inverted time constants.

#### Experimental Results

#### Pulse Optimization

Optimizing the pulse width for a given pulse height was more difficult than expected. Having previously run the NQR spectrometer at a "usable" setting without regard to maximizing the signal, the author was surprised to discover the large amount of drift and poor repeatability with the experimental setup, despite the known correlation of small changes in FID amplitude with changes in pulse width near the FID maximum response. Attempts to use two pulses with a variable separation to measure changes in the echo height were unsuccessful. The echo height appeared to decrease and then leveled off before disappearing completely. As the second pulse must be wider then the first, the NQR spectrometer continually drifted such that the errors voided any attempt to measure T<sub>2</sub>.

<sup>&</sup>lt;sup>1</sup> Bruker NMR NQR Periodic Table, Bruker Instruments, Inc., Manning Park, Billerica, MA 01812.




Figure 5-2 The widths of the NQCC (left y-axis, solid line) and the primary EFG component,  $V_{zz}$ , (right y-axis, broken line) for the  $\nu_+$  and  $\nu_-$  lines of sodium nitrite.

The bonding structure of urea is known to be a prime example of  $sp^2$  hybridization. Under Townes and Dailey theory, the NQR parameters are related to the bonding parameters by Eqns. [2-55] and [2-56]. Following the work and notation of Negita et al. [1981] (probably after Oja [1973]), where only the differences between urea and urea- $d_4$  are important, we will assume that  $\sigma_{NC}$  is constant, since the N-C bond less likely to become polarized than the N-H bond due to the difference in electronegativity between C and H, and write [Negita et al., Eqn. 6]

$$\Delta \alpha = \Delta \pi - \frac{2}{3} \Delta \sigma_{NH}$$
 [5-11]

$$\Delta(\alpha \eta) = \Delta \sigma_{NH}$$
. [5-12]

This analysis gives the following values when combined with the experimental results:

$$\chi_{2} \Delta \pi = -34.27 \pm 0.13$$
 [5-13]

$$\chi_{2p} \Delta \sigma_{NH} = 10.50 \pm 0.18$$
. [5-14]


The exact value for  $\chi_{2}$  is not known but its range is known to be from 8 to 14 MHz [Marino 1968]. The exact value used is not very important considering the magnitude of the experimental errors, so we will use  $\chi_{2} = 10$  MHz to yield the final results of

$$\Delta \pi = -0.004$$
  $\Delta \sigma_{yyy} = 0.001$ . [5-15]

The experimental values for the nuclear quadrupole coupling constant and the asymmetry parameter of  $^{14}N$  in urea- $d_4$  differ from urea by +1% and -2%, respectively. Townes and Dailey theory reveals that urea- $d_4$  has a 0.2% increase in the lone pair electronic density and an almost negligible decrease in the N-H  $\sigma$  bond density. These small differences between urea and urea- $d_4$  are believed to be due to the increase in mass upon deuteration. The differences between urea and urea- $d_4$  are similar to that between urea-NaCl-H<sub>2</sub>O and urea-NaBr-H<sub>2</sub>O and are greater than the differences between the two sites in thiourea or the change from ethylurea to methylurea.

To relate these results to other deuterated compounds, the work of Hunt and Mackay [1974] will be used as a reference. They found that derivatives of formamide, using sp hybrid orbitals, show on average a decrease of 0.004 electrons in the  $\sigma_{\rm NH}$  orbitals for each 25 kHz increase in  $\chi$  upon deuteration. Using sp or  $sp^2$  bonding for urea gives similar results and suggests that for  $^{14}N$  in symmetric molecules, less shifting of electrons is necessary for large changes in the nuclear quadrupole coupling constant. The shift of 41 kHz for urea- $d_4$  only resulted in a shift 0.001 electrons in the  $\sigma_{\rm NH}$  orbitals as opposed to an expected 0.007 according to Hunt and Mackay. Even accounting for four N-H bonds instead of two, the electronic shift is smaller than predicted.

For comparison with other compounds with the same basic structure as urea, a plot of  $\chi\eta$  versus  $\chi$  is shown in Fig. 5-3. This choice of axes allows the graphical space to be uniform with the same units in both directions. Higher values of  $\chi\eta$ 



Moving from left to right, the diamonds (♠) are the two sites of thiourea [Smith and Cotts 1964, Jamil 1992], the triangles (♠) are urea nitrate, urea phosphate, urea oxalate [Murgich and Santana R. 1981], urea-hydrogen peroxide [Negita et al. 1977], urea-NH₄Cl [Murgich and Santana R. 1981], urea-rock salt, and urea-NaBr-H₂O [Negita et al. 1977], the squares (■) are hydroxyurea [Sauer and Bray 1973], ethylurea [Chen and Dodgen 1976] and methylurea [Dinesh and Rogers 1972], and the circles (♠) represent urea and urea-d₄.

Figure 5-3 EFG-Space Diagram of urea and related compounds.

correspond to more polarization of the nitrogen bonds; higher values of  $\chi$  correspond to more  $\tau$  bond character. The substitution of  $^2H$  for  $^1H$  in urea causes a change equivalent to the difference between urea-NaCl-H<sub>2</sub>O and urea-NaBr-H<sub>2</sub>O, but with less change in nitrogen bond polarization, and is greater than the differences between the two sites in thiourea or the change from ethylurea to methylurea.

The error bars for the positions of urea nitrate, urea phosphate, urea oxalate, and urea-NH<sub>4</sub>Cl are given to remind the reader that the exact parings of the  $\nu_+$  and  $\nu_-$  lines for these compounds is not known and that the position given on the graph is only the average position for these compounds. The possibilities are on opposing sides near the ends of the error bars for the first three compounds. There are six known lines for urea-NH<sub>4</sub>Cl and thus three sets of pairs that would all fall within the limits of the error bars given.

# Effect of Gamma Rays on Urea-Water

A decrease in  $T_2^*$  to a constant value [C.I. >95%] of 550  $\mu$ s from 780  $\mu$ s was measured. The spread in the data around the 550  $\mu$ s central value is slightly larger than attributable to the measurement and analysis error attributed to each individual measurement. This suggests a source of change in the measured values other than the irradiation. Despite previous reports from this laboratory [Higgins 1990, Hintenlang and Higgins 1992, Hintenlang et al. 1992],  $^{60}$ Co irradiation of urea-water was not shown to cause a linear or exponential increase in the NQR linewidth even when the absorbed dose was extended from 300 to 900 Gy.

### Review of Higgin's Original Data

Since verification of the previously reported work in this laboratory was not obtained, the laboratory records were searched for the original data sets taken on urea-water by Higgins [1990]. Five data runs from that work were identified.

Details of this data are given in Appendix D. The comparison of the original analysis with the analysis obtained using the techniques cited in this work is shown in Fig. 5-4.

The use of nonlinear curve fitting gives drastically different results than just fitting the peaks of the FID to an exponential curve (or the logarithm of those values to a straight line) as was done by Higgins. The errors obtained after nonlinear curve fitting demonstrate that the errors originally reported for these points are underestimated. The reanalysis does not support the conclusion that  $^{60}$ Co  $\gamma$  rays cause a measurable variable decrease in the  $T_2$  of urea-water. The original data that were published by Hintenlang and Higgins in 1992 were not available for review. It is believed that the curve given by these authors was coincidental with the same underestimation of errors that plagued Higgins' original work.

<sup>&</sup>lt;sup>2</sup> The data published by Hintenlang and Higgins in 1992 is believed to be different than the data given by Higgins in 1991 since Higgins reported a linear response and Hintenlang and Higgins reported an exponential response.




Figure 5-4 Reanalysis of Higgins' data on radiation effects on urea: water.

#### Effect of Water on Urea

Both Higgins [1990] and Hintenlang and Higgins [1992] reported that recrystallizing water into the urea crystalline structure did not cause a change in T2\* when compared to dry, polycrystalline urea. In both previously reported cases, the datum for urea and the urea-water standard have T2\* values around 800 µs. This result is not supported in this work. All standard samples (N=21) which were recrystallized with water added to pure urea had T2\* values below 650 µs with one as low as 380 us. As is shown in Fig. 4-17, the amount of water added as measured as a molar ratio, moles of water to moles of urea, always led to a decrease in T2\*. The wide variations in the data in Fig. 4-17 are simply experimental scatter. Although there may appear to the eye to be a downward trend in the data given in Fig. 4-17, it is indistinguishable from a line with slope m=0 above a 95% confidence interval. The majority of data were taken around a molar ratio of 1.0 as this is the region which the previous researchers had used. The extreme value of 0.09 represents the lower limit of the amount of water that could be added. At and below this point, the water would boil away before the urea could dissolve in the water to be recrystallized. The upper limit of 1.3 represents the point where water would be left unincorporated after the urea recrystallized.

The process of adding water to polycrystalline urea results in the widening of the linewidth and therefore a shrinking of  $T_2^*$  down to the region of 550  $\mu$ s. It is therefore the addition of water to the urea and the associated changes in the internal crystalline structure of the urea that is responsible for the "radiation effect" previously

measured. If chemical impurities, water in this case, are added to a crystal, the disruptions of the lattice lead to EFG changes that are propagated several crystalline units from the disruption site in spite of the r<sup>3</sup> dependance. These disruptions shift the distribution of EFGs, leading to line broadening and a lowering of the central amplitude of a peak.

## Pulsed 14N NOR of Urea-H2O2 and Urea-Rock Salt

Due to their similar crystalline structure, urea-H<sub>2</sub>O<sub>2</sub> is a logical choice for comparison to urea-water. The structure of urea-H<sub>2</sub>O<sub>2</sub> is known to have the hydrogen peroxide hydrogen bonded between the oxygen of one urea and the hydrogens of the next. The base urea structure of urea-H<sub>2</sub>O<sub>2</sub> is almost exactly the same as pure urea [Lu et al. 1941, Fritchie and McMullan 1981]. Had the radiation effects on the NQR spectra of urea-water previously described been seen, the radiation effect on urea-H<sub>2</sub>O<sub>2</sub> could have been key to understanding the effect on urea-water.

Pulsed NQR experiments require longer  $T_2$  values than CW experiments with the worst case for pulsed NQR being a compound with short  $T_2$  and long  $T_1$ . The original paper on urea-rock salt by Negita et al. (1977) utilized a CW apparatus. No time constants for urea-rock salt have ever been reported, but they are probably be too short to allow for detection by pulsed NQR methods.

# CHAPTER 6

If radiation protection practice is to become biologically based instead of energy deposition based, then the radiation effects of radiations of different qualities must be measured directly on biological materials. One of the simplest organic compounds found in the human body with a strong <sup>14</sup>N NQR signal is urea. Urea is also known to form a variety of compounds and complexes, such as urea-hydrogen peroxide and urea-rock salt, giving a range of similar materials for study. To tie the results to radiation biology work, the presence of water, the universal solvent, is believed to be necessary. Ionizing photons are used as the radiation source for this radiation effects study.

The following specific objectives were considered.

Propose and test a method for quantifying changes in NQR signals.
 The proposed NQR linewidth analysis method uses the NQR relaxation times to calculate the natural widths of the EFG parameters exclusive of the effects of the spin dynamics. The use of this technique were successfully demonstrated using Petersen's <sup>14</sup>N NQR data of changes in the relaxation times of sodium nitrite as a function of temperature.

Demonstrate the validity of NQR measurements taken on the Ritec spectrometer system by detecting and quantifying one or more unreported resonances as well as resonances previously described in the literature.

The Ritec NQR spectrometer was calibrated for <sup>14</sup>N NQR using standard samples of HMT and urea. The previously unreported  $\nu$ , line of urea- $d_4$  was identified at 2381.46 kHz allowing the determination of  $\gamma$  and  $\eta$  for urea- $d_4$  for the first time.

3) Follow up the work of Higgins and Hintenlang by replicating their measurements of the <sup>14</sup>N NQR spin-spin relaxation times for urea-water and extending the range of <sup>60</sup>Co gamma ray absorbed doses above 300 Gy.

In the range of 0-900 Gy, there were no measurable changes observed in the relaxation times of urea-water that could be attributed to exposure to ionizing photons. The works of the previous researchers was not replicated and is not supported.

4) Compare and correlate changes in the NQR experimentally derived quantities of urea-water to gamma ray dose to quantify the broadening of the electric field gradient at the nitrogen sites.

It was determined that the inverse linewidth parameter of urea-water differs from dry, polycrystalline urea with values of 550  $\mu$ s and 780  $\mu$ s, respectively. These results were observed for urea-water with composition ranging from 0.1 to 1.3 molar ratio of water to urea.

5) Make recommendations for further study in this area.

Nuclear quadrupole resonance of <sup>14</sup>N nuclei is not currently useful as a radiation effects probe of organic solid solutions. No further experiments are recommended until such time as the theoretical basis for NQR has reached the point of providing adequate justification that the desired radiation effect will be observable.

In addition to the previous listing of objectives and conclusions, the following summarizes other important contributions of this work. An expression used to describe the spin dynamics in experimental NMR was applied to experimental NQR to yield quantitative information on the widths of the EFG parameters. For a Lorentzian lineshape the "NQR linewidth analysis" method yields the following relationships between the NQR EFG parameter widths and  $T_2$  and  $T_2$ .

$$\Delta[eq\eta] = \frac{2h}{\pi eQ} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)_d$$
 [4-8]

and

$$\Delta [eq]_{\max} \leq \frac{h}{3\pi eQ} \left[ 2 \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)_{\pm} - \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)_{d} \right]. \tag{4-9}$$

As can be inferred from Eq. [4-9] there is an internal consistency requirement for

$$\left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_{+} = \left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_{-}.$$
 [4-7]

By experimentally measuring the  $T_2$  and  $T_2$  dynamic spin system time constants of NQR transitions, information on the widths of the EFG parameters can be determined. This method extends the traditional NQR method of estimating the total width of eq (or x) from the width of the resonance lines.

Note that all equations in this chapter are numbered as originally given to provide a reference back to the discussion where the equations were first used.

As a test of this new analysis method, a very complete data set, Petersen's data set on sodium nitrite, was chosen. Values for  $T_2$  and  $T_2^*$  for the  $\nu_+$  and  $\nu_-$  lines were determined by Petersen as a function of temperature from 77 K to over 400 K. Since experimental values for  $T_2$  and  $T_2^*$  are unavailable for the  $\nu_d$  line for any  $^{14}N$  containing compound, several approximations the NQR linewidth analysis method were explored. The assumptions for each approximation were 1) that  $T_2 >> T_2^*$  for all transitions so that  $1/T_2$  can be neglected, 2) that  $T_2$  is relatively constant for all transitions under all experimental conditions, and 3) that the following extension to Eq. [4-7] is true:

$$\left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_* = \left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_- = \left[\frac{1}{T_2^*} - \frac{1}{T_2}\right]_d.$$
 [5-5]

Since the only assumption which eliminated the need for experimental values for  $\nu_d$  is the last one, that simplification was adopted and applied to Petersen's sodium nitrite data. Under this assumption, Eq. [4-8] transforms into

$$\Delta[\chi\eta] = \frac{2}{\pi} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right)$$
 [5-7]

and Eq. [4-9] into

$$\Delta[\chi]_{\max} \le \frac{1}{3\pi} \left( \frac{1}{T_2^*} - \frac{1}{T_2} \right).$$
 [5-9]

Note that this assumption leads to the result that the widths of the NQR EFG components are all proportional.

Petersen's sodium nitrite data provide support for Eq. [4-7] and the internal consistency requirement that  $\nu_+$  and  $\nu_-$  yield the same results. The final results of applying the approximated NQR linewidth analysis method yields values for  $\Delta[\chi]$  in the range of 100 Hz to 950 Hz. The lowest value for  $\Delta[\chi]$  occurs just above 300 K and the highest occurs at an internal phase transition near 420 K.

Using standard samples of HMT and urea, the performance of the RITEC NOR spectrometer in the Department of Nuclear Engineering Sciences at the University of Florida was analyzed and the spectrometer was calibrated for 14N NOR work. The proper pulse height and pulse width for urea and related compounds were experimentally determined for single pulse experiments to be  $\sim 20 \mu s$  at  $\sim 1400 \text{ V}$ , but the equipment was determined to be too unstable when using wider pulses or pulse separation values or more than 1 ms to adequately determine T2 values by use of multi-pulse sequences such as the 180°-τ-90° inversion-recovery method. As a test of the calibration for single pulse experiments, the previously unreported  $\nu$  line for urea-d<sub>4</sub> was detected at 2381 ± 0.04 kHz and used to determine accurately the values for  $\chi$  (=3548.74  $\pm$  0.03 kHz) and  $\eta$  (=0.31571  $\pm$  0.00007) for urea- $d_4$  along with the associated  $T_2$ ° values for  $\nu_+$  (=928 ± 23  $\mu$ s) and  $\nu_-$  (=721 ± 12  $\mu$ s). In terms of Townes and Dailey theory, urea-d4 has a 0.004 increase in the lone pair electronic density and a slight decrease in the N-H bond electronic density. The differences are smaller than were predicted by the correlations of Hunt and Mackay [1974]. To

further explore the differences between the various urea-based substances, an EFG graph [Fig. 5-3] was made and the locations of thirteen compounds were placed. It was determined that the substitution of <sup>2</sup>H for <sup>1</sup>H in urea causes a change equivalent to changing the Cl in urea-NaCl-H<sub>2</sub>O to Br to form urea-NaBr-H<sub>2</sub>O and is greater than the differences between the two sites in thiourea or the change from ethylurea to methylurea.

Urea recrystallized in the presence of water has a decrease in  $T_2^*$  that is found to be relatively constant regardless of exposure to  $^{60}$ Co  $\gamma$  rays up to an absorbed dose of 900 Gy, twice the range in exposure reported previously. It is believed that the previously reported data were misinterpreted due to a low signal-to-noise ratio and a simplistic data analysis method prone to larger errors than were expected by the previous researchers. The conclusion of the radiation effects studies on urea-water by Higgins and Hintenlang and Higgins was not supported as their work could not be replicated.

Cobalt-60 irradiation of urea-water was not observed to lead to any change in the NQR linewidth for an absorbed dose in the range from 0 to 900 Gy. Since verification of the previously reported work in this laboratory was not obtained, the laboratory records were searched for the original data sets taken on urea-water by Higgins [1990]. The comparison of the original analysis with the analysis obtained using the techniques cited in this work shows that nonlinear curve fitting gives dramatically different results than just fitting the peaks of the FID to an exponential curve (or the logarithm of those values to a straight line) as was done by Higgins.

The errors obtained after nonlinear curve fitting demonstrate that the errors originally reported for these points were underestimated. Despite previous reports from this laboratory, <sup>60</sup>Co irradiation of urea-water was not shown to cause a linear or exponential increase in the NQR linewidth for an absorbed dose in the range from 0 to 900 Gy.

All standard samples of urea (N=21) which were recrystallized with water were measured with  $T_2^*$  values around 550  $\mu$ s with all below 650  $\mu$ s and one as low as 380  $\mu$ s. As shown in Fig. 4-17, any amount of water added, measured as a molar ratio of moles of water to moles of urea, always led to a decrease in  $T_2^*$  as compared to dry, polycrystalline urea. Both Higgins [1990] and Hintenlang and Higgins [1992] reported that recrystallizing water into the urea crystalline structure did not cause a decrease in  $T_2^*$  when compared to dry, polycrystalline urea. In both previously reported cases, the datum for urea and the urea-water standard have  $T_2^*$  values around 800  $\mu$ s. This result was not supported in this work.

The process of adding water to polycrystalline urea results in the widening of the linewidth and therefore a shrinking of  $T_2$ \* down to the region of 550  $\mu$ s. It is therefore the addition of water to the urea and the associated changes in the internal crystalline structure of the urea that is responsible for the "radiation effect" previously measured.

The primary conclusion of this work is that <sup>14</sup>N NQR is still Not Quite Ready for high precision work in radiation effects as a probe of solid solutions. The experimental apparatus was state-of-the-art at the time it was purchased. It is not capable of taking high enough accuracy data for radiation effects study attempted here. While multipulse experiments are becoming common in NMR, the NQR community is behind in both experimental and theoretical developments. This is probably due to the large amount of research funding available for medical imaging. Also, the high sensitivity of NQR experiments to the preparation and handling of the samples prevents highly accurate comparisons between samples. The continuing work into the fundamental theory of NQR pulses and radiofrequency interactions with matter by such researchers as Sanctuary and Krishnan may modify this conclusion in the future.

For NQR to be used as an effective radiation effects tools for exploring the effects of photons, the following items would need to be developed or found: more precise equipment for the measurement of NQR parameters with pulse width stability of <3% and pulse separation stability of <3% for separations of tens of thousands of pulse widths, multiple pulse sequences which isolate particular attributes of the system, a better understanding of the fundamental interactions of pulses and the spin system in organic systems, and an organic material which demonstrates changes in its bonding configuration after exposure to small amounts of photonic ionizing radiation. The best type of system would be a binary, well mixed mixture which reacted upon exposure. The two largest limitations on NQR for radiation effects studies are the long  $T_1$  and  $T_2$  time constants for most biologically active organics and NQR's sensitivity to small changes in pressure and temperature.

# APPENDIX A FORTRAN PROGRAMS

The following computer programs were written in FORTRAN to aid in manipulating and analyzing the NQR data. Each was compiled on a Zenith personal computer with Intel® 386iTM/387iTM processors with Microsoft® FORTRAN version 5.1

### CONVERT

This program takes the PRN datafile that was imported from the Nicolet and converts it into an OUT file of time versus voltage. An example of the PRN and OUT files are in Appendix B. The required inputs are the input PRN filename, the output OUT filename, the size of the data spectrum, the number of initial points to be deleted, and the increment at which to discard the data points.

```
C PROGRAM TAXES THE OUTPUT .prn FILE FROM THE NICOLET AND CONVERTS C THE NICOLET FORMAT TO A USER-NAMED DATAFILE OF TIME VERSUS VOLTAGE C WRITTEN BY Louis H Iselin C VERSION 3.20 OF 13 JAN 91 C C C THE FOLLOWING IS THE DESCRIPTION OF THE VARIABLES USED:
```

<sup>&</sup>lt;sup>1</sup> Intel Corporation, 2200 Mission College Blvd., Santa Clara, CA 95052-8119.

<sup>&</sup>lt;sup>2</sup> Microsoft Corporation, Redmond, WA 98052-6399,

```
- THE NICOLET INPUT FILE NAME
  NIC
c
  OUT
              =
                 THE OUTPUT FILE NAME
  ERRMSG
             THE STANDARD ERROR MESSAGE
                 THE ERROR NUMBER FOR ERRORS READING INPUT FILE - NIC
  TC1
                 THE ERROR NUMBER FOR ERRORS READING OUTPUT FILE - OUT
  IC2
             THE INTEGER WHICH DETERMINES THE INPUT FILE
  SIZE
             SIZE, (1) FULL-(2) HALF-(4) QUARTER
ċ
           THE NUMBER OF COLUMNS OF DATA POINTS
c
           THE NUMBER OF COLUMNS OF DATA POINTS IN USE
C
  n
           THE NUMBER OF ROWS OF DATA
ċ
  R
           THE NUMBER OF ROWS OF DATA IN USE
c
             THE NUMBER OF INITIAL DATA POINTS TO DELETE FROM
c
  DELPTS
C
            THE OUTPUT FILE - OUT
c
  X(D,S)
             THE VOLTAGE DATA POINTS FROM THE INPUT FILE
             THE NUMBER OF DATA POINTS TO SKIP AFTER EACH RETAINED
c
  SKIP
č
               POINT
             THE TIME BETWEEN EACH DATA POINT
ċ
  DELTA
             THE TIME THE FIRST DATA POINT WAS TAKEN WITH RESPECT TO
c
  START
ċ
                 THE TRIGGER OF THE NICOLET
c
  MAX
             THE MAXIMUM NUMBER OF DATA POINTS
             THE INITIAL COLUMN OF DATA
CCC
   IS
   JS.JC
             THE INITIAL ROW OF DATA
                JS = STATIC. JC = CHANGES
č
   VARIABLE DECLARATIONS AND INITIATIONS
      CHARACTER NIC*36, OUT*36, ERRMSG*41
      INTEGER
               IC1, IC2, C, R, S, MAX, NUM
                DELPTS, SKIP, IS, JS, JC, SIZE
      INTEGER
                DELTA, START
      DIMENSION X(8,2048)
      DATA ERRMSG / ** INVALID RESPONSE - PLEASE TRY AGAIN ***/
      DATA IC1 /0/, IC2 /0/, C /8/, R /1536/, S /2048/
      DATA MAX /15872/, NUM /0/
      DATA X /16384*-99999./
C
c
    MAIN PROGRAM STARTS
c
    ASK FOR AND OPEN THE NICOLET INPUT "PRN" DATA FILE
C
      PRINT*, '*
                       CONVERT
      PRINT*,'*
                 WRITTEN BY Louis H Iselin
                                             + 1
      PRINT*, '* VERSION 3.10 OF 22 DEC 90 *'
      PRINT*,' '
      PRINT*, ' Welcome to the CONVERT program to CONVERT'
      PRINT*,'
                  the Nicolet prn datafile to a datafile'
      PRINT*,'
                    of time vs. voltage'
      PRINT*,' '
      PRINT*,' What is the Nicolet INPUT file name?'
 10
      PRINT*,
                       (include path if necessary)'
      PRINT*,'
      READ(*,'(A)') NIC
      OPEN (UNIT=1, FILE=NIC, STATUS='OLD', IOSTAT=IC1)
      IF (IC1.NE.O) THEN
       PRINT*, ERRMSG
PRINT*, Error ',IC1,' has occurred.'
       GOTO 10
      ENDIF
      PRINT*,' '
C
```

```
ASK THE SIZE OF THE NICOLET DATA FILE USED AS INPUT
C
      PRINT*,' Please give the size of the data spectrum.'
      PRINT*, 'MAX POINTS - 15872
                                                        3968
                                         7936
                                        (2) Half
                                                     (4) Quarter'
      PRINT*,'
                           (1)Full
      PRINT*,'
      READ(*,*) SIZE
    QUARTER SIZED INPUT FILE PARAMETERS
C
      IF (SIZE.GT.2) THEN
       C=2
       R=1920
       MAX=3968
С
С
    HALF SIZED INPUT FILE PARAMETERS
       ELSEIF (SIZE.EO.2) THEN
            C=4
            R=1792
            MAX=7936
      ENDIE
c
    ASK FOR AND OPEN THE OUTPUT FILE
      PRINT*,' '
      PRINT*,' What is the desired OUTPUT datafile name?'
 20
      PRINT*,'
                         (include path if necessary)'
      PRINT*,' '
      READ (*, '(A)') OUT
      OPEN (UNIT=2, FILE=OUT, STATUS='NEW', IOSTAT=IC2)
      IF (IC2.NE.O) THEN
       PRINT*, ERRMSG
       PRINT*, ' Error ', IC2, ' has occurred.'
       GOTO 20
      ENDIF
      PRINT*.' '
c
    ASK FOR THE NUBER OF INITIAL DATA POINTS TO STRIP FROM THE SPECTRUM
c
c
      PRINT*, ' How many initial points do you wish to delete?'
 30
      READ(*,*) DELPTS
      IF ((DELPTS.LT.0).OR.(DELPTS.GE.MAX)) THEN
       PRINT*, ERRMSG
       GOTO 30
      ENDIF
С
    CALCULATE INITIAL COLUMN AND ROW PARAMETERS
С
      IF (DELPTS.GT.2047) THEN
       IS = (DELPTS / 2048) + 1
JS = MOD (DELPTS , 2048) + 1
      ELSE
       IS = 1
       JS = DELPTS + 1
      ENDIF
      JC = JS
   ASK FOR THE NUMBER OF DATA POINTS TO SKIP AFTER EACH RETAINED POINT
c
 40
      PRINT*, ' PLEASE GIVE THE DESIRED SAMPLING INTERVAL.'
      PRINT*, ' How many data points should be skipped'
```

```
PRINT*,'
                   after each retained data point?'
      PRINT*,'
      READ(*,*) SKIP
      IF ((SKIP.LT.0).OR.(SKIP.GE.MAX)) THEN
       PRINT*, ERRMSG
       GOTO 40
      ENDIF
c
    READ INPUT FILE
c
ċ
ċ
    READ FIRST 2 LINES
c
      DO 50, J=1,2
       IF (C.EQ.8) READ (1,601) (X(I,J), I=1,C)
       IF (C.EQ.4) READ (1,602) (X(I,J), I=1,C)
       IF (C.EQ.2) READ (1,604) (X(I,J), I=1,C)
      CONTINUE
 50
 601
     FORMAT (14X, 8(1X,G8.6))
      FORMAT (14X, 4(1X,G8.6))
 602
 604
      FORMAT (14X, 2(1X,G8.6))
C
    READ NEXT 2 LINES, INCLUDING START AND DELTA
c
č
      READ
              (1,*) START, (X(I,3), I=1,C)
      READ
              (1,*) DELTA, (X(I,4), I=1,C)
c
č
    READ NEXT 3 DATA LINES
c
      DO 51, J=5,7
       IF (C.EO.8) READ (1,601) (X(I,J), I=1,C)
           (C.EQ.4) READ (1,602) (X(I,J), I=1,C)
       IF (C.EQ.2) READ (1,604) (X(I,J), I=1,C)
 51
      CONTINUE
c
    READ THE REMAINING DATA LINES WITH FULL COLUMNS OF DATA
C
c
      DO 52, J=8,R
       IF (C.EQ.8) READ (1,611) (X(I,J), I=1,C)
       IF (C.EQ.4) READ (1,612) (X(I,J), I=1,C)
       IF (C.EQ.2) READ (1,614) (X(I,J), I=1,C)
 52
      CONTINUE
       FORMAT (2X, 8(1X, G8.6))
FORMAT (2X, 4(1X, G8.6))
FORMAT (2X, 2(1X, G8.6))
 611
 612
 614
C
c
    READ THE REMAINING DATA LINES
c
      DO 53, J=R+1,2048
       IF(C.EQ.8) READ
                           (1,621) (X(I,J), I=1,C-1)
                           (1,622) (X(I,J), I=1,C-1)
        IF(C.EQ.4) READ
                           (1,624) (X(I,J), I=1,C-1)
       IF(C.EQ.2) READ
      FORMAT (2X, 7(1X, G8.6))
 621
      FORMAT (2X, 3(1X, G8.6))
 622
      FORMAT (2X, 1(1X, G8.6))
 624
      CONTINUE
 53
      CLOSE
              (UNIT=1, STATUS='KEEP')
C
С
    WRITE OUTPUT INFORMATION
С
    WRITE INPUT NICOLET FILE NAME
С
C
      WRITE(2,*) NIC
```

```
Ċ
    COUNT THE NUMBER OF OUTPUT DATA POINTS
      DO 91, I = IS, C
       IF (I.EQ.C) S = R
       DO 90, J = JC, S, SKIP + 1
          NUM = NUM + 1
 90
       CONTINUE
       JC = J - 2048
 91
      CONTINUE
c
    WRITE THE TIME INCREMENT AND NUMBER OF DATA POINTS
C
    TO THE OUTPUT FILE
c
      WRITE(2,*) DELTA*(SKIP+1.)
      WRITE(2,*) NUM
    WRITE THE TIME AND VOLTAGE
      s = 2048
      JC = JS
      DO 81, I = IS, C
      IF (I.EQ.C) S = R
       DO 80, J = JC, S, SKIP + 1
          WRITE (2,70) ((I-1-START)*2048+J)*DELTA, X(I,J)
 80
       CONTINUE
       JC = J - 2048
 81
      CONTINUE
 70
      FORMAT (2X, F12.9, 2X, F10.6)
    CLOSE THE OUTPUT FILE AND END PROGRAM
c
      CLOSE (UNIT=2, STATUS='KEEP')
      PRINT*,' PROGRAM FINISHED'
PRINT*,' DATAFILE ',OUT,'IS READY FOR USE.'
      PRINT*,'
      END
```

#### PSD FFT

This program reads in OUT files created by CONVERT and outputs the PSD FFT of the data after padding the data with zeroes out to a specified power of 2. The maximum number of data points allowed is 131072. Since this program compiles to an executable file larger than 640KB, it was compiled with Microsoft® FORTRAN 5.1 to run inside Microsoft® Windows™ 3.0 using the following command:

FL /MW0 /Gt FFT.FOR /link /SE:4096

It has also been ported to the Department of Nuclear Engineering Sciences DEC™
3000 Model 400 AlphaStation™ running OpenVMS™.

The following subroutines from Price must be supplied or their functional equivalent: REALFT and FOUR1. The required inputs to the program are the input OUT filename, the output FFT filename, and the total number of points desired to be used in the FFT.

```
THIS PROGRAM IS FFT. FOR FROM FT77. FOR FROM PSD. FOR
  DEVELOPED BY KHALID JAMIL AND MODIFIED BY LOUIS H ISELIN *
  UPDATED DEC.29,1990 AND MODIFIED 9 APR 91
  THIS VERSION FOR MS WINDOWS 3.0 AND MS FORTRAN 5.1
       17 NOV 91
*
  SUBROUTINES TAKEN FROM NUMERICAL RECIPES
**********
c
  THE FOLLOWING IS THE DESCRIPTION OF THE VARIABLES USED:
C
Ċ
  VARIABLE DECLARATIONS AND INITIATIONS
     CHARACTER INFILE*40, OUTFILE*40, TITLE*30
     REAL D1. DELTA
     REAL*8 PI
     INTEGER M, NUMPTS, ISIGN
     DIMENSION D1(131072)
     DATA PI /3.14159265358979DO/
С
  MAIN PROGRAM STARTS
C
ċ
  ASK FOR AND OPEN THE INPUT DATA FILE
     PRINT*, *
                             FFT. FOR
     PRINT*, *
                       DEVELOPED BY KHALID JAMIL
                                                         * '
     PRINT*, *
                       MODIFIED BY LOUIS H ISELIN
                                                         * "
     PRINT*,' * UPDATED DEC.29,1990 / MODIFIED 9 APR 91
     PRINT*, * *
                            17 NOV 91
10
     PRINT*, ' ENTER NAME OF YOUR INPUT FILE (UP TO 40 CHARACTERS)'
     READ(*,'(A)') INFILE
     OPEN(1, FILE=INFILE, STATUS='OLD', IOSTAT=IC1)
     IF (IC1.NE.O) THEN
       PRINT*, ' Error ', IC1, ' has occurred.'
       GOTO 10
     ENDIF
     PRINT*.' '
c
  ASK FOR AND OPEN THE OUTPUT FILE
11
     PRINT*.' ENTER NAME FOR OUTPUT FILE (UP TO 40 CHARACTERS)'
     READ(*,'(A)') OUTFILE
     OPEN(2, FILE=OUTFILE, STATUS='NEW', IOSTAT=IC2)
```

```
IF (IC2.NE.O) THEN
          PRINT*.' Error '.IC2.' has occurred.'
         GOTO 11
      ENDIF
      PRINT*.' '
č
   GIVE NUMBER OF DATA POINTS
      PRINT*, ' ENTER NUMBER OF DATA POINTS. MUST BE POWER OF 2'
      PRINT*, SUGGESTED VALES ARE POWERS OF 2:
      PRINT*,
                8192, 16384, 32768, 65536, 131072-MAX'
      PRINT*,'
      READ(*,*)M
      PRINT*,'
  PROGRAM TAKES OVER
С
      PRINT*,' READING INPUT DATA'
READ(1,'(A)') TITLE
READ(1,*) DELTA
      READ(1.*) NUMPTS
      K = 1
      READ(1,*,END=13) DUM, D1(K)
 12
      K = K + 1
      GOTO 12
      PRINT*, ' FAST FINITE FOURIER TRANSFORM STARTS'
 13
      N=M/2
       ISIGN=1
      CALL REALFT (D1, N, ISIGN)
      PRINT*, ' FFT COMPLETED'
      PRINT*, WRITING POWER SPECTRUM DENSITY
      B=0.0
      DO 20 J=1,M,2
          B=B+1.0
          A=D1(J)**2+D1(J+1)**2
       if(b-1..lt.2.e5*m*delta)WRITE(2,*)(B-1.0)/(M*DELTA),A
20
       CONTINUE
      END
С
č
       SUBROUTINE REALFT (DATA, N, ISIGN)
       SUBROUTINE FOUR1 (DATA, NN, ISIGN)
```

#### PXLTA & CXLTA

These two programs are related to CONVERT in that the base code for CONVERT was simply modified to produce modified output ASC files. These ASC files are ASCII code in the block format to be read by ASBIN to be converted to the binary input required for HSVD. PXLTA translates a PRN file to ASC and CXLTA takes an OUT file, from CONVERT or test data in the OUT format, and translates it

to ASC fromat. Although the code says it is for use on PC class personal computers, the same code was used on an IBM<sup>®3</sup> RISC System/6000<sup>™2</sup> computer running AIX<sup>®</sup> and a DECstation<sup>™4</sup> 5000 model 200 running ULTRIX<sup>™3</sup>. The required inputs for PXLTA parallel those required for CONVERT; the only requirements for CXLTA are the input and output filenames.

```
PROGRAM TAKES THE OUTPUT .prn FILE FROM THE NICOLET, CONVERTS THE
c
  NICOLET FORMAT TO A THE INPUT FORMAT REQUIRED FOR
  HSVD [(C) TU-DELFT] AS MODIFIED FOR USE ON PC'S UNDER
  MICROSOFT FORTRAN 5.1 INSIDE THE MICROSOFT WINDOWS 3.0 PLATFORM
c
С
  WRITTEN BY Louis H Iselin
č
  VERSION 1.10 OF 12 OCT 91
ċ
  BASED ON THE ESTABLISHED PROGRAM NAMED 'CONVERT' VERSION 3.20
c
c
  DOCUMENTED BELOW
C
  PROGRAM TAKES THE OUTPUT .prn FILE FROM THE NICOLET AND CONVERTS
c
  THE NICOLET FORMAT TO A USER-NAMED DATAFILE OF TIME VERSUS VOLTAGE
C
c
ċ
  WRITTEN BY Louis H Iselin
  VERSION 3.20 OF 13 JAN 91
c
c
-
C******************************
C
  THE FOLLOWING IS THE DESCRIPTION OF THE VARIABLES USED:
c
С
           = THE NICOLET INPUT FILE NAME
С
   NIC
   HSVDOUT =
              THE OUTPUT FILE NAME FOR HSVD INPUT
c
   ERRMSG
              THE STANDARD ERROR MESSAGE
              THE ERROR NUMBER FOR ERRORS READING INPUT FILE - NIC
c
   IC1
            THE ERROR NUMBER FOR ERRORS READING OUTPUT FILE - HSVDOUT
c
   IC3
             THE INTEGER WHICH DETERMINES THE INPUT FILE
C
   SIZE
C
                  SIZE, (1) FULL-(2) HALF-(4) QUARTER
             THE NUMBER OF COLUMNS OF DATA POINTS
C
           = THE NUMBER OF COLUMNS OF DATA POINTS IN USE
c
c
           = THE NUMBER OF ROWS OF DATA
              THE NUMBER OF ROWS OF DATA IN USE
c
              THE NUMBER OF INITIAL DATA POINTS TO DELETE FROM
c
   DELPTS
                 THE OUTPUT FILE - OUT
C
              THE VOLTAGE DATA POINTS FROM THE INPUT FILE
c
   X(D,S)
              THE NUMBER OF DATA POINTS TO SKIP AFTER EACH RETAINED
C
   SKIP
POINT
              THE TIME BETWEEN EACH DATA POINT
   DELTA
              THE TIME THE FIRST DATA POINT WAS TAKEN WITH RESPECT TO
   START
                 THE TRIGGER OF THE NICOLET
```

<sup>3</sup> Internatinal Business Machines Corporation, White Plains, NY 10604.

<sup>4</sup> Digital Electronics Corporation, Maynard, MA 01754-1418.

```
MAX
           = THE MAXIMUM NUMBER OF DATA POINTS
           = THE INITIAL COLUMN OF DATA
  IS
č
   JS.JC
              THE INITIAL ROW OF DATA
c
                 JS = STATIC, JC = CHANGES
C
              TIME BETWEEN DATA POINTS IN THE OUTPUT FILES
   DELTAT
č
   START
              THE START TIME IN THE OUTPUT FILES
           =
c
   IVAR
              THE ACTUAL NUMBER OF VARIABLES IN THE FILE HSVDOUT
c
   JVAR
             REMAINER OF IVAR/4
ċ
   VARIABLE DECLARATIONS AND INITIATIONS
C
      PROGRAM PYLTA
c
      CHARACTER NIC*36, HSVDOUT*36, ERRMSG*41
                 IC1, IC3, C, R, S, MAX, NUM, IVAR, JVAR
      INTEGER
      INTEGER
                 DELPTS, SKIP, IS, JS, JC, SIZE
                 DELTA, START, X, V
      DIMENSION X(8,2048), V(8192)
      DATA ERRMSG / ** INVALID RESPONSE - PLEASE TRY AGAIN ***/
      DATA IC1 /0/, IC2 /0/, C /8/, R /1536/, S /2048/
      DATA MAX /15872/, NUM /0/
C
      DATA X /16384*-99999./
C
C
    MAIN PROGRAM STARTS
ċ
C
    ASK FOR AND OPEN THE NICOLET INPUT "PRN" DATA FILE
С
      PRINT*,'***************************
      PRINT*, '*
                   PXLTA
                                             . .
      PRINT*, '*
                  WRITTEN BY Louis H Iselin
                                              * "
      PRINT*,'* VERSION 1.10 OF 12 OCT 91
      PRINT*,
      PRINT*, ' Welcome to the PXLTA program to XtransLaTe'
      PRINT*,'
                  the Nicolet prn datafile to datafiles'
      PRINT*,'
                     usable as input files for HSVD'
      PRINT*,' '
      PRINT*, ' What is the Nicolet INPUT file name?'
 10
      PRINT*,'
                        (include path if necessary)'
      PRINT*,' '
      READ(*,'(A)') NIC
      OPEN (UNIT=1, FILE=NIC, STATUS='OLD', IOSTAT=IC1) IF (IC1.NE.0) THEN
       PRINT*, ERRMSG
PRINT*, Error ',IC1,' has occurred.'
       GOTO 10
      ENDIF
      PRINT*,' '
C
ċ
    ASK THE SIZE OF THE NICOLET DATA FILE USED AS INPUT
      PRINT*,' Please give the size of the data spectrum.'
      PRINT*, 'MAX POINTS - 15872
                                      7936
      PRINT*,'
                          (1)Full
                                      (2) Half
                                                (4)Quarter'
      PRINT*,'
      READ(*,*) SIZE
С
    QUARTER SIZED INPUT FILE PARAMETERS
      IF (SIZE.GT.2) THEN
       C=2
       R=1920
```

```
MAY=3968
C
C
    HALF SIZED INPUT FILE PARAMETERS
ċ
       ELSEIF (SIZE.EO.2) THEN
            C=4
            R=1792
            MAX=7936
      ENDIE
      PRINT*,' '
C
    ASK FOR AND OPEN THE HSVD OUTPUT FILE NAME
      PRINT*,' '
      PRINT*, ' What is the desired OUTPUT datafile name for HSVD?'
 25
      PRINT*,'
                         (include path if necessary)'
      PRINT*, '
      READ(*,'(A)') HSVDOUT
      OPEN (UNIT=3, FILE=HSVDOUT, STATUS='NEW', IOSTAT=IC3)
      IF (IC2.NE.O) THEN
         PRINT*, ERRMSG
PRINT*, Error ',IC3,' has occurred.'
         GOTO 25
      ENDIF
      PRINT*.'
С
    ASK FOR THE NUMBER OF INITIAL DATA POINTS TO STRIP FROM THE SPECTRUM
 30
      PRINT*, ' How many initial points do you wish to delete?'
      READ(*.*) DELPTS
      IF ((DELPTS.LT.O).OR.(DELPTS.GE.MAX)) THEN
       PRINT*, ERRMSG
       GOTO 30
      ENDIF
C
    CALCULATE INITIAL COLUMN AND ROW PARAMETERS
c
      IF (DELPTS.GT.2047) THEN
       IS = (DELPTS / 2048) + 1
       JS = MOD (DELPTS , 2048) + 1
      ELSE
       IS = 1
       JS = DELPTS + 1
      ENDIF
      JC = JS
С
Ċ
    ASK FOR THE NUMBER OF DATA POINTS TO SKIP AFTER EACH RETAINED POINT
 40
      PRINT*, ' PLEASE GIVE THE DESIRED SAMPLING INTERVAL. '
      PRINT*, ' How many data points should be skipped'
      PRINT*,'
                  after each retained data point?
      PRINT*,' '
      READ(*,*) SKIP
      IF ((SKIP.LT.0).OR.(SKIP.GE.MAX)) THEN
       PRINT*, ERRMSG
       GOTO 40
      ENDIF
č
    READ INPUT FILE
c
c
    READ FIRST 2 LINES
c
```

```
DO 50. J=1.2
       IF (C.EO.8) READ (1,601) (X(I,J), I=1,C)
          (C.EQ.4) READ (1,602) (X(I,J), I=1,C)
       IF (C.EQ.2) READ (1,604) (X(I,J), I=1,C)
 50
      CONTINUE
 601
      FORMAT (14X, 8(1X,G8.6))
 602
      FORMAT (14X, 4(1X,G8.6))
 604
     FORMAT (14X, 2(1X,G8.6))
C
    READ NEXT 2 LINES, INCLUDING START AND DELTA
C
ċ
      READ
             (1,*) START, (X(I,3), I=1,C)
      READ
             (1.*) DELTA. (X(I.4), I=1.C)
   READ NEXT 3 DATA LINES
c
      DO 51, J=5,7
       IF (C.EQ.8) READ (1,601) (X(I,J), I=1,C)
       IF (C.EQ.4) READ (1,602) (X(I,J), I=1,C)
       IF (C.EQ.2) READ (1,604) (X(I,J), I=1,C)
 51
      CONTINUE
c
C
    READ THE REMAINING DATA LINES WITH FULL COLUMNS OF DATA
      DO 52, J=8,R
       IF (C.EQ.8) READ (1,611) (X(I,J), I=1,C)
       IF (C.EQ.4) READ (1,612) (X(I,J), I=1,C)
       IF (C.EQ.2) READ (1,614) (X(I,J), I=1,C)
 52
      CONTINUE
 611
       FORMAT (2X, 8(1X, G8.6))
FORMAT (2X, 4(1X, G8.6))
 612
       FORMAT (2X, 2(1X, G8.6))
 614
c
c
    READ THE REMAINING DATA LINES
      DO 53, J=R+1,2048
       IF(C.EO.8) READ
                          (1,621) (X(I,J), I=1,C-1)
       IF(C.EQ.4) READ
                          (1,622) (X(I,J), I=1,C-1)
       IF(C.EQ.2) READ
                          (1,624) (X(I,J), I=1,C-1)
 621
     FORMAT (2X, 7(1X, G8.6))
 622
      FORMAT (2X, 3(1X, G8.6))
 624
      FORMAT (2X, 1(1X, G8.6))
 53
      CONTINUE
      CLOSE (UNIT=1. STATUS='KEEP')
С
    COUNT THE NUMBER OF OUTPUT DATA POINTS
C
      DO 91, I = IS, C
       IF (I.EQ.C) S = R
       DO 90, J = JC, S, SKIP + 1
          NUM = NUM + 1
 90
       CONTINUE
       JC = J - 2048
 91
      CONTINUE
С
c
    WRITE THE TIME AND VOLTAGE
      IV = 1
      s = 2048
      JC = JS
      DO 81, I = IS, C
      IF (I.EQ.C) S = R
```

```
DO 80, J = JC, S, SKIP + 1
         IF (IV . LE . 8192 ) THEN
            V(IV) = X(I,J)
            IV = IV + 1
         ENDIF
80
      CONTINUE
      JC = J - 2048
81
     CONTINUE
C
С
    CREATE THE HSVDOUT OUTPUT FILE
C
     IVAR = MIN ( NUM , 8192 )
     WRITE(3,100) REAL(IVAR), DELTA*(SKIP+1.)*1000.,
             REAL((IS-1-START)*2048+JS)*1000.*DELTA, 0.0
 100
     FORMAT (4E15.5)
     DO 110, I = 1, 15
 110
        WRITE(3,100) 0.0, 0.0, 0.0, 0.0
     DO 130, I = 4, IVAR, 4
 130
     WRITE(3,135) V(I-3), V(I-2), V(I-1), V(I)
 135
     FORMAT (4E18.10)
     JVAR = MOD(IVAR, 4)
     IF (JVAR.NE.O) THEN
        WRITE(3,135) (V(J), J = IVAR-JVAR+1, IVAR)
     ENDIF
C
С
C
     PRINT*,' '
     PRINT*, ' PXLTA -- FINISHED -- PXLTA'
     PRINT*, '
     PRINT*, ' THE DESIRED DATAFILE IS READY FOR USE.'
     PRINT*,'
                ', HSVDOUT
     PRINT*,' '
     END
PROGRAM TAKES AN OUTPUT FILE OF TIME VERSUS VOLTAGE IN THE 'CONVERT'*
  FROMAT AND TRANSLATES IT TO THE FILE FORMAT AS INPUT
  FOR HSVD [(C) TU-DELFT] AS MODIFIED FOR USE AT UFlorida
C
c
C
  WRITTEN BY Louis H Iselin
  VERSION 1.10 OF 13 OCT 91
C
c
C****************
C
  THE FOLLOWING IS THE DESCRIPTION OF THE VARIABLES USED:
C
c
C
  FFTIN
            THE INPUT FILE NAME
  HSVDOUT =
C
             THE OUTPUT FILE NAME FOR HSVD INPUT
c
  ERRMSG
             THE STANDARD ERROR MESSAGE
C
  DUMMY
             DUMMY CHARACTER*36 VARIABLE
c
             THE ERROR NUMBER FOR ERRORS READING INPUT FILE - FFTIN
  IC1
c
             THE ERROR NUMBER FOR ERRORS READING OUTPUT FILE - HSVDOUT
  IC3
C
  MAX
             THE MAXIMUM NUMBER OF DATA POINTS
             TIME BETWEEN DATA POINTS IN THE OUTPUT FILES
C
  DELTAT
С
  START
             THE START TIME IN THE OUTPUT FILES
C
  DUM
             DUMMY REAL*4 VARIABLE
C
  VARIABLE DECLARATIONS AND INITIATIONS
C
C
     PROGRAM CXLTA
```

```
C
      CHARACTER FFTIN*36, HSVDOUT*36, ERRMSG*41, DUMMY*36
                 IC1, IC3, MAX, NUM
      INTEGER
      REAL.
                 DELTAT, START, V. DUM
                V(8192)
      DIMENSION
      DATA ERRMSG / ** INVALID RESPONSE - PLEASE TRY AGAIN **'/
DATA IC1 /0/, IC3 /0/
      DATA MAX /8192/, V /8192*0./
C
c
    MAIN PROGRAM STARTS
c
č
    ASK FOR AND OPEN THE INPUT "OUT" DATA FILE
      PRINT*, '***************************
      PRINT*, '*
                      C X T. T A
                                              * *
      PRINT* . '*
                  WRITTEN BY Louis H Iselin
                                              * "
      PRINT*, '* VERSION 1.10 OF 13 OCT 91
                                             . .
      PRINT*, '
      PRINT*,' Welcome to the CXLTA program to TRANSLATE'
      PRINT*,'
                  a time vs voltage datafile to a datafile'
      PRINT*,'
                     usable as an input file for HSVD'
      PRINT*,
      PRINT*,' What is the Nicolet INPUT file name?'
 10
      PRINT*.
                        (include path if necessary)'
      PRINT*, '
      READ(*,'(A)') FFTIN
      OPEN (UNIT=1, FILE=FFTIN, STATUS='OLD', IOSTAT=IC1)
      IF (IC1.NE.O) THEN
          PRINT*, ERRMSG
PRINT*, Error ',IC1,' has occurred.'
          GOTO 10
      ENDIF
      PRINT*,' '
C
ċ
    ASK FOR AND OPEN THE HSVD OUTPUT FILE
      PRINT*, ' What is the desired ASC datafile name for HSVD?'
 20
      PRINT*,
                        (include path if necessary)'
      PRINT*,'
      READ(*,'(A)') HSVDOUT
      OPEN (UNIT=2, FILE=HSVDOUT, STATUS='NEW', IOSTAT=IC3)
      IF (IC3.NE.O) THEN
          PRINT*, ERRMSG
          PRINT*, ' Error ', IC3, ' has occurred.'
          GOTO 20
      ENDIF
      PRINT*,' '
С
c
    READ INPUT FILE
      READ(1,'(A)') DUMMY
      READ(1,*) DELTAT
      READ(1,*) NUM
      READ(1,*) START, V(1)
      IF (NUM.GT.MAX) NUM = MAX
      DO 30, I = 2, NUM
         READ(1,*) DUM, V(I)
 30
      CONTINUE
      CLOSE (UNIT=1, STATUS='KEEP')
```

```
C WRITE OUTPUT INFORMATION TO HSVDOUT
C WRITE(2,100) REAL(NUM), DELTAT*1000., START*1000., 0.0
100 FORMAT(4815.5)
D0 100, I = 1, 15
WRITE(2,100) 0.0, 0.0, 0.0, 0.0
110 CONTINUE
D0 130, I = 4, NUM, 4
130 WRITE(2,135) V(I-3), V(I-2), V(I-1), V(I)
135 FORMAT(4818.10)
JVAR = MOD(NUM, 4)
IF (JVAR.NE.0) THEN
WRITE(2,135) (V(J), J = NUM-JVAR+1, NUM)
ENDIF
ENDI
```

#### HSVD

The code for HSVD and the associated programs, such as ASBIN, are copyrighted by the Delft University of Technology and the use of the programs is controlled by Dr. Ron de Beer. The source code is available from Dr. de Beer only upon his receipt of a letter stating that the programs will only be used in a non-industrial setting. The version used in this work is HSVD 91.1. More information is available from

Dr. Ron de Beer Applied Physics Laboratory Delft University of Technology P.O. Box 5046 2600 GA Delft THE NETHERLANDS

phone: 31 15786394 e-mail: beer@dutnsi2.tudelft.nl

HSVD has two output files: HSVSCR.PAR and SINVAL.DAT.

HSVSCR.PAR is the data regression output file. An example of this file is in

Appendix B. HSVD also wants to write a file of the amplitudes versus the singular

values, named SINVAL.DAT, to help determine which singular values are due to the

resonance signal and which are due to the noise. This file was not used since similar information can also be obtained from the FFT. The basic inputs to HSVD are the input ASC filename, the number of data points, and the value of the Hankel parameter (number of columns in the data matrix). The HSVD package also contains an ERROR program to compute the two sigma errors from the HSVSCR.PAR file.

### FIT

This program uses the Levenberg-Marquart weighted diagonal method of nonlinear least squares curve fitting. All calculations are done in double precision and 10000 data points are fit. The input data must be in a file named "fit.d", the initial parameter guesses must be in a file named "fit.i" and the output file will be named "fit.o". FIT requires the subroutines MRQMIN, MRQCOF, COVSRT, and GAUSSJ from Price, or their functional equivalents. The frequencies must be entered in hertz, the phase in radians, and the relaxation times in seconds.

```
PROGRAM FIT
REAL*8 S.T.DEV.COEF.COVAR.ALPHA.ALAMDA.CHISO.SUM.noise
integer nc, nca, mfit, lista
character*40 title, blank
DIMENSION S(10000), T(10000), DEV(10000), COEF(12), COVAR(12,12)
DIMENSION ALPHA (12,12), LISTA (12)
EXTERNAL FCOSE
DATA NC /12/, ALAMDA /-5./, CHISQ /0.DO/, noise /0.dO/
DATA COVAR /144*0./, ALPHA /144*0./, NCA /12/,MFIT /12/
OPEN(UNIT=1, FILE='fit.d')
sum=0.d0
read(1,'(a)') title
read(1,'(a)') blank
read(1,'(a)') blank
DO 10, I=1,10000
   READ(1,*) S(I), T(I)
   sum=sum+t(i)
    if (i.gt.9500) noise=noise+dabs(t(i))
continue
close(1)
```

10

```
DO 11, I=1,MFIT
 11
         LISTA(I)=I
      DO 12. I=1.10000
 12
         DEV(I)=noise/500.d0
      open(unit=2, file='fit.i')
      DO 13, I=1, MFIT
 13
         read(2,*) coef(i)
      close(2)
      coef(2)=coef(2)*6.283185308d0
      coef(6)=coef(6)*6.283185308d0
      coef(10)=coef(10)*6.283185308d0
      do 14, i=1,10000
 14
         t(i)=t(i)-sum/10000.d0
 20
      CALL MRQMIN(S,T,DEV,10000,COEF,NC,LISTA,MFIT,COVAR,
              ALPHA, NCA, CHISQ, FCOSE, ALAMDA)
      IF (CHISQ.LE.1.d-10) GOTO 25
      if (alamda.lt.1.d-250) goto 25
      if (alamda.gt.1.d+250) goto 25
      GOTO 20
 25
      ALAMDA=0.DO
      CALL MROMIN(S.T.DEV.10000.COEF.NC.LISTA.MFIT.COVAR.
          ALPHA, NCA, CHISQ, FCOSE, ALAMDA)
      coef(2)=coef(2)/6.283185308d0
      coef(6)=coef(6)/6.283185308d0
      coef(10)=coef(10)/6.283185308d0
      OPEN(UNIT=3, FILE='fit.o')
      write(3,*)title
      DO 31 I=1,MFIT
         WRITE(3,*) COEF(I),1.d0/dsqrt(alpha(i,i)*(10000.d0-13.d0))
 31
      continue
      write(3,*)
      write(3,*) ' noise level =', noise/500.d0
C
      SUBROUTINE FCOSE (X, A, YFIT, DYDA, MA)
      REAL*8 X.A, YFIT, DYDA, YFIT1, YFIT2, YFIT3
      integer ma
      DIMENSION A(MA), DYDA(MA)
      YFIT1=A(1)*DCOS(A(2)*X+A(3))*DEXP(-X/A(4))
      YFIT2=A(5)*DCOS(A(6)*X+A(7))*DEXP(-X/A(8))
      YFIT3=A(9) *DCOS(A(10) *X+A(11)) *DEXP(-X/A(12))
      YFIT=YFIT1+YFIT2+YFIT3
      DYDA(1)=YFIT1/A(1)
      DYDA(3) = -A(1)*DSIN(A(2)*X+A(3))*DEXP(-X/A(4))
      DYDA(2) = DYDA(3) *X
      DYDA(4) = YFIT1 * X/A(4)/A(4)
      DYDA(5)=YFIT1/A(5)
      DYDA(7) = -A(5)*DSIN(A(6)*X+A(7))*DEXP(-X/A(8))
      DYDA(6)=DYDA(7)*X
      DYDA(8)=YFIT1*X/A(8)/A(8)
      DYDA(9)=YFIT1/A(9)
      DYDA(11) = -A(9)*DSIN(A(10)*X+A(11))*DEXP(-X/A(12))
      DYDA(10)=DYDA(11) *X
      DYDA(12) = YFIT1 * X/A(12)/A(12)
      RETURN
      END
C
      SUBROUTINE MRQMIN(X,Y,SIG,NDATA,A,MA,LISTA,MFIT,
            COVAR, ALPHA, NCA, CHISQ, FUNCS, ALAMDA)
      SUBROUTINE MRQCOF(X,Y,SIG,NDATA,A,MA,LISTA,MFIT,ALPHA,BETA,NALP,
            CHISQ, FUNCS)
      SUBROUTINE COVSRT(COVAR, NCVM, MA, LISTA, MFIT)
      SUBROUTINE GAUSSJ(A, N, NP, B, M, MP)
```

#### APPENDIX B EXAMPLE FILES

Only the first page is given for each file except where necessary to include important data. The format is shifted to multiple columns in some cases to allow for more of the file to be printed on a page. The  $v_{-}$  line of urea- $d_{4}$  is used as for illustrative purposes. Data was collected with a reference frequency of 2389.00  $\pm$  0.05 kHz.

#### PRN

```
0.000950 0.004044 -.000319 -.001322 -.003428 -.002956 -.002819 -.002594
"PI 1/A"
               0.001419 0.003906 -.000463 -.001375 -.003522 -.002947 -.002812 -.002656
               0.001344 0.003941 -.000413 -.001347 -.003456 -.002891 -.002787 -.002556
 .0000002
               0.000975 0.003841 -.000419 -.001459 -.003447 -.002844 -.002750 -.002472
"From B"
               0.002072 0.003866 -.000541 -.001409 -.003450 -.002837 -.002769 -.002484
" To I"
               0.002353 0.003800 -.000547 -.001419 -.003334 -.002800 -.002744 -.002419
               0.003594 0.003753 -.000597 -.001425 -.003319 -.002747 -.002728 -.002450
"" 0.004959 0.003678 -.000641 -.001441 -.003322 -.002716 -.002706 -.002434
** 0.006384 0.003641 -.000734 -.001484 -.003306 -.002694 -.002684 -.002459
"" 0.009587 0.003597 -.000741 -.001438 -.003256 -.002669 -.002700 -.002509
** 0.011231 0.003544 -.000853 -.001419 -.003269 -.002609 -.002719 -.002466
"" 0.015950 0.003478 -.000897 -.001531 -.003262 -.002684 -.002700 -.002447
** 0.018209 0.003416 -.000963 -.001534 -.003291 -.002694 -.002812 -.002516
"" 0.023569 0.003341 -.000984 -.001547 -.003234 -.002703 -.002763 -.002500
MM 0.026278 0.003347 -.001034 -.001575 -.003269 -.002691 -.002797 -.002516
"" 0.031806 0.003250 -.001137 -.001650 -.003216 -.002816 -.002791 -.002597
*** 0.034094 0.003284 -.001159 -.001769 -.003231 -.002763 -.002819 -.002594
"" 0.040262 0.003187 -.001231 -.001887 -.003234 -.002875 -.002781 -.002666
"" 0.041897 0.003206 -.001247 -.001947 -.003197 -.002884 -.002806 -.002681
"" 0.048809 0.003172 -.001312 -.002119 -.003112 -.002863 -.002725 -.002691
*** 0.050316 0.003138 -.001344 -.002219 -.003163 -.002888 -.002706 -.002647
MM 0.056822 0.003172 -.001425 -.002219 -.003019 -.002837 -.002647 -.002675
"" 0.058872 0.003131 -.001434 -.002331 -.003000 -.002797 -.002584 -.002678
"M 0.064753 0.003128 -.001528 -.002391 -.002969 -.002828 -.002469 -.002706
*** 0.067512 0.002991 -.001550 -.002431 -.002975 -.002806 -.002400 -.002669
"" 0.072875 0.002922 -.001653 -.002450 -.002984 -.002797 -.002384 -.002753
*** 0.076037 0.002866 -.001691 -.002491 -.002959 -.002756 -.002291 -.002763
"" 0.081056 0.002834 -.001775 -.002484 -.003013 -.002734 -.002275 -.002812
" 0.084387 0.002700 -.001850 -.002528 -.002934 -.002759 -.002197 -.002784
*** 0.088231 0.002691 -.001875 -.002537 -.002950 -.002644 -.002141 -.002784
MM 0.091500 0.002672 -.001991 -.002534 -.002906 -.002653 -.002103 -.002778
*** 0.093916 0.002572 -.002041 -.002497 -.002962 -.002728 -.002069 -.002766
```




Figure B-1 PRN file for data set UD106.

## OUT

The following OUT file is the same as the above PRN file, except that the first 456 points have been deleted and than every 5 points after the first has been skipped.

The file has been divided into three columns to conserve space.

ud106.prn		.000108600	.005881	.000174600	007350
2.000000E-07	7	.000109800	.006172	.000175800	007769
2607		.000111000	.006562	.000177000	008384
.000046200	.000100	.000112200	.006984	.000178200	008984
.000047400	000991	.000113400	.007322	.000179400	009325
.000048600	001947	.000114600	.007659	.000180600	009722
.000049800	003041	.000115800	.007997	.000181800	010084
.000051000	003947	.000117000	.008347	.000183000	010334
.000052200	004803	.000118200	.008850	.000184200	010569
.000053400	005375	.000119400	.009094	.000185400	010969
.000054600	005906	.000120600	.009153	.000186600	011175
.000055800	005934	.000121800	.009216	.000187800	011375
.000057000	005962	.000123000	.009494	.000189000	011597
.000058200	006381	.000124200	.009553	.000190200	011625
.000059400	006897	.000125400	.009556	.000191400	011672
.000060600	007391	.000126600	.009625	.000192600	011481
.000061800	008019	.000127800	.009625	.000193800	011391
.000063000	008341	.000129000	.009553	.000195000	011291
.000064200	008672	.000130200	.009638	.000196200	011278
.000065400	008762	.000131400	.009641	.000197400	011378
.000066600	009084	.000132600	.009550	.000198600	011431
.000067800	009634	.000133800	.009231	.000199800	011487
.000069000	009828	.000135000	.009291	.000201000	011512
.000070200	009856	.000136200	.009203	.000202200	011419
.000071400	010091	.000137400	.009066	.000203400	011256
.000072600	009913	.000138600	.008759	.000204600	011053
.000073800	009662	.000139800	.008331	.000205800	010716
.000075000	009363	.000141000	.007531	.000207000	010362
.000076200	009184	.000142200	.006819	.000208200	010306
.000077400	008913	.000143400	.006431	.000209400	010181
.000078600	008556	.000144600	.005975	.000210600	010147
.000079800	008016	.000145800	.005575	.000211800	009787
.000081000	007391	.000147000	.005034	.000213000	009325
.000082200	006831	.000148200	.004453	.000214200	008828
.000083400	006191	.000149400	.003950	.000215400	008391
.000084600	005691	.000150600	.003375	.000216600	007847
.000085800	005341	.000151800	.002900	.000217800	007141
.000087000	004775	.000153000	.002531	.000219000	006550
.000088200	004028	.000154200	.001819	.000220200	005937
.000089400	003231	.000155400	.001053	.000221400	005219
.000099600	002463	.000155400	-000444	.000227400	004684
.000091800	001684	.000157800	.000100	.000223800	004294
.000091000	000819	.000157000	000303	.000225000	003662
.000094200	000037	.000159000	008000	.000226200	003178
.000095400	.000616	.000160200	001425	.000227400	002841
.000095400	.001125	.000167400	002141	.000228600	002362
.000090000	.001500	.000162600	002141	.000228800	001797
.000097800	.002150	.000165000	002000	.000229800	001378
.000099000	.002150	.000166200	003112	.000231000	001378
.000100200	.003000	.000165200	004362	.000232200	000506
.000101400	.003000	.000168600	005219	.000234600	.000100
.000102600	.003716	.000168600		.000234600	.000100
.000103800	.004181	.000169800	005803 006356	.000237000	.001603
.000105000	.004409	.000171000	006862	.000237000	.001603
.000107400	.005359	.000173400	007078	.000239400	.002306




Figure B-2 OUT file for data set UD106.

FFT

This is the PSD FFT of the above OUT file padded with zeroes to 32768 points. A second page is filled to show the peak values.

0.0000000E+00	760.9504	221
38,14697	729.1951	225
76.29395	640.0808	228
114.4409	510.5210	232
152.5879	363.9980	236
190.7349	224.9005	240
228.8818	112,9581	244
267.0288	39.26183	247
305.1758	4.839679	251
343.3228	1.980404	255
381.4697	17.68378	259
419.6167	38.04451	263
457.7637	52.19839	267
495.9106	54.72288	270
534.0576	45.97632	274
572.2046	30.57127	278
610.3516	14.75859	282
648.4985	3.765519	286
686.6455	1.1685744E-02	289
	2.696752	293
724.7925		293
762.9395	8.692378	
801.0864	14.19740	301
839.2334	16.39766	305
877.3804	14.46995	308
915.5273	9.614935	312
953.6743	4.236131	316
991.8213	0.7190000	320
1029.968	0.3768323	324
1068.115	2.993566	328
1106.262	7.089060	331
1144.409	10.70587	335
1182.556	12.31145	339
1220.703	11.40428	343
1258.850	8.590425	347
1296.997	5.161522	350
1335.144	2.428280	354
1373.291	1.146707	358
1411.438	1.291605	362
1449.585	2.237180	366
1487.732	3.200548	370
1525.879	3.689956	373
1564.026	3.724335	377
1602.173	3.731587	381
1640.320	4.210831	385
1678.467	5.365650	389
1716.614	6.921056	392
1754.761	8.228678	396
1792.908	8.603058	400
1831.055	7.703892	404
1869.202	5.751913	408
1907.349	3.453485	411
1945.496	1.664772	415
1983.643	0.9675586	419
2021.790	1.381133	423
2059.937	2.368170	427
2098.083	3.140391	431
2136.230	3.109677	434
2174.377	2.246246	438

2212.524	1.143985
2250.671	0.7383693
2288.818	1.803383
2326.965	4.478462
2365.112	8.078354
2403.259	11.31133
2441.406	12.83292
2479.553	11.88906
2517.700	8.741746
2555.847	4.655894
2593.994	1.422951
2632.141	0.6133943
2670.288	2.884444
2708.435	7.655189
2746.582	13.30301
2784.729	17.80412
2822.876	19.54365
2861.023	17.94721
2899.170	13.66924
2937.317	8.273064
2975.464	3.560611
3013.611	0.8544950
3051.758	0.5388385
3089.905	2.032551 4.166529
3128.052	5.760629
3166.199 3204.346	6.126069
3242.493	5.279334
3280.640	3.807483
3318.787	2.492533
3356.934	1.904005
3395.081	2.160213
3433.228	2.953340
3471.375	3.790556
3509.521	4.297481
3547.668	4.412319
3585.815	4.372459
3623.962	4.516652
3662,109	5.028404
3700.256	5.776313
3738.403	6.350087
3776.550	6.279818
3814.697	5.320628
3852.844	3.642908
3890.991	1.812829
3929.138	0.5563740
3967.285	0.4166425
4005.432	1.476738
4043.579	3.295191
4081.726	5.098189
4119.873	6.143721
4158.020	6.082418
4196.167	5.135392
4234.314	3.994831
4272.461	3.487818
4310.608	4.161575
4348.755	5.990752
4386.902	8.352397

4425.049 4463.196 4501.343 4539.490 4577.637 4615.784 4653.931 4692.078	10.28769 10.93240 9.916217 7.544309 4.676003 2.356279	7057.190 7095.337 7133.484 7171.631	89.41947 89.06531 94.25574 110.4981
4463.196 4501.343 4539.490 4577.637 4615.784 4653.931 4692.078	10.93240 9.916217 7.544309 4.676003	7095.337 7133.484 7171.631	89.06531 94.25574
4501.343 4539.490 4577.637 4615.784 4653.931 4692.078	9.916217 7.544309 4.676003	7133.484 7171.631	94.25574
4539.490 4577.637 4615.784 4653.931 4692.078	7.544309 4.676003	7171.631	
4577.637 4615.784 4653.931 4692.078	4.676003		
4615.784 4653.931 4692.078		7209.778	141.3306
4653.931 4692.078		7247.925	186.6604
4692.078	1.369394	7286.072	242.2114
	1,916727	7324.219	300.3946
4730.225	3.559567	7362.366	352.3742
4768.372	5.443081	7400.513	390.6268
4806.519	6.689876	7438.660	411.0755
4844.666	6.780005	7476.807	414.0274
4882.813	5.749754	7514.954	403.5919
4920.959	4.132702	7553,101	385.8449
4959.106	2.687369	7591.248	366.4799
4997.253	2.048668	7629.395	348.8558
5035.400	2.464096	7667.542	333,1668
5073.547	3.724101	7705.688	316.9741
5111.694	5.298605	7743.835	296.7903
5149.841	6,597362	7781.982	269.9909
5187.988	7.224140	7820.129	236.2471
5226.135	7.111959	7858.276	197.9065
5264.282	6.494284	7896.423	159.2261
5302.429	5.748394	7934.570	124.8379
5340.576	5.202096	7972.717	98, 12273
5378.723	4.999944	8010.864	80.16123
5416.870	5.083504	8049.011	69.64269
5455.017	5.277388	8087, 158	63,68530
5493.164	5.421806	8125.305	59,14591
5531.311	5.476997	8163.452	53,83155
5569.458	5.548172	8201.599	47.12376
5607.605	5.825448	8239.746	39.82930
5645.752	6.475920	8277.893	33.42569
5683.899	7.544211	8316.040	29.11920
5722.046	8.907525	8354.187	27,17266
5760.193	10.30124	8392.334	26.78976
5798.340	11.39964	8430.480	26,55659
5836.487	11.91803	8468.628	25,17804
5874.634	11.70295	8506.774	22,12668
5912.781	10.78876	8544.922	17.88940
5950.928	9.412022	8583.068	13.70854
5989.075	7.981226	8621.216	10,96120
6027.222	7.000308	8659.362	10.48554
6065.369	6.948027	8697.510	12.17386
6103.516	8.129026	8735.656	15.01320
6141.663	10.53481	8773.804	17.53797
6179.810	13.77208	8811.950	18.47137
6217.957	17.11401	8850.098	17.25757
6256.104	19.69605	8888.244	14.25271
6294.250	20.81633	8926.392	10.51087
6332.397	20.23823	8964.538	7.287132
6370.544	18.36128	9002.686	5.496964
6408.691	16.15549	9040.832	5.372013
6446.838	14.84264	9078.979	6.444166
6484.985	15.42540	9117.126	7.831418
6523.132	18.25643	9155.273	8.667295
6561.279	22.85389	9193.420	8.467973
6599.426	28.08397	9231.567	7.282268
6637.573	32.67095	9269.714	5.586030
6675.720	35.82940	9307.861	4.003677
6713.867	37.72206	9346.008	3.008503
6752.014	39.49038	9384.155	2.743257
6790.161	42.77959	9422.302	3.026457
6828.308	48.92173	9460.449	3.511908
6866.455	58.13803	9498.596	3.898499
6904.602	69.17286	9536.743	4.076335
6942.749	79.62966	9574.890	4.142400
6980.896	86.98392	9613.037	4.294917
7019.043	89.91930	9651.184	4.678635




Figure B-3 Full PSD FFT for data set UD106.




Figure B-4 Detail of PSD FFT of data set UD106.

#### ASC

```
0.00000E+00
   0.81920E+04
                 0.20000E-03
                                 0.46200E-01
  0.00000E+00
                  0.00000E+00
                                 0.00000E+00
                                               0.00000E+00
                  0.00000E+00
                                                0.00000E+00
   0.00000E+00
                                 0.00000E+00
   0.00000E+00
                  0.00000E+00
                                 0.00000E+00
                  0.00000E+00
                                 0.00000E+00
                                                0.000006+00
   0.00000E±00
   0.00000E+00
                 0.00000E+00
                                 0.00000E+00
                                               0.00000E+00
                 0.00000E+00
   0.00000E+00
                                 0.00000E+00
                                               0.00000E+00
   0.00000E+00
                 0.00000E+00
                                 0.00000E+00
                                                0.00000E+00
  0.0000000
                 0.00000F+00
                                0.00000E+00
                                               0.00000E+00
   0.00000E+00
                 0.00000E+00
                                 0.00000E+00
                                               0.00000E+00
                 0.00000E+00
                                 0.00000F+00
                                               0.00000F+00
  0.00000E±00
   0.00000E+00
                 0.00000E+00
                                 0.00000E+00
                                               0.00000E+00
                 0.00000F+00
                                 0.00000E+00
  0.00000E+00
                                               0.00000E+00
   0.00000E+00
                  0.00000E+00
                                 0.00000F+00
                                               0.00000E+00
                                0.00000E+00
                                               0.00000E+00
  0.00000E+00
                 0.00000F+00
   0-00000F+00
                  0.00000E+00
                                0.00000F+00
                                                0.00000F+00
 0.999999747E-04 -0.1630000042E-03 -0.3689999867E-03 -0.5690000253E-03
-0.6590000121E-03 -0.8500000113E-03 -0.9909999790E-03 -0.1119000022E-02
-0.1306000049E-02 -0.1430999953E-02 -0.1550000045E-02 -0.1827999949E-02
-0.1947000041E-02 -0.2150000073E-02 -0.2338000108E-02 -0.2536999993E-02
-0.2666000044E-02 -0.2906000009E-02 -0.3041000105E-02 -0.3247000044E-02
-0.3375000088E-02 -0.3540999955E-02 -0.3690999933E-02 -0.3834000090E-02
-0.3947000019E-02 -0.4172000103E-02 -0.4302999936E-02 -0.4433999769E-02
-0.4519000184E-02 -0.4641000181E-02 -0.4803000018E-02 -0.4834000021E-02
-0.499999888E-02 -0.5063000135E-02 -0.5191000178E-02 -0.5297000054E-02
-0.5375000183E-02 -0.5481000058E-02 -0.5634000059E-02 -0.5638000090E-02
-0.5783999804E-02 -0.5830999929E-02 -0.5905999802E-02 -0.5977999885E-02
-0.5983999930E-02 -0.5996999796E-02 -0.6025000010E-02 -0.5925000180E-02
-0.5934000015E-02 -0.5905999802E-02 -0.5849999841E-02 -0.5863000173E-02
-0.5872000009E-02 -0.5931000225E-02 -0.5962000228E-02 -0.6006000098E-02
-0.6033999845E-02 -0.6190999877E-02 -0.6211999804E-02 -0.6359000225E-02
-0.6380999926E-02 -0.6519000046E-02 -0.6606000010E-02 -0.6661999971E-02
-0.6721999962E-02 -0.6819000002E-02 -0.6897000130E-02 -0.6984000094E-02
-0.7025000174E-02 -0.7141000126E-02 -0.7228000090E-02 -0.7321999874E-02
-0.7391000167E-02 -0.7509000134E-02 -0.7577999961E-02 -0.7747000083E-02
-0.7790999953E-02 -0.7927999832E-02 -0.8019000292E-02 -0.7950000465E-02
-0.8105999790E-02 -0.8147000335E-02 -0.8209000342E-02 -0.8247000165E-02
-0.8341000415E-02 -0.8352999575E-02 -0.8415999822E-02 -0.8456000127E-02
-0.8553000167E-02 -0.8596999571E-02 -0.8671999909E-02 -0.8693999611E-02
-0.8728000335E-02 -0.8744000457E-02 -0.8768999949E-02 -0.8750000037E-02
-0.8762000129E-02 -0.8809000254E-02 -0.8828000166E-02 -0.8909000084E-02
-0.8946999907E-02 -0.9022000246E-02 -0.9084000252E-02 -0.9169000201E-02
-0.9286999702E-02 -0.9347000159E-02 -0.9449999779E-02 -0.9655999951E-02
-0.9634000249E-02 -0.9677999653E-02 -0.9734000079E-02 -0.9747000411E-02
-0.9793999605E-02 -0.9812000208E-02 -0.9828000329E-02 -0.9836999699E-02
-0.9862000123E-02 -0.9906000458E-02 -0.9831000119E-02 -0.9847000241E-02
-0.9855999611E-02 -0.9875000454E-02 -0.9897000156E-02 -0.1001300011E-01
-0.9965999983E-02 -0,1003700029E-01 -0,1009100024E-01 -0.1002799999E-01
-0.1002200041E-01 -0.9975000285E-02 -0.1001300011E-01 -0.9975000285E-02
-0.9913000278E-02 -0.9840999730E-02 -0.9812000208E-02 -0.9769000113E-02
-0.9712000377E-02 -0.9655999951E-02 -0.9662000462E-02 -0.9662000462E-02
-0.9575000033E-02 -0.9506000206E-02 -0.9496999905E-02 -0.9406000376E-02
-0.9363000281E-02 -0.9328000247E-02 -0.9269000031E-02 -0.9262000211E-02
-0.9212000296E-02 -0.9212000296E-02 -0.9184000082E-02 -0.9119000286E-02
-0.9084000252E-02 -0.9084000252E-02 -0.8968999609E-02 -0.9008999914E-02
-0.8913000114E-02 -0.8868999779E-02 -0.8828000166E-02 -0.8740999736E-02
-0.8650000207E-02 -0.8612000383E-02 -0.8555999957E-02 -0.8506000042E-02
-0.8396999910E-02 -0.8318999782E-02 -0.8249999955E-02 -0.8128000423E-02
-0.8015999570E-02 -0.7922000252E-02 -0.7833999582E-02 -0.7712000050E-02
-0.7577999961E-02 -0.7422000170E-02 -0.7391000167E-02 -0.7263000123E-02
-0.7184000220E-02 -0.7046999875E-02 -0.7019000128E-02 -0.6928000133E-02
-0.6831000093E-02 -0.6719000172E-02 -0.6653000135E-02 -0.6469000131E-02
-0.6393999793E-02 -0.6275000051E-02 -0.6190999877E-02 -0.6134000141E-02
-0.6025000010E-02 -0.5965999793E-02 -0.5888000131E-02 -0.5783999804E-02
-0.5690999795E-02 -0.5669000093E-02 -0.5559000187E-02 -0.5541000050E-02
```

#### HSVSCR.PAR

This is the output file from HSVD. It has been modified to remove the printing of the singular values and the signal roots. These parameters have only been commented out in the printing of the output file and could easily be returned to the file if they were desired. The damping factor reported here is  $T_2^*$ , the inverse linewidth parameter, and the amplitudes are in arbitrary (relative) units.

```
name of signal file:
                                  ud106.dat
number of data-points of signal:
step-size of signal (milli-seconds):
                                       0.000200
begin time of signal (milli-seconds):
                                         0.0462
number of data-points in havd:
                                           6144
size parameter of hankel matrix:
                                          3072
number of frequencies:
signal noise level:
                                    0.16447E-03
root mean square of havd fit:
                                    0.20322E-02
```

fre(khz) dam(ms) amp(a.u.) phase(degr.)
0.755161E+01 -0.933070E+00 0.110758E-01 0.135269E+03

The ERROR program with HSVD calculates the two-sigma errors.

name of signal file: ud106.dat number of data-points of signal: 8192 step-size of signal (milli-seconds): 0.000 begin time of signal (milli-seconds): 0.046 number of data-points in hsvd: 6144 3072 size parameter of hankel matrix: number of frequencies: 0.1645E+00 signal noise level: root mean square of havd fit: 0.2032E+00 test parameter:

result of havd:

test parameter:

freq f2sd decay d2sd ampor a2sd phasor p2sd (khz) (khz) (a. u.) (degrees) 7.55161 0.47403 -1.07173 2.97845 0.01164 0.01581 10.214 81.797

#### FIT.O

This is the output file of FIT, the nonlinear least squares curve fitting program using the Levenberg-Marquart method. The values are in the order of amplitude, frequency (Hz), phase (rad), and relaxation time (s), for the fitted peak. The values for alpha and covar are the upper triangular matrix values. The alpha column is directly from the fitting program. The covar column is the covariance matrix values. Since variances must be positive, note that covar entries 1, 5, 8 and 10 are indeed positive (emphasis added).

```
ud106.prn
1.397072791946770E-002
 7548.42692677702
0.192156800836138
7.213702176382539E-004
          1.965733364180134E-003
          1.926644355989993E-003
dev
  alpha
                         covar
 92802447.8515003
                        2.993034257636894E-008
 3.47182899708311
                        1.588257543932525E-004
                       -1.243098079541661E-007
 37684.8360559455
 1117605271.79131
                       -1.586853535868848E-009
5.721593453057895E-003
                         477.141996238359
 8.13691770249254
                       -0.212679857744911
0.725177718655479
                       -7.499220742641315E-006
                        1.496014832744504E-004
 18279.8292216466
                        5.938532471083577E-009
 93209.6644723470
 21072415440.6407
                        1.315904099702059E-010
```

While HSVD returns a useful estimate of the frequency, the damping factor is too high and with a large standard deviation due to the errors associated with the poor noise response of the HSVD algorithm. Final NQR parameters for the UD106 data run are resonance frequency 2381.45  $\pm$  0.05 kHz with a T,\* value of 721  $\pm$  12  $\mu$ s.

# APPENDIX C PETERSEN'S SODIUM NITRITE DATA

The sodium nitrite data used as a test of the NQR linewidth analysis method are from Petersen's doctoral thesis [Petersen 1975, 1976]. The graphs used were digitized, smoothed and parameterized and then manipulated.

#### Raw Data

The first column is temperature (K) and the second is the value of the time constant.

Note that the second value in each pair is the logarithmic value from the graph as digitized linearly.

### Upper Line - Spin-Spin Relaxation Time

The raw  $T_2$  data for the  $\nu_+$  line are given here.

75.104230	5.560800E-01	385.750600	7.498900E-01
81.933030	5.205900E-01	401.086700	7.223400E-01
94.094400	6.160200E-01	421.574700	6.667700E-01
116.383900	5.443500E-01	358.187100	5.823600E-01
139.551400	5.943800E-01	373.278500	5.462100E-01
154.090100	5.394000E-01	389.103300	5.446200E-01
163.811600	5.392200E-01	402.955100	5.575500E-01
179.970000	6.073600E-01	424.056200	5.308000E-01
196.157100	5.137900E-01	429.452900	4.038100E-01
208.150100	4.998200E-01	425.704700	2.961400E-01
252.048800	5.491500E-01	430.761800	2.825600E-01
313.884100	6.756700E-01	433.685700	1.866400E-01
327.199200	7.299100E-01	435.123400	1.429100E-01
342.663700	6.842100E-01	445.435300	9.830000E-02
351.992400	6.647800E-01	442.837000	8.061000E-02
361.897600	6.831400E-01	435.844100	8.163000E-02
370.565400	7.280500E-01	431.767700	6.456000E-02
379.132700	6.998100E-01	439.663500	4.433000E-02

```
448.028600
              3.685000E-02
                                       449.874900
                                                    -1.012000E-02
            4.130000E-02
                                       461.398300
                                                    -8.911000E-02
454.319200
438.594700
             1.712000E-02
                                       472.712300
435.908100
                                                    -9.983000E-02
            -1.880000E-02
434.619400
                                                    -1.119900E-01
                                       437.496100
                                                    -1.857900E-01
437.212700
            -2.725000E-02
454.634600
            4.540000E-03
```

#### Upper Line - Inverse Linewidth Parameter

### The To data for the v line are:

```
426.600000
76.570000
            -4.700000E-01
                                                   -6.000000E-01
82,720000
           -4.300000E-01
                                      428.040000
                                                   -6.400000E-01
                                                   -7.500000E-01
94.880000
           -5.000000E-01
                                      448.210000
120,050000
           -5.100000E-01
                                      448,670000
                                                   -7.700000E-01
107.920000
          -4.000000E-01
                                      420,400000
                                                   -8.000000E-01
                                                   -8.000000E-01
117.420000
          -4.300000E-01
                                      430.830000
                                                   -8.00000E-01
140.030000
           -4.100000E-01
                                      438.080000
                                                   -8.000000E-01
154.830000
           -4.100000E-01
                                      441.420000
          -4.400000E-01
                                      445.500000
                                                   -8.000000E-01
162.270000
194.890000
           -4.700000E-01
                                      438.260000
                                                   -8.300000E-01
178.160000
            -4.000000E-01
                                      443.860000
                                                   -8.300000E-01
                                      445.370000
                                                   -8.300000E-01
208.210000
            -3.600000E-01
250.800000
            -2.100000E-01
                                      452.780000
                                                   -8.300000E-01
313.350000
            -1.600000E-01
                                      422,720000
                                                   -8.600000E-01
            -2.000000E-01
326.970000
                                      436.020000
                                                   -8.600000E-01
333.080000
            -2.300000E-01
                                      442.520000
                                                   -8.600000E-01
342.790000
           -2.500000E-01
                                      450.090000
                                                   -8.600000E-01
357.970000
           -1.900000E-01
                                                   -8.600000F-01
                                      453.560000
358.660000
           -2.200000E-01
                                      456.140000
                                                   -8.600000E-01
373.990000
           -2.200000E-01
                                      461.120000
                                                   -8.600000E-01
                                     467.330000
373.480000 -2.600000E-01
                                                  -8.600000E-01
352.410000
          -3.300000E-01
                                      471.590000
                                                   -8.900000E-01
362.050000
          -4.100000E-01
                                      434.020000
                                                   -9.200000E-01
370.310000
          -4.200000E-01
                                      438,250000
                                                   -9.200000E-01
387.890000
          -4.200000E-01
                                      435,610000
                                                   -9.600000E-01
                                     432.840000
380.840000
           -4.600000E-01
                                                       -1.000000
           -5.300000E-01
                                      435.260000
                                                       -1.000000
385.830000
403.990000
          -5.300000E-01
                                      440.840000
                                                       -1.000000
402.530000
                                     435.690000
                                                      -1.050000
          -6.000000E-01
```

#### Lower Line - Spin-Spin Relaxation Time

## The raw $T_2$ data for the $y_1$ line are given here.

76.765730	2.764500E-01	121.172300	4.815600E-01
80.623050	3.691900E-01	138.832900	4.124400E-01
96.277300	4.326400E-01	151.633900	3.935900E-01
117.352700	3.482200E-01	165.835400	3.720600E-01

179.018600	3.823500E-01	440.348400	1.592300E-01
196.053600	3.730900E-01	431.681100	1.520900E-01
208.108700	3.534400E-01	448.995900	1.478700E-01
219.451900	3.581400E-01	440.758400	1.385800E-01
251.658200	5.105100E-01	442.814500	1.380200E-01
311.300900	5.364100E-01	441.944100	1.340100E-01
324.804000	5.376200E-01	437.713300	1.260100E-01
331.609600	5.378200E-01	438.572400	1.198400E-01
351.413500	5.627700E-01	439.762000	1.187500E-01
356.796900	5.488200E-01	443.767200	1.184400E-01
360.037200	5.479900E-01	447.539200	1.028400E-01
369.134700	5.639400E-01	452.735200	1.019800E-01
372.136700	5.457300E-01	451.415000	8.269000E-02
377.157700	5.847300E-01	450.547600	8.162000E-02
383.535600	5.865400E-01	432.680100	7.861000E-02
386.674000	6.760600E-01	435.280100	8.019000E-02
398.907200	6.072600E-01	437.975200	6.997000E-02
400.450600	5.436000E-01	453.674300	6.925000E-02
426.450600	4.031300E-01	459.088300	6.892000E-02
424.065800	3.986100E-01	437.193000	4.826000E-02
429.427600	3.581300E-01	453.635200	3.304000E-02
438.396100	2.522400E-01	434.003700	4.570000E-03
432.399400	2.126500E-01	435.586200	-3.247000E-02
434.753900	1.893100E-01	467.308000	-4.493000E-02
439.078600	1.852400E-01	472.283200	-5.277000E-02
433.334800	1.786000E-01	451.308200	-1.153200E-01
445.984600	1.658600E-01		

#### Lower Line - Inverse Linewidth Parameter

The  $T_2^*$  data for the  $v_1$  line are:

```
-1.900000E-01
75.950000
                                        387.120000
                                                      -3.200000E-01
                                        382.970000
                                                      -3.300000E-01
80.620000
             -2.100000E-01
 86.090000
             -2.300000E-01
                                        378.470000
                                                      -3.800000E-01
96.080000
             -3.300000E-01
                                        400.800000
                                                      -4.600000E-01
105.410000
             -2.800000E-01
                                        398.750000
                                                      -4.900000E-01
118.510000
             -2.600000E-01
                                        425.790000
                                                      -6.000000E-01
138.080000
             -2.900000E-01
                                        423.350000
                                                      -6.400000E-01
151.520000
             -2.800000E-01
                                        435.180000
                                                      -7.000000E-01
166.040000
             -2.800000E-01
                                        446.020000
                                                      -7.000000E-01
208.830000
             -3.600000E-01
                                        440.350000
                                                      -7.200000E-01
219.300000
             -3.000000E-01
                                        447.490000
                                                      -7.200000E-01
                                        430.170000
                                                      -7.500000E-01
178.830000
             -1.900000E-01
196.440000
             -1.900000E-01
                                        432.820000
                                                      -7.400000E-01
251.170000
             -1.000000E-01
                                        439.170000
                                                      -7.400000E-01
311.250000
                                        445.110000
             -5.000000E-02
                                                      -7.500000E-01
355.480000
             -5.000000E-02
                                        450.270000
                                                      -7.400000E-01
325.660000
             -1.500000E-01
                                        452.510000
                                                      -7.400000E-01
                                        441.410000
                                                      -7.700000E-01
331.750000
             -1.500000E-01
370.930000
             -1.500000E-01
                                        446.830000
                                                      -7.700000E-01
360.790000
             -2.400000E-01
                                        449.210000
                                                      -7.700000E-01
350.520000
             -3.100000E-01
                                        440.070000
                                                      -8.000000E-01
368.060000
             -3.200000E-01
                                        450.380000
                                                      -8.000000E-01
```

433.980000	-8.200000E-01	453.920000	-9.200000E-01
437.410000	-8.200000E-01	460.260000	-9.200000E-01
450.880000	-8.300000E-01	471.230000	-9.200000E-01
438.710000	-8.500000E-01	431.650000	-9.600000E-01
440.280000	-8.600000E-01	433.690000	-1.000000
435.220000	-8.900000E-01	467.100000	-1.000000
435.550000	-9.200000E-01	434.740000	-1.070000

#### Linearized Raw Data

#### Upper Line - Spin-Spin Relaxation Time

The linearized raw  $T_2$  data for the  $\nu_+$  line are given here.

75.10423	3.59816	421.57471	4.64269
81.93303	3.31581	424.05620	3.39469
94.0944	4.13067	425.70472	1.97761
116.3839	3.50227	429.45293	2.53402
139.5514	3.92989	430.76184	1.91673
154.09013	3.46258	431.76774	1.16027
163.81158	3.46115	433.68571	1.53688
179.96998	4.04911	434.61937	0.95763
196.15707	3.2643	435.12342	1.38966
208, 1501	3.16097	435.84407	1.20679
252.04879	3.5412	435,90804	0.7727
313.88412	4.73882	437.21272	0.93918
327,19921	5.36921	437.49605	0.65194
342.66367	4.83292	438.59469	1.04021
351,99238	4.62147	439.66354	1.10746
358,18707	3.82261	442.83698	1.20395
361.89758	4.82103	445.43533	1.25401
370.56536	5.34626	448.02862	1.08855
373.27849	3.5173	449.87488	0.97697
379.13266	5.00968	454.31914	1.09977
385.7506	5.62199	454.63463	1.01051
389.10332	3.50445	461.39825	0.8145
401.08668	5.27643	472.71231	0.79464
402.95511	3.61036		

## Upper Line - Inverse Linewidth Parameter

The linearized  $T_2^*$  data for the  $v_*$  line are:

76.57	0.33884	154.83	0.38905
82.72	0.37154	162.27	0.36308
94.88	0.31623	178.16	0.39811
107.92	0.39811	194.89	0.33884
117.42	0.37154	208.21	0.43652
120.05	0.30903	250.80	0.61660
140.03	0.38905	313.35	0.69183

326.97	0.63096	435.26	0.10000
333.08	0.58884	435.61	0.10965
342.79	0.56234	435.69	0.08913
352.41	0.46774	436.02	0.13804
357.97	0.64565	438.08	0.15849
358.66	0.60256	438.25	0.12023
362.05	0.38905	438.26	0.14791
370.31	0.38019	440.84	0.10000
373.48	0.54954	441.42	0.15849
373.99	0.60256	442.52	0.13804
380.84	0.34674	443.86	0.14791
385.83	0.29512	445.37	0.14791
387.89	0.38019	445.50	0.15849
402.53	0.25119	448.21	0.17783
403.99	0.29512	448.67	0.16982
420.40	0.15849	450.09	0.13804
422.72	0.13804	452.78	0.14791
426.60	0.25119	453.56	0.13804
428.04	0.22909	456.14	0.13804
430.83	0.15849	461.12	0.13804
432.84	0.10000	467.33	0.13804
434.02	0.12023	471.59	0.12882

## Lower Line - Spin-Spin Relaxation Time

# The linearized $T_2$ data for the $\nu_-$ line are given here.

76.76573	1.88995	432.6801	1.19842
80,62305	2.33986	433.3348	1.50869
96.27730	2.70795	434.0037	1.01058
117.3527	2.22956	434.7539	1.54636
121.1723	3.03082	435,2801	1,20279
138.8329	2.58488	435.5861	0.92796
151.6339	2.47508	437.1930	1.11753
165.8354	2.35537	437.7133	1.33663
179.0186	2.41185	437.9752	1.17482
196.0536	2.36097	438.3961	1.78748
208.1087	2.25652	438.5724	1.31777
219.4519	2.28108	439.0786	1.53193
251.6583	3.23974	439.7620	1.31447
311.3009	3.43882	440.3484	1.44288
324.8040	3.44842	440.7584	1.37588
331.6096	3.45001	441.9441	1.36148
351.4135	3.65401	442.8145	1.37411
356.7969	3.53851	443.7672	1.31353
360.0372	3.53175	445.9846	1.46508
369.1347	3.66387	447.5392	1.26718
372.1367	3.51342	448.9959	1.40563
377.1577	3.84353	450.5476	1.20676
383.5356	3.85958	451.3082	0.7668
386.6740	4.74308	451.4150	1.20973
398.9072	4.04818	452.7352	1.26468
400.4506	3.49623	453.6352	1.07905
424.0658	2.50386	453.6743	1.17287
426.4506	2.53006	459.0883	1.17198
429.4276	2.28102	467.3080	0.90172
431.6811	1.41935	472.2832	0.88558
432.3994	1.63174		

The linearized  $T_2^*$  data for the  $\nu$  line are:

75.27	0.64565	429.78	0.18197
79.79	0.61660	431.70	0.10965
86.11	0.58884	433.40	0.18197
95.54	0.46774	433.89	0.10000
106.52	0.52481	434.28	0.08511
118.05	0.54954	434.55	0.12882
120.52	0.32359	435.25	0.15136
137.92	0.51286	435.48	0.12023
152.53	0.52481	435.73	0.19953
166.43	0.52481	437.06	0.15136
179.02	0.64565	438.83	0.17783
197.61	0.64565	439.24	0.14125
210.15	0.44668	439.90	0.19055
222.77	0.50119	439.94	0.15849
253.91	0.79433	440.87	0.14125
313.70	0.89125	441.19	0.16982
326.76	0.69183	445.70	0.18197
332.73	0.69183	447.13	0.19953
350.89	0.48978	447.34	0.16982
357.63	0.89125	448.41	0.19055
361.88	0.57544	450.24	0.16982
368.43	0.47863	450.77	0.18197
372.51	0.70795	450.81	0.15136
379.31	0.41687	451.52	0.16218
382.90	0.46774	451.70	0.16218
387.78	0.47863	453.30	0.18197
399.44	0.32359	453.75	0.12023
401.96	0.34674	459.91	0.12023
424.66	0.22909	467.55	0.10000
425.91	0.25119	472.21	0.12023

## Manipulated Data

The  $\nu_+$  line data after smoothing and parameterization are given here.

Temp	$T_2$	$T_2^*$	$1/T_2^*$	1/T2	$y=1/T_2^*-1/T_2$	1/y
75.47	3.69	0.35	0.002857	0.000271	0.002586	0.386677
75.94	3.69	0.35	0.002857	0.000271	0.002586	0.386677
75.95	3.68	0.35	0.002857	0.000272	0.002585	0.386787
77.14	3.68	0.35	0.002857	0.000272	0.002585	0.386787
77.16	3.69	0.35	0.002857	0.000271	0.002586	0.386677
80.00	3.69	0.35	0.002857	0.000271	0.002586	0.386677
80.30	3.70	0.35	0.002857	0.000270	0.002587	0.386567
82.72	3.70	0.35	0.002857	0.000270	0.002587	0.386567
82.87	3.71	0.35	0.002857	0.000270	0.002588	0.386458
85.77	3.71	0.35	0.002857	0.000270	0.002588	0.386458
85.89	3.72	0.35	0.002857	0.000269	0.002588	0.386350

Temp	$T_2$	$T_2^*$	1/T2*	1/T2	$y=1/T_2^*-1/T_2$	1/y
89.96	3.72	0.35	0.002857	0.000269	0.002588	0.386350
90.21	3.73	0.35	0.002857	0.000268	0.002589	0.386243
109.78	3.73	0.35	0.002857	0.000268	0.002589	0.386243
110.01	3.74	0.35	0.002857 0.002857	0.000267	0.002590	0.386136 0.386136
119.76 119.81	3.75	0.35	0.002857	0.000267	0.002590	0.386029
121.24	3.75	0.35	0.002857	0.000267	0.002590	0.386029
121.47	3.74	0.35	0.002857	0.000267	0.002590	0.386136
136.23	3.74	0.35	0.002857	0.000267	0.002590	0.386136
136.37	3.74	0.36	0.002778	0.000267	0.002510	0.398343
141.49	3.74	0.36	0.002778	0.000267	0.002510	0.398343
141.64	3.73	0.36	0.002778	0.000268	0.002510	0.398457
146.76	3.73	0.36	0.002778	0.000268	0.002510	0.398457
146.91	3.72	0.36	0.002778	0.000269	0.002509	0.398571
147.87	3.72	0.36	0.002778	0.000269	0.002509	0.398571
148.00	3.73	0.36	0.002778	0.000268	0.002510	0.398457
148.95 149.22	3.72	0.36	0.002778	0.000268	0.002510	0.398457
155.84	3.72	0.36	0.002778	0.000269	0.002509	0.398571
156.07	3.72	0.37	0.002773	0.000269	0.002434	0.410866
160.11	3.72	0.37	0.002703	0.000269	0.002434	0.410866
160.17	3.71	0.37	0.002703	0.000270	0.002433	0.410988
166.11	3.71	0.37	0.002703	0.000270	0.002433	0.410988
166.26	3.71	0.38	0.002632	0.000270	0.002362	0.423363
167.76	3.71	0.38	0.002632	0.000270	0.002362	0.423363
167.87	3.70	0.38	0.002632	0.000270	0.002361	0.423494
172.71	3.70	0.38	0.002632	0.000270	0.002361	0.423494
172.88 176.31	3.69	0.38	0.002632	0.000271	0.002361	0.423625
176.54	3.68	0.38	0.002632	0.000271	0.002360	0.423758
178.85	3.68	0.39	0.002564	0.000272	0.002292	0.436231
179.12	3.67	0.39	0.002564	0.000272	0.002292	0.436372
180.74	3.67	0.39	0.002564	0.000272	0.002292	0.436372
180.95	3.66	0.39	0.002564	0.000273	0.002291	0.436514
183.05	3.66	0.39	0.002564	0.000273	0.002291	0.436514
183.32	3.65	0.39	0.002564	0.000274	0.002290	0.436656
185.36	3.65	0.39	0.002564	0.000274	0.002290	0.436656
185.49 192.25	3.64	0.40	0.002500	0.000275	0.002225	0.449383
192.46	3.64	0.41	0.002439	0.000275	0.002164	0.462043
192.52	3.64	0.41	0.002439	0.000275	0.002164	0.462043
192.76	3.63	0.41	0.002439	0.000275	0.002164	0.462205
199.03	3.63	0.41	0.002439	0.000275	0.002164	0.462205
199.18	3.63	0.42	0.002381	0.000275	0.002105	0.474953
205.09	3.63	0.42	0.002381	0.000275	0.002105	0.474953
205.30	3.63	0.43	0.002326	0.000275	0.002050	0.487781
212.25	3.63	0.43	0.002326	0.000275	0.002050	0.487781
212.33	3.63	0.44	0.002273	0.000275	0.001997	0.500690
216.35 216.43	3.63	0.44	0.002273	0.000275	0.001997	0.500690
217.24	3.64	0.44	0.002273	0.000275	0.001998	0.500500
217.51	3.64	0.45	0.002273	0.000275	0.001947	0.513480
218.59	3.64	0.45	0.002222	0.000275	0.001947	0.513480
218.85	3.65	0.45	0.002222	0.000274	0.001948	0.513281
221.01	3.65	0.45	0.002222	0.000274	0.001948	0.513281
221.25	3.66	0.45	0.002222	0.000273	0.001949	0.513084
221.27	3.66	0.45	0.002222	0.000273	0.001949	0.513084
221.54	3.66	0.46	0.002174	0.000273	0.001901	0.526125
222.62 222.73	3.66	0.46	0.002174	0.000273	0.001901	0.526125
224.51	3.67	0.46	0.002174	0.000272	0.001901	0.525919
224.66	3.68	0.46	0.002174	0.000272	0.001902	0.525714
225.98	3.68	0.47	0.002128	0.000272	0.001856	0.538816

Temp	$T_2$	$T_2^*$	$1/T_2^*$	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
226.15	3.69	0.47	0.002128	0.000271	0.001857	0.538602
228.38	3.69	0.47	0.002128	0.000271	0.001857	0.538602
228.53	3.70	0.47	0.002128	0.000270	0.001857	0.538390
229.61 229.71	3.70 3.71	0.47	0.002128	0.000270	0.001857 0.001814	0.538390
231.79	3.71	0.48	0.002083	0.000270	0.001814	0.551331
231.89	3.72	0.48	0.002083	0.000269	0.001815	0.551111
232.97	3.72	0.48	0.002083	0.000269	0.001815	0.551111
233.10	3.73	0.48	0.002083	0.000268	0.001815 0.001815	0.550892
233.57	3.73	0.49	0.002041	0.000268	0.001773	0.564105
234.18	3.73	0.49	0.002041	0.000268	0.001773	0.564105
234.31	3.74	0.49	0.002041	0.000267	0.001773	0.563877
235.94	3.74	0.49	0.002041	0.000267	0.001773	0.563877
236.99	3.75	0.49	0.002041	0.000267	0.001774	0.563650
237.13	3.76	0.49	0.002041	0.000266	0.001775	0.563425
237.28	3.76	0.49	0.002041	0.000266	0.001775	0.563425
237.43 238.06	3.76 3.76	0.50	0.002000	0.000266	0.001734	0.576687
238.32	3.77	0.50	0.002000	0.000265	0.001735	0.576453
239.81	3.77	0.50	0.002000	0.000265	0.001735	0.576453
239.96	3.78	0.50	0.002000	0.000265	0.001735	0.576220
240.75 241.00	3.78 3.79	0.50	0.002000	0.000265	0.001735 0.001736	0.576220 0.575988
242.05	3.79	0.50	0.002000	0.000264	0.001736	0.575988
242.19	3.79	0.51	0.001961	0.000264	0.001697	0.589299
242.34	3.79	0.51	0.001961	0.000264	0.001697	0.589299
242.49	3.80	0.51	0.001961 0.001961	0.000263	0.001698 0.001698	0.589058
243.69	3.81	0.51	0.001961	0.000262	0.001698	0.588818
245.32	3.81	0.51	0.001961	0.000262	0.001698	0.588818
245.72 246.26	3.82	0.51	0.001961	0.000262	0.001699	0.588580
246.51	3.83	0.51	0.001961	0.000262	0.001700	0.588343
246.79	3.83	0.52	0.001923	0.000261	0.001662	0.601692
247.19	3.83	0.52	0.001923	0.000261	0.001662	0.601692
247.41 248.46	3.84	0.52	0.001923 0.001923	0.000260	0.001663 0.001663	0.601446
248.53	3.85	0.52	0.001923	0.000260	0.001663	0.601201
248.93	3.85	0.52	0.001923	0.000260	0.001663	0.601201
249.20 250.00	3.86	0.52	0.001923	0.000259	0.001664	0.600958
250.00	3.86	0.52	0.001923	0.000259	0.001664	0.600958
250.99	3.87	0.52	0.001923	0.000258	0.001665	0.600716
251.21	3.88	0.52	0.001923	0.000258	0.001665	0.600476
251.59	3.88	0.52	0.001923	0.000258	0.001665	0.600476
251.74 252.28	3.89	0.54	0.001852 0.001852	0.000257	0.001595	0.627045
252.48	3.90	0.54	0.001852	0.000256	0.001595	0.626786
253.21	3.90	0.54	0.001852	0.000256	0.001595	0.626786
253.38 254.15	3.91 3.91	0.54	0.001852 0.001852	0.000256	0.001596	0.626528
254.42	3.92	0.54	0.001852	0.000255	0.001597	0.626272
255.23	3.92	0.54	0.001852	0.000255	0.001597	0.626272
255.32	3.93	0.54	0.001852	0.000254	0.001597	0.626018
256.03 256.16	3.93	0.54	0.001852 0.001852	0.000254	0.001597 0.001598	0.626018
256.56	3.94	0.54	0.001852	0.000254	0.001598	0.625765
256.69	3.94	0.55	0.001818	0.000254	0.001564	0.639233
256.70 256.81	3.94	0.55	0.001818	0.000254	0.001564	0.639233
257.41	3.95	0.55	0.001818	0.000253	0.001565	0.638971

257.63   3.96   0.55   0.001818   0.000253   0.001566   0.638710	Temp	$T_2$	$T_2^*$	$1/T_2^*$	1/T2	$y=1/T_2^*-1/T$	1/y
258, 31 3, 97 0.55 0.001818 0.000225 0.001566 0.638450 259, 55 3, 397 0.55 0.001818 0.000251 0.001567 0.638192 260.10 3, 398 0.55 0.001818 0.000251 0.001567 0.638192 260.10 3, 398 0.55 0.001818 0.000251 0.001567 0.638192 260.85 3, 399 0.55 0.001818 0.000251 0.001568 0.637836 0.60.85 3, 399 0.55 0.001818 0.000251 0.001568 0.637936 260.85 3, 399 0.55 0.001818 0.000251 0.001568 0.637936 260.85 3, 399 0.55 0.001818 0.000250 0.001568 0.637936 260.98 4.00 0.55 0.001818 0.000250 0.001568 0.637861 262.19 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.72 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000250 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637146 263.79 4.03 0.56 0.001786 0.000249 0.001569 0.637176 263.79 4.03 0.56 0.001786 0.000248 0.001530 0.6378176 265.50 4.00 4.00 4.00 4.00 4.00 4.00 4.00							
259, 50 3, 3, 97 0.55 0.001818 0.000252 0.001566 0.638450 269.10 3,98 0.55 0.001818 0.000251 0.001567 0.638192 260.126 3,99 0.55 0.001818 0.000251 0.001567 0.638192 260.26 3,99 0.55 0.001818 0.000251 0.001568 0.637936 260.98 4.00 0.55 0.001818 0.000251 0.001568 0.637936 260.98 4.00 0.55 0.001818 0.000250 0.001568 0.637981 262.19 4.00 0.55 0.001818 0.000250 0.001568 0.637861 262.19 4.01 0.55 0.001818 0.000250 0.001568 0.637861 262.19 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637146 263.73 4.02 0.55 0.001818 0.000249 0.001569 0.637146 263.79 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.04 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.04 0.56 0.001786 0.000248 0.001538 0.550375 265.40 4.04 0.56 0.001786 0.000248 0.001538 0.550375 265.40 4.05 4.05 0.001786 0.000248 0.001538 0.550315 265.40 4.05 4.05 0.001786 0.000248 0.001538 0.550315 265.40 4.05 0.56 0.001786 0.000248 0.001538 0.550315 265.40 4.05 0.56 0.001786 0.000248 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.07 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.07 0.05 0.001786 0.000247 0.001539 0.649857 266.40 4.07 0.05 0.001786 0.000247 0.001539 0.649860 267.14 4.07 0.56 0.001786 0.000245 0.001540 0.649345 267.01 4.00 0.56 0.001786 0.000245 0.001540 0.649345 267.01 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.01 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.01 4.10 0.56 0.001786 0.000246 0.001540 0.649345 267.01 4.10 0.56 0.001786 0.000247 0.001541 0.649931 270.20 4.11 0.56 0.001786 0.000240 0.001541 0.648938 267.14 4.10 0.56 0.001786 0.000240 0.001541 0.648938 267.14 4.10 0.56 0.001786 0.000240 0.001640 0.64838 267.14 4.11 0.56 0.001786 0.000240 0.001640 0.64838 267.14 4.11 0.56 0.001786 0.							
259, 50 3,98 0.55 0.001818 0.000251 0.001567 0.638192 260.26 3,99 0.55 0.001818 0.000251 0.001568 0.637936 260.85 3,99 0.55 0.001818 0.000251 0.001568 0.637936 260.85 3,99 0.55 0.001818 0.000251 0.001568 0.637936 260.85 3,99 0.55 0.001818 0.000251 0.001568 0.637936 260.98 4.00 0.55 0.001818 0.000250 0.001568 0.637981 261.92 4.01 0.55 0.001818 0.000250 0.001568 0.637681 262.72 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.72 4.01 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.70 4.03 0.56 0.001786 0.000249 0.001569 0.637176 263.70 4.03 0.56 0.001786 0.000249 0.001569 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001570 0.636925 264.66 4.04 0.56 0.001786 0.000248 0.001539 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001539 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001539 0.550375 264.66 4.04 0.56 0.001786 0.000248 0.001539 0.550375 266.60 4.04 0.56 0.001786 0.000248 0.001539 0.550375 266.60 4.04 0.56 0.001786 0.000248 0.001539 0.569375 266.60 4.04 0.56 0.001786 0.000248 0.001539 0.649857 266.61 4.06 0.56 0.001786 0.000246 0.001539 0.649857 266.61 4.06 0.56 0.001786 0.000246 0.001539 0.649857 266.71 4.00 0.56 0.001786 0.000246 0.001539 0.649857 267.75 4.00 0.56 0.001786 0.000246 0.001539 0.649857 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.00 0.00 0.00 0.00 0.00 0.00 0.0							
260.10         3.98         0.55         0.001818         0.000251         0.001567         0.638192           260.26         3.99         0.55         0.001818         0.000251         0.001568         0.637936           260.98         4.00         0.55         0.001818         0.000250         0.001568         0.637861           261.92         4.00         0.55         0.001818         0.000250         0.001569         0.637428           262.72         4.01         0.55         0.001818         0.000249         0.001569         0.637428           263.73         4.02         0.55         0.001818         0.000249         0.001569         0.637176           263.74         4.03         0.55         0.001818         0.000249         0.001569         0.637176           263.79         4.03         0.55         0.001818         0.000248         0.001539         0.637176           264.45         4.03         0.56         0.001786         0.002248         0.001538         0.550375           265.40         4.04         0.56         0.001786         0.002248         0.001538         0.55015           265.40         4.04         0.56         0.001786         0.00247							
260.26 3.99 0.55 0.001818 0.000251 0.001568 0.637936 260.98 4.00 0.55 0.001818 0.000251 0.001568 0.637936 260.98 4.00 0.55 0.001818 0.000250 0.001568 0.637861 261.92 4.00 0.55 0.001818 0.000250 0.001568 0.637861 262.19 4.01 0.55 0.001818 0.000250 0.001568 0.637861 262.72 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.72 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001570 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001570 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001539 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001539 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.04 0.56 0.001786 0.000248 0.001538 0.550375 264.60 4.05 0.56 0.001786 0.000248 0.001539 0.550375 264.60 4.05 0.56 0.001786 0.000248 0.001539 0.549857 265.60 4.00 4.056 0.001786 0.000248 0.001539 0.549857 265.60 4.00 4.056 0.001786 0.000248 0.001539 0.649857 265.70 4.00 4.056 0.001786 0.000246 0.001539 0.649857 265.71 4 4.07 0.56 0.001786 0.000246 0.001539 0.649857 265.71 4 4.07 0.56 0.001786 0.000246 0.001539 0.649857 265.71 4 4.07 0.56 0.001786 0.000246 0.001539 0.649857 265.71 4 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001541 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.00 0.00 0.00 0.00 0.00 0.00 0.00 0.0			0.55				
260.98 4.00 0.55 0.001818 0.000250 0.001568 0.637681 262.19 4.01 0.55 0.001818 0.000250 0.001568 0.637681 262.19 4.01 0.55 0.001818 0.000250 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637146 263.57 0.40 0.56 0.001786 0.000248 0.001570 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001570 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001539 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.60 4.04 0.56 0.001786 0.000248 0.001538 0.550375 265.45 0.00 4.04 0.56 0.001786 0.000248 0.001538 0.550315 265.53 4.05 0.56 0.001786 0.000248 0.001539 0.549857 266.47 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.05 0.56 0.001786 0.000248 0.001539 0.649857 266.47 4.06 0.56 0.001786 0.000247 0.001539 0.649857 267.01 4.06 0.56 0.001786 0.000246 0.001539 0.649857 267.13 4.07 0.55 0.001786 0.000247 0.001539 0.649857 268.47 4.08 0.56 0.001786 0.000246 0.001539 0.649857 268.47 4.09 0.56 0.001786 0.000246 0.001539 0.6498600 267.01 4.06 0.56 0.001786 0.000246 0.001539 0.6498600 268.47 4.09 0.56 0.001786 0.000246 0.001539 0.6498600 268.47 4.09 0.56 0.001786 0.000246 0.001540 0.649345 267.13 4.08 0.56 0.001786 0.000246 0.001540 0.649345 267.13 4.08 0.56 0.001786 0.000246 0.001540 0.649345 267.13 4.05 0.001786 0.000246 0.001540 0.649345 267.13 4.05 0.001786 0.000246 0.001540 0.649345 277.15 4.07 0.55 0.001786 0.000247 0.001541 0.648938 269.25 4.11 0.56 0.001786 0.000240 0.001541 0.648938 277.15 4.10 0.56 0.001786 0.000241 0.001541 0.648938 277.15 4.10 0.56 0.001786 0.000241 0.001542 0.648338 277.15 4.10 0.56 0.001786 0.000243 0.001542 0.648338 277.15 4.10 0.56 0.001786 0.000242 0.001544 0.647843 277.15 4.10 0.56 0.001786 0.000242 0.001544 0.647843 277.15 4.11 0.56 0.001786 0.000240 0.001544 0.647843 277.15 4.11 0.56 0.001786 0.000240 0.001544 0.647843 277.15 4.11 0.55 0.001786 0.000240 0.001544 0.647843 277.15 4.11 0.55 0.001786 0.000240	260.26	3.99	0.55	0.001818			0.637936
261.92 4.00 0.55 0.001818 0.000249 0.001569 0.637428 262.72 4.01 0.55 0.001818 0.000249 0.001569 0.637428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637428 263.76 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.53 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.77 4.03 0.55 0.001818 0.000249 0.001569 0.637176 263.79 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.04 0.56 0.001786 0.000248 0.001538 0.550375 264.60 4.04 0.56 0.001786 0.000248 0.001538 0.550375 265.40 4.05 0.56 0.001786 0.000248 0.001538 0.550375 266.40 4.05 0.56 0.001786 0.000248 0.001538 0.550315 265.40 4.05 0.56 0.001786 0.000248 0.001539 0.549857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000246 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000246 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000246 0.001539 0.649857 266.40 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.01 4.07 0.56 0.001786 0.000246 0.001539 0.649800 267.14 4.07 0.56 0.001786 0.000246 0.001530 0.649345 268.35 4.08 0.56 0.001786 0.000246 0.001540 0.649345 268.35 4.08 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000244 0.001541 0.649991 268.47 4.09 0.56 0.001786 0.000244 0.001542 0.648338 269.25 4.11 0.56 0.001786 0.000244 0.001542 0.648338 270.05 4.11 0.56 0.001786 0.000244 0.001542 0.648338 270.15 4.14 0.15 0.001786 0.000244 0.001542 0.648338 270.15 4.14 0.55 0.001786 0.000244 0.001542 0.648338 271.15 4.14 0.55 0.001786 0.000244 0.001544 0.647844 271.18 4.13 0.55 0.001786 0.000244 0.001544 0.647844 271.18 4.13 0.55 0.001786 0.000244 0.001544 0.647844 271.18 4.13 0.55 0.001786 0.000240 0.001644 0.647844 271.18 0.14 0.58 0.001786 0.000240 0.001644 0.647844 271.18 0.15 0.58 0.001786 0.000240 0.001644 0.647844 271.18 0.15 0.58 0.001786 0.000240 0.001644 0.647844 271.18 0.15 0.58 0.001786 0.000240 0.001648 0.647396 272.27 4.11 0.56 0.001786 0.000240 0.001648 0.647396 272.28 4.11 0.56 0.001786 0.0002							
262.19         4.01         0.55         0.001818         0.000249         0.001569         0.637428           262.72         4.01         0.55         0.001818         0.000249         0.001569         0.637428           262.85         4.02         0.55         0.001818         0.000249         0.001569         0.637176           263.73         4.03         0.55         0.001818         0.000248         0.001570         0.637176           264.60         4.03         0.56         0.001786         0.002248         0.001538         0.550375           264.40         4.04         0.56         0.001786         0.002248         0.001538         0.550375           265.53         4.05         0.56         0.001786         0.002248         0.001538         0.550375           266.47         4.04         0.56         0.001786         0.002247         0.001538         0.55015           266.47         4.05         0.56         0.001786         0.002246         0.001539         0.649957           266.47         4.06         0.56         0.001786         0.002246         0.001539         0.649956           267.14         4.07         0.56         0.001786         0.002246							
262, 72 4.01 0.55 0.001818 0.000249 0.001569 0.6371428 262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.75 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.77 4.03 0.55 0.001818 0.000249 0.001569 0.637176 263.77 4.03 0.55 0.001818 0.000248 0.001579 0.636925 263.79 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.04 0.56 0.001786 0.000248 0.001538 0.550375 265.40 4.04 0.56 0.001786 0.000248 0.001538 0.550315 265.40 4.04 0.56 0.001786 0.000248 0.001538 0.550315 265.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.06 0.56 0.001786 0.000246 0.001539 0.649857 267.01 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.75 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.75 4.07 0.56 0.001786 0.000245 0.001540 0.649335 267.75 4.07 0.56 0.001786 0.000245 0.001540 0.649335 267.75 4.07 0.56 0.001786 0.000245 0.001540 0.649335 267.75 4.09 0.001540 0.001540 0.649335 268.45 4.09 0.56 0.001786 0.000245 0.001541 0.649931 268.45 4.09 0.56 0.001786 0.000244 0.001541 0.649991 268.47 4.09 0.56 0.001786 0.000244 0.001541 0.649931 268.65 4.10 0.56 0.001786 0.000244 0.001542 0.648838 269.14 4.10 0.56 0.001786 0.000244 0.001542 0.648838 269.14 4.10 0.56 0.001786 0.000244 0.001542 0.648838 270.00 4.11 0.56 0.001786 0.000243 0.001541 0.648931 270.00 4.11 0.56 0.001786 0.000243 0.001541 0.648931 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648838 270.00 4.11 0.56 0.001786 0.000242 0.001544 0.647843 271.44 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.45 4.14 0.58 0.001786 0.000242 0.001648 0.647836 271.50 4.14 0.58 0.001786 0.000242 0.001648 0.647836 271.50 4.14 0.58 0.001786 0.000242 0.001648 0.647838 271.50 4.14 0.58 0.001786 0.000242 0.001648 0.647838 271.50 4.14 0.58 0.001786 0.000240 0.001648 0.647830 271.50 4.14 0.58 0.001786 0.000240 0.001648 0.647830 271.50 4.14 0.58 0.001786 0.000240 0.001648 0.647830 271.65 4.15 0.58 0.001786 0.000240 0.001648							
262.85 4.02 0.55 0.001818 0.000249 0.001569 0.637176 263.70 4.03 0.55 0.001818 0.000249 0.001569 0.637176 263.70 4.03 0.56 0.001786 0.000248 0.001570 0.636925 264.60 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 265.40 4.04 0.56 0.001786 0.000248 0.001538 0.550375 265.53 4.05 0.56 0.001786 0.000248 0.001538 0.550315 265.53 4.05 0.56 0.001786 0.000248 0.001538 0.550115 265.53 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.06 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.06 0.56 0.001786 0.000246 0.001539 0.649857 267.14 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.14 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.81 4.07 0.56 0.001786 0.000246 0.001539 0.649958 267.81 4.08 0.56 0.001786 0.000246 0.001530 0.649335 267.81 4.08 0.56 0.001786 0.000246 0.001540 0.649345 267.81 4.08 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000244 0.001541 0.648931 268.65 4.10 0.56 0.001786 0.000244 0.001541 0.648838 269.12 4.11 0.56 0.001786 0.000244 0.001542 0.648588 269.12 4.11 0.56 0.001786 0.000243 0.001542 0.648588 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001544 0.648783 271.14 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.14 0.56 0.001786 0.000242 0.001544 0.647843 271.14 0.56 0.001786 0.000242 0.001544 0.647843 271.14 0.56 0.001786 0.000242 0.001544 0.647843 271.14 0.56 0.001786 0.000242 0.001544 0.647838 271.15 0.414 0.58 0.001724 0.000241 0.001648 0.67396 272.75 4.15 0.58 0.001724 0.000241 0.001648 0.67396 272.75 4.15 0.58 0.001724 0.000240 0.001648 0.67396 272.75 4.15 0.58 0.001724 0.000240 0.001648 0.67396 272.75 4.15 0.58 0.001724 0.000240 0.001648 0.67396 272.75 4.15 0.58 0.001724 0.000240 0.001648 0.67396 272.							
263.70 4.03 0.55 0.001818 0.000248 0.001570 0.536925 264.60 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.45 4.03 0.56 0.001786 0.000248 0.001538 0.550375 265.46 0.04 0.40 0.56 0.001786 0.000248 0.001538 0.550375 265.53 4.05 0.56 0.001786 0.000248 0.001538 0.550315 265.53 4.05 0.56 0.001786 0.000248 0.001538 0.550315 265.53 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.06 0.56 0.001786 0.000247 0.001539 0.649857 267.14 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.14 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.81 4.07 0.56 0.001786 0.000246 0.001539 0.649857 267.81 4.07 0.56 0.001786 0.000246 0.001530 0.649345 267.81 4.08 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000246 0.001540 0.649345 268.47 4.09 0.56 0.001786 0.000244 0.001541 0.648931 268.65 4.10 0.56 0.001786 0.000244 0.001541 0.648931 268.65 4.10 0.56 0.001786 0.000244 0.001541 0.648838 269.12 4.11 0.56 0.001786 0.000244 0.001542 0.648588 269.12 4.11 0.56 0.001786 0.000243 0.001542 0.648588 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648588 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648900 270.31 4.13 0.56 0.001786 0.000243 0.001543 0.64890 271.54 4.15 0.58 0.001786 0.000242 0.001544 0.647843 271.14 4.15 0.58 0.001786 0.000242 0.001544 0.647843 271.14 0.56 0.001786 0.000242 0.001544 0.647843 271.15 4.14 0.56 0.001786 0.000242 0.001544 0.647843 271.15 4.14 0.58 0.001786 0.000242 0.001544 0.647898 271.55 4.15 0.58 0.001786 0.000242 0.001544 0.647898 271.55 4.15 0.58 0.001786 0.000242 0.001544 0.647898 271.56 4.15 0.58 0.001786 0.000242 0.001648 0.673966 272.75 4.15 0.58 0.001724 0.000240 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.15 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.15 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.15 0.58 0.001724 0.00023							
263.79 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.65 40 4.03 0.56 0.001786 0.000248 0.001538 0.550375 264.60 4.04 0.56 0.001786 0.000248 0.001538 0.550315 265.40 4.04 0.56 0.001786 0.000248 0.001538 0.550315 265.40 4.05 0.56 0.001786 0.000248 0.001539 0.550315 265.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.06 0.56 0.001786 0.000246 0.001539 0.649857 267.01 4.06 0.56 0.001786 0.000246 0.001539 0.649857 267.01 4.07 0.56 0.001786 0.000246 0.001539 0.649850 0.267.01 4.07 0.56 0.001786 0.000246 0.001539 0.649850 0.267.75 4.07 0.56 0.001786 0.000246 0.001539 0.649850 0.267.75 4.07 0.56 0.001786 0.000246 0.001530 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 268.35 4.08 0.56 0.001786 0.000245 0.001541 0.649991 268.47 4.09 0.56 0.001786 0.000244 0.001540 0.649345 269.25 4.11 0.55 0.001786 0.000244 0.001541 0.649991 268.65 4.11 0.55 0.001786 0.000244 0.001542 0.648838 269.12 4.11 0.55 0.001786 0.000244 0.001542 0.648838 269.25 4.11 0.55 0.001786 0.000244 0.001542 0.648838 270.00 4.11 0.55 0.001786 0.000243 0.001542 0.648338 270.00 4.11 0.55 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.55 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.55 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.55 0.001786 0.000243 0.001543 0.648090 270.24 4.12 0.55 0.001786 0.000243 0.001543 0.648090 270.24 4.12 0.55 0.001786 0.000243 0.001543 0.648090 271.15 4.14 0.55 0.001786 0.000242 0.001544 0.647843 271.15 4.14 0.55 0.001786 0.000242 0.001544 0.647843 271.15 4.14 0.55 0.001786 0.000242 0.001544 0.647843 271.15 4.14 0.55 0.001786 0.000242 0.001544 0.647843 271.15 4.14 0.55 0.001786 0.000242 0.001544 0.647839 271.15 4.14 0.55 0.001786 0.000242 0.001544 0.647830 271.15 4.14 0.55 0.001786 0.000240 0.001648 0.673765 271.25 4.15 0.58 0.00174 0.000240 0.001648 0.673765 272.08 4.15 0.58 0.00174 0.000240 0.001648 0.673765 272.26 4.15 0.58 0.00174 0.000240 0.001648 0.673765 272.26 4.15 0.58 0.00174 0.000240 0.001648 0.673765 272.26 4.15 0.58 0.001724 0	263.53	4.02	0.55		0.000249	0.001569	
264.45         4.03         0.56         0.001786         0.000248         0.001538         0.550375           264.60         4.04         0.56         0.001786         0.000248         0.001538         0.550115           265.53         4.05         0.56         0.001786         0.000247         0.001539         0.649857           266.47         4.06         0.56         0.001786         0.000247         0.001539         0.649857           266.47         4.06         0.56         0.001786         0.000246         0.001539         0.649857           267.14         4.07         0.56         0.001786         0.000246         0.001539         0.649936           267.81         4.08         0.56         0.001786         0.000246         0.001540         0.649345           268.47         4.07         0.56         0.001786         0.002246         0.001540         0.649345           268.47         4.08         0.56         0.001786         0.002245         0.001541         0.649345           268.47         4.10         0.56         0.001786         0.002244         0.001542         0.648938           269.12         4.11         0.56         0.01786         0.002243							
264.60 4.04 0.56 0.001786 0.000248 0.001538 0.550115 265.40 4.04 0.56 0.001786 0.000247 0.001539 0.550115 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.06 0.56 0.001786 0.000247 0.001539 0.649857 267.01 4.06 0.56 0.001786 0.000247 0.001539 0.649857 267.01 4.07 0.56 0.001786 0.000246 0.001539 0.649857 0.670174 0.001539 0.649857 0.670174 0.001539 0.649857 0.670174 0.001539 0.649857 0.670174 0.001539 0.649857 0.670174 0.001539 0.649857 0.670174 0.001539 0.649857 0.670174 0.001539 0.649850 0.001746 0.000246 0.001530 0.649345 0.670174 0.001540 0.001540 0.0649345 0.001540 0.001540 0.649345 0.001540 0.001540 0.0649345 0.001540 0.001540 0.649345 0.001540 0.001540 0.001540 0.649345 0.001541 0.001540 0.001540 0.001540 0.649345 0.001541 0.001541 0.649091 0.001541 0.001541 0.649091 0.001541 0.001541 0.649091 0.001541 0.001541 0.649091 0.001541 0.001541 0.001541 0.648938 0.001741 0.001541 0.001541 0.648938 0.001541 0.001541 0.001541 0.648938 0.001541 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001541 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.648838 0.001741 0.001541 0.001541 0.6487841 0.001541 0.001541 0.001541 0.6487841 0.001541 0.001541 0.001541 0.6487841 0.001541 0.001541 0.001541 0.6487841 0.001541 0.001541 0.001541 0.6487841 0.001541 0.001541 0.001541 0.6487841 0.001541 0							
265. 40 4.04 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.47 4.06 0.56 0.001786 0.000247 0.001539 0.649857 0.664.71 4.06 0.56 0.001786 0.000246 0.001539 0.649857 0.6714 4.07 0.56 0.001786 0.000246 0.001539 0.649805 0.6714 4.07 0.56 0.001786 0.000246 0.001539 0.649805 0.6726, 0.001786 0.000246 0.001539 0.649805 0.6726, 0.001786 0.000246 0.001540 0.649345 0.6726, 0.001786 0.000246 0.001540 0.649345 0.649345 0.001540 0.001540 0.001540 0.649345 0.001541 0.001540 0.001540 0.649345 0.001541 0.001541 0.649931 0.001541 0.001541 0.001541 0.648931 0.001541 0.001541 0.001541 0.648931 0.001541 0.001541 0.648931 0.001541 0.001541 0.001541 0.648931 0.001541 0.001541 0.001541 0.648858 0.001786 0.000244 0.001541 0.648858 0.001786 0.000244 0.001541 0.648858 0.001786 0.000243 0.001542 0.648588 0.001786 0.000243 0.001542 0.648588 0.001786 0.000243 0.001542 0.648538 0.001786 0.000243 0.001542 0.648338 0.001541 0.056 0.001786 0.000243 0.001542 0.648338 0.001541 0.0							
265.53 4.05 0.56 0.001786 0.000247 0.001539 0.649857 266.40 4.05 0.56 0.001786 0.000247 0.001539 0.649857 267.01 4.05 0.56 0.001786 0.000246 0.001539 0.649857 0.679.01 0.001539 0.649857 0.679.01 0.001539 0.649857 0.679.01 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.649600 0.001539 0.001530 0.00246 0.001530 0.649345 0.001530 0.001530 0.00246 0.001530 0.649345 0.001530 0.00246 0.001530 0.649345 0.001530 0.00245 0.001541 0.649991 0.001541 0.001541 0.649991 0.001541 0.001541 0.649991 0.001541 0.001541 0.649991 0.001541 0.001541 0.649991 0.001541 0.001541 0.049991 0.001541 0.001542 0.001541 0.648938 0.001541 0.055 0.001786 0.000244 0.001542 0.648588 0.001541 0.055 0.001786 0.000244 0.001542 0.648588 0.001541 0.055 0.001786 0.000243 0.001542 0.648588 0.001541 0.055 0.001786 0.000243 0.001542 0.648588 0.001541 0.055 0.001786 0.000243 0.001542 0.648588 0.001541 0.001541 0.001542 0.001542 0.001541 0.648990 0.001541 0.001541 0.001542 0.001542 0.001542 0.001543 0.001544 0.001544 0.001644 0.001544 0.001644 0.001544 0.001644 0.001644 0.001644 0.001644 0.001644 0.001644 0.001644 0.001644 0.00164							
266.40         4.05         0.56         0.001786         0.000247         0.001539         0.649800           266.47         4.06         0.56         0.001786         0.000246         0.001539         0.649800           267.14         4.07         0.56         0.001786         0.000246         0.001539         0.649305           267.81         4.07         0.56         0.001786         0.000246         0.001540         0.649345           267.81         4.08         0.56         0.001786         0.002245         0.001541         0.649345           268.47         4.09         0.56         0.001786         0.002245         0.001541         0.648931           268.47         4.09         0.56         0.001786         0.002244         0.001542         0.648938           269.14         4.10         0.56         0.001786         0.002244         0.001542         0.648588           269.12         4.11         0.56         0.001786         0.002243         0.001542         0.648388           270.00         4.11         0.56         0.001786         0.002243         0.001542         0.648338           270.15         4.12         0.56         0.001786         0.002243							
267.01         4.06         0.56         0.001786         0.000246         0.001539         0.649365           267.14         4.07         0.56         0.001786         0.000246         0.001540         0.649345           267.81         4.08         0.56         0.001786         0.000246         0.001540         0.649345           268.47         4.09         0.56         0.001786         0.002245         0.001541         0.649991           268.47         4.09         0.56         0.001786         0.002244         0.001542         0.648938           269.14         4.10         0.56         0.001786         0.002244         0.001542         0.648588           269.25         4.11         0.56         0.001786         0.002243         0.001542         0.648588           270.00         4.11         0.56         0.001786         0.002243         0.001542         0.648388           270.15         4.12         0.56         0.001786         0.002243         0.001543         0.648938           270.21         4.12         0.56         0.001786         0.002243         0.001544         0.647843           271.14         4.13         0.56         0.01786         0.002242		4.05					
267.14 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.75 4.07 0.56 0.001786 0.000246 0.001540 0.649345 267.81 4.08 0.56 0.001786 0.000245 0.001541 0.649931 268.35 4.08 0.56 0.001786 0.000245 0.001541 0.649991 268.47 4.09 0.56 0.001786 0.000245 0.001541 0.649991 268.65 4.10 0.56 0.001786 0.000244 0.001541 0.648938 269.14 4.10 0.56 0.001786 0.000244 0.001542 0.648588 269.25 4.11 0.56 0.001786 0.000244 0.001542 0.648588 270.00 4.11 0.56 0.001786 0.000244 0.001542 0.648588 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648588 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.21 4.13 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.55 0.001786 0.000242 0.001544 0.647884 271.17 4 0.15 0.001786 0.000242 0.001544 0.647884 271.27 4.1 0.55 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.55 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.55 0.001786 0.000242 0.001544 0.647898 271.80 4.15 0.58 0.001724 0.000242 0.001544 0.647898 271.80 4.15 0.58 0.001724 0.000242 0.001648 0.674934 271.80 4.15 0.58 0.001724 0.000241 0.001643 0.674230 271.80 4.15 0.58 0.001724 0.000241 0.001643 0.674230 271.80 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.18 4.15 0.58 0.001724 0.000241 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000241 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000241 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000239 0.001665 0.673444 274.00 4.18 0.58 0.001724 0.000239 0.001666 0.673244 274.20 0.58 0.001724 0.000239 0.001666 0.673244 274.20 0.58 0.001724 0.000239 0.001666 0.							
267.75 4.07 0.56 0.001786 0.000245 0.001540 0.649991 268.35 4.08 0.56 0.001786 0.000245 0.001541 0.649991 268.47 4.09 0.56 0.001786 0.000245 0.001541 0.649991 268.47 4.09 0.56 0.001786 0.000244 0.001541 0.648983 268.65 4.10 0.56 0.001786 0.000244 0.001542 0.648588 269.12 4.10 0.56 0.001786 0.000244 0.001542 0.648588 269.12 4.11 0.56 0.001786 0.000243 0.001542 0.648588 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648538 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648538 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648538 270.00 4.11 0.56 0.001786 0.000243 0.001543 0.648990 270.31 4.12 0.56 0.001786 0.000243 0.001543 0.648990 270.31 4.13 0.56 0.001786 0.000243 0.001544 0.6487843 271.12 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.17 4.14 0.56 0.001786 0.000242 0.001544 0.647893 271.15 4.14 0.56 0.001786 0.000242 0.001544 0.647893 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647893 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.58 0.001724 0.000242 0.001544 0.647893 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647893 271.36 4.14 0.58 0.001724 0.000242 0.001643 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.13 4 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.02 0.58 0.001724 0.000239 0.001485 0.673344 274.22 0.58 0.001724 0.000239 0.001485 0.673264 274.75 4.20 0.58 0.001724 0.000239 0.00							
267. 81 4.08 0.56 0.001786 0.000245 0.001541 0.649091 268.47 4.09 0.56 0.001786 0.000244 0.001541 0.649091 268.65 4.10 0.56 0.001786 0.000244 0.001541 0.648939 268.65 4.10 0.56 0.001786 0.000244 0.001542 0.648588 269.14 4.10 0.56 0.001786 0.000244 0.001542 0.648588 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648588 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648538 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.14 4.13 0.56 0.001786 0.000242 0.001544 0.647894 271.27 4.14 0.55 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.35 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.80 4.15 0.58 0.001724 0.000242 0.001544 0.647598 271.80 4.15 0.58 0.001724 0.000242 0.001648 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.16 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001484 0.673966 6.74230 272.08 4.15 0.58 0.001724 0.000240 0.001484 0.673966 6.74230 272.08 4.15 0.58 0.001724 0.000240 0.001484 0.673966 6.74230 272.08 4.15 0.58 0.001724 0.000240 0.001484 0.673966 6.74230 272.08 4.15 0.58 0.001724 0.000240 0.001484 0.673966 6.74230 272.08 4.15 0.58 0.001724 0.000240 0.001484 0.673966 6.74230 272.08 4.15 0.58 0.001724 0.000239 0.001485 0.674230 272.08 4.15 0.58 0.001724 0.000239 0.001486 0.673244 0.74204 0.74204 0.000239 0.001486 0.673244 0.74204 0.74204 0.000239 0.001486 0.673244 0.74204 0.74204 0.000239 0.001486 0.673244 0.74204 0.74204 0.000238 0.001487 0.672672 276.53 4.20 0.58 0.001724 0.000239 0.001486 0.673244 0.74205 0.7544 0.000239							
268.35         4.08         0.56         0.001786         0.000245         0.001541         0.648991           268.47         4.09         0.56         0.001786         0.000244         0.001542         0.648839           268.65         4.10         0.56         0.001786         0.000244         0.001542         0.648838           269.12         4.11         0.56         0.001786         0.000243         0.001542         0.648838           270.00         4.11         0.56         0.001786         0.000243         0.001542         0.648388           270.15         4.12         0.56         0.001786         0.000243         0.001543         0.648938           270.21         4.12         0.56         0.001786         0.000243         0.001543         0.648938           271.14         4.13         0.56         0.001786         0.000242         0.001544         0.647843           271.17         4.14         0.56         0.001786         0.000242         0.001544         0.647893           271.50         4.14         0.58         0.001724         0.000242         0.001544         0.647598           271.50         4.14         0.58         0.001724         0.000242							
268.65 47 4.09 0.56 0.001786 0.000244 0.001541 0.648888 269.14 4.10 0.56 0.001786 0.000244 0.001542 0.648888 269.25 4.11 0.56 0.001786 0.000244 0.001542 0.648888 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648838 270.15 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648039 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.12 4.13 0.56 0.001786 0.000242 0.001544 0.647894 271.27 4.14 0.55 0.001786 0.000242 0.001544 0.647893 271.27 4.14 0.55 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.80 4.15 0.58 0.001724 0.000242 0.001544 0.647598 271.80 4.15 0.58 0.001724 0.000242 0.001483 0.674439 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.25 4.16 0.58 0.001724 0.000241 0.001484 0.673966 0.674230 272.25 4.16 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.25 4.16 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000240 0.001484 0.673966 0.674230 272.26 4.15 0.58 0.001724 0.000239 0.001485 0.673444 0.673966 0.674230 0.000440 0.001484 0.673966 0.674230 0.000440 0.001484 0.673966 0.674230 0.000440 0.000484 0.673966 0.674230 0.000480 0.000480 0.673244 0.000239 0.001485 0.673444 0.673966 0.000480 0.000480 0.673244 0.000239 0.000486 0.673244 0.000239 0.000486 0.673							
269,14 4.10 0.56 0.001786 0.000244 0.001542 0.648388 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648338 270.015 4.12 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648390 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.56 0.001786 0.000243 0.001543 0.648090 270.34 4.13 0.56 0.001786 0.000242 0.001544 0.647894 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647894 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.50 4.15 0.58 0.001724 0.000242 0.001544 0.647598 271.80 4.15 0.58 0.001724 0.000242 0.001483 0.674494 271.86 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001484 0.673966 272.10 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.10 4.18 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.19 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.19 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.19 0.58 0.001724 0.000239 0.001485 0.673346 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001486 0.673282 275.55 4.20 0.58 0.001724 0.000239 0.001486 0.673282 275.55 4.20 0.58 0.001724 0.000239 0.001486 0.673282 275.55 4.20 0.58 0.001724 0.000239 0.001486 0.673282 275.55 4.20 0.58 0.001724 0.000239 0.001486 0.673284 274.20 0.58 0.001724 0.000239 0.001486 0.673284 274.25 0.58 0.001724 0.000239 0.001486 0.673284 275.65 4.21 0.58 0.001724 0.000239 0.001486 0.673284 275.65 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.65 4.22 0.58 0.001724 0.000239 0.0014							
269,25 4.11 0.56 0.001786 0.000243 0.001542 0.648338 270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648338 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648890 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648890 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648890 270.23 4 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.12 7 4.14 0.56 0.001786 0.000242 0.001544 0.647893 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 0.414 0.58 0.001742 0.000242 0.001544 0.647598 271.35 0.414 0.58 0.001724 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001543 0.67494 271.80 4.15 0.58 0.001724 0.000242 0.001643 0.67494 271.80 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.91 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.18 0.58 0.001724 0.000240 0.001484 0.673966 272.74 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.20 0.58 0.001724 0.000239 0.001485 0.673344 274.22 0.58 0.001724 0.000239 0.001485 0.673344 274.23 0.59 0.058 0.001724 0.000239 0.001485 0.673344 274.23 0.59 0.001248 0.000239 0.001485 0.673262 276.65 4.20 0.58 0.001724 0.000239 0.001485 0.673262 276.65 4.20 0.58 0.001724 0.000239 0.001485 0.673262 276.65 4.20 0.58 0.001724 0.000239 0.001485 0.673262 276.65 4.20 0.58 0.001724 0.000239 0.001485 0.673262 276.65 4.20 0.58 0.001724 0.000239 0.001485 0.673262 276.65 4.20 0.58 0.001724 0.000239 0.00148							
270.00 4.11 0.56 0.001786 0.000243 0.001542 0.648398 270.15 4.12 0.56 0.001786 0.000243 0.001543 0.6488990 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.6488990 270.34 4.13 0.56 0.001786 0.000243 0.001543 0.6488990 270.34 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.127 4.14 0.56 0.001786 0.000242 0.001544 0.647894 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.50 4.15 0.58 0.001724 0.000242 0.001643 0.674494 271.80 4.15 0.58 0.001724 0.000242 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.108 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.208 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.216 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.218 4.16 0.58 0.001724 0.000241 0.001483 0.674230 272.218 4.16 0.58 0.001724 0.000241 0.001483 0.674230 272.218 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.18 4.17 0.58 0.001724 0.000240 0.001484 0.673966 0.673968 0.001724 0.000240 0.001484 0.673966 0.673908 0.001724 0.000240 0.001484 0.673966 0.74230 272.19 4.19 0.58 0.001724 0.000240 0.001484 0.673966 0.74230 0.000241 0.001483 0.674230 0.74230 0.000241 0.001483 0.674230 0.74230 0.000241 0.001483 0.674230 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.001484 0.673966 0.74230 0.000240 0.000485 0.673282 0.744.20 0.58 0.000724 0.000238 0.001486 0.673282 0.744.20 0.58 0.000724 0.000238 0.001486 0.673282 0.744.20 0.58 0.000724 0.000238 0.001486 0.673282 0.744.20 0.58 0.000724 0.000238 0.001486 0.673282 0.75569 0.000260 0.000480 0.672282 0.75569 0.000260 0.000480 0.672282 0.000260 0.000480 0.672248 0.000239 0.000486 0.672282 0.000260 0.							
270.15 4.12 0.56 0.001786 0.000243 0.001543 0.648890 270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648890 270.34 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.12 4.14 0.56 0.001786 0.000242 0.001544 0.647843 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 0.414 0.58 0.001742 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001543 0.674949 471.80 4.15 0.58 0.001724 0.000242 0.001643 0.67494 271.80 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673965 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673965 273.345 4.17 0.58 0.001724 0.000240 0.001484 0.673965 273.45 4.18 0.58 0.001724 0.000240 0.001484 0.673965 273.45 4.18 0.58 0.001724 0.000240 0.001484 0.673965 273.45 4.19 0.58 0.001724 0.000240 0.001484 0.673965 273.45 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.20 0.19 0.58 0.001724 0.000239 0.001485 0.673444 274.20 0.58 0.001724 0.000239 0.001485 0.673444 274.20 0.58 0.001724 0.000239 0.001485 0.673386 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673386 274.65 4.20 0.58 0.001724 0.000239 0.001485 0.673242 275.56 4.21 0.58 0.001724 0.000239 0.001485 0.673262 275.56 4.21 0.58 0.001724 0.000239 0.001485 0.673262 275.69 4.21 0.58 0.001724 0.000239 0.001485 0.673264 274.73 4.23 0.58 0.001724 0.000239 0.001485 0.673264 274.73 4.23 0.58 0.001724 0.000239 0.001485 0.673264 275.645 4.21 0.58 0.001724 0.000239 0.001485 0.673264 275.645 4.21 0.58 0.001724 0.000239 0.001485 0.673264 275.645 4.21 0.58 0.001724 0.000239 0.0							
270.21 4.12 0.56 0.001786 0.000243 0.001543 0.648890 270.34 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.17 4.13 0.56 0.001786 0.000242 0.001544 0.647843 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001544 0.647598 271.50 4.15 0.58 0.001724 0.000242 0.001543 0.674494 271.80 4.15 0.58 0.001724 0.000242 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.210 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.210 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.210 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.213 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 0.73305 272.34 4.18 0.58 0.001724 0.000240 0.001484 0.673966 0.73305 272.49 4.18 0.58 0.001724 0.000240 0.001485 0.673305 272.49 4.18 0.58 0.001724 0.000240 0.001485 0.673305 272.49 4.18 0.58 0.001724 0.000240 0.001485 0.673305 272.49 4.18 0.58 0.001724 0.000239 0.001485 0.673305 274.45 4.18 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673282 275.55 4.20 0.58 0.001724 0.000239 0.001486 0.672928 275.56 4.21 0.58 0.001724 0.000239 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.21 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.21 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.21 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000239 0.001487 0.672672 277.16 4.23							
271.14 4.13 0.56 0.001786 0.000242 0.001544 0.647898 271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647898 271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001543 0.674494 271.68 4.14 0.58 0.001724 0.000242 0.001643 0.674494 271.80 4.15 0.58 0.001724 0.000241 0.001643 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001643 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.98 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.98 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.15 4.16 0.58 0.001724 0.000241 0.001643 0.674230 272.17 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.78 4.16 0.58 0.001724 0.000240 0.001648 0.673966 0.72288 4.17 0.58 0.001724 0.000240 0.001648 0.673966 0.72288 4.17 0.58 0.001724 0.000240 0.001648 0.673966 0.72328 4.17 0.58 0.001724 0.000240 0.001648 0.673966 0.72328 0.001648 0.000240 0.001648 0.673966 0.72328 0.001724 0.000240 0.001648 0.673966 0.73366 0.001724 0.000239 0.001648 0.673966 0.73366 0.001724 0.000239 0.001648 0.673968 0.744230 0.74420 0.000240 0.001648 0.673968 0.744230 0.74420 0.000240 0.001648 0.673966 0.74230 0.001648 0.74230 0.000240 0.001648 0.673966 0.74262 0.74420 0.000239 0.001648 0.673968 0.744230 0.000239 0.001648 0.673968 0.744230 0.000239 0.001648 0.673986 0.74262 0.74655 0.001724 0.000239 0.001648 0.673986 0.673282 0.74655 0.001724 0.000239 0.001648 0.672928 0.74655 0.001724 0.000239 0.001648 0.672672 0.76645 0.000230 0.001648 0.672672 0.76645 0.000230 0.001648 0.672672 0.76645 0.000230 0.001648 0.672672 0.76645 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.776645 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672672 0.77664 0.000230 0.001648 0.672664 0.000230 0.001648 0.672672 0.000230 0.001648 0.672664							
271.27 4.14 0.56 0.001786 0.000242 0.001544 0.647598 271.35 4.14 0.58 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001643 0.6749494 271.80 4.15 0.58 0.001724 0.000242 0.001643 0.674494 271.80 4.15 0.58 0.001724 0.000241 0.001643 0.674494 271.81 4.15 0.58 0.001724 0.000241 0.001643 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001643 0.674230 272.13 4.16 0.58 0.001724 0.000241 0.001643 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001648 0.673966 272.78 4.17 0.58 0.001724 0.000240 0.001648 0.673966 272.78 8.17 0.58 0.001724 0.000240 0.001648 0.673965 273.45 4.17 0.58 0.001724 0.000240 0.001648 0.673965 273.45 4.17 0.58 0.001724 0.000240 0.001648 0.673705 273.45 4.19 0.58 0.001724 0.000239 0.001685 0.673464 274.20 4.19 0.58 0.001724 0.000239 0.001685 0.673364 274.20 0.58 0.001724 0.000239 0.001685 0.673364 274.52 4.20 0.58 0.001724 0.000239 0.001685 0.673366 275.69 4.20 0.58 0.001724 0.000239 0.001685 0.673262 275.69 4.21 0.58 0.001724 0.000239 0.001685 0.673262 275.69 4.21 0.58 0.001724 0.000239 0.001685 0.673262 275.69 4.21 0.58 0.001724 0.000239 0.001685 0.673262 275.69 4.21 0.58 0.001724 0.000239 0.001685 0.673262 275.69 4.21 0.58 0.001724 0.000238 0.001686 0.672928 275.69 4.21 0.58 0.001724 0.000237 0.001687 0.672672 276.45 4.21 0.58 0.001724 0.000237 0.001687 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001687 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001686 0.672928 277.16 4.23 0.59 0.001724 0.000237 0.001687 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001687 0.672672 276.45 4.23 0.59 0.001724 0.000237 0.001687 0.672672 276.45 4.23 0.59 0.001724 0.000237 0.001687 0.672672 276.45 4.23 0.59 0.001724 0.000237 0.001687 0.672672 276.45 0.56 0.001724 0.000237 0.001687 0.672672 276.45 0.672672 0.58600000000000000000000000000000000000	270.34	4.13	0.56	0.001786	0.000242	0.001544	0.647843
271.35 4.14 0.56 0.001786 0.000242 0.001544 0.647598 271.50 4.14 0.58 0.001724 0.000242 0.001683 0.674494 271.68 4.14 0.58 0.001724 0.000242 0.001683 0.674494 271.80 4.15 0.58 0.001724 0.000241 0.001683 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001683 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001683 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001683 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001683 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001683 0.674230 272.15 4.16 0.58 0.001724 0.000241 0.001683 0.674230 272.25 4.16 0.58 0.001724 0.000240 0.001684 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001684 0.673966 272.78 4.16 0.58 0.001724 0.000240 0.001684 0.673966 272.78 4.18 0.58 0.001724 0.000240 0.001684 0.673965 273.45 4.17 0.58 0.001724 0.000240 0.001684 0.673965 0.73345 0.001724 0.000240 0.001684 0.673965 0.73345 0.001724 0.000239 0.001685 0.673464 274.20 0.19 0.58 0.001724 0.000239 0.001685 0.673464 0.742.20 0.58 0.001724 0.000239 0.001685 0.673186 0.742.20 0.58 0.001724 0.000239 0.001685 0.673186 0.74725 0.000239 0.001685 0.673282 0.747.75 4.20 0.58 0.001724 0.000239 0.001685 0.673282 0.747.75 4.21 0.58 0.001724 0.000239 0.001685 0.673282 0.747.75 4.21 0.58 0.001724 0.000239 0.001685 0.673282 0.747.75 4.22 0.58 0.001724 0.000239 0.001685 0.673282 0.747.75 4.22 0.58 0.001724 0.000239 0.001685 0.673282 0.756.645 4.21 0.58 0.001724 0.000238 0.001687 0.672672 0.766.45 4.22 0.58 0.001724 0.000238 0.001687 0.672672 0.776.44 0.22 0.58 0.001724 0.000238 0.001687 0.672672 0.776.45 4.22 0.58 0.001724 0.000237 0.001687 0.672672 0.776.45 4.22 0.58 0.001724 0.000238 0.001687 0.672672 0.776.45 4.22 0.58 0.001724 0.000238 0.001687 0.672672 0.776.45 4.23 0.58 0.001724 0.000238 0.001687 0.672672 0.776.45 4.23 0.58 0.001724 0.000238 0.001687 0.672672 0.776.45 4.23 0.58 0.001724 0.000238 0.001687 0.672672 0.776.45 4.23 0.58 0.001724 0.000238 0.001688 0.672164 0.777.55 4.23 0.59 0.001628 0.000238 0.001688 0.672164 0.777.55 4.23 0.59 0.001628 0.000238 0.001688 0.672164 0.777.55 4.23 0.59 0.001628 0.000238 0.							
271.50 4.14 0.58 0.001724 0.000242 0.001483 0.674494 271.68 4.15 0.58 0.001724 0.000242 0.001483 0.674494 271.80 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.28 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.45 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.08 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673344 274.20 0.58 0.001724 0.000239 0.001485 0.673346 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673386 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673282 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 276.45 4.23 0.59 0.001724 0.000238 0.001487 0.672672 277.16 4.23 0.58 0.001724 0.000238 0.001488 0.672164 277.14 4.23 0.58 0.001724 0.000237 0.001487 0.672618 277.14 4.23 0.58 0.001724 0.000238 0.001489 0.6726164 277.14 4.23 0.58 0.001724 0.000238 0.001489 0.672164 277.15 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.15 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.15 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.15 4.23 0.59 0.001629 0.000238 0							
271.68 4.14 0.58 0.001724 0.000242 0.001483 0.674494 271.80 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.96 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.48 4.18 0.58 0.001724 0.000240 0.001484 0.673966 272.48 4.18 0.58 0.001724 0.000240 0.001484 0.673965 0.73345 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.55 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.55 4.20 0.58 0.001724 0.000239 0.001485 0.673186 274.55 4.20 0.58 0.001724 0.000239 0.001485 0.673186 274.55 4.20 0.58 0.001724 0.000239 0.001485 0.673282 275.59 4.20 0.58 0.001724 0.000239 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672672 277.14 4.23 0.58 0.001724 0.000237 0.001487 0.672672 277.14 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.55 0.58 0.001724 0.000237 0.001487 0.672618 277.15 0.58 0.001724 0.000236 0.001488 0.672164 277.55 0.001724 0.000237 0.001487 0.672618 277.15 0.58 0.001724 0.000237 0.001487 0.672618 277.16 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.55 0							
271.80 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.08 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.78 4.17 0.58 0.001724 0.000240 0.001484 0.673965 273.48 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.48 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.48 4.18 0.58 0.001724 0.000240 0.001484 0.673705 6.73444 274.08 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.20 0.58 0.001724 0.000239 0.001485 0.673386 274.55 4.20 0.58 0.001724 0.000239 0.001485 0.673386 274.55 4.20 0.58 0.001724 0.000239 0.001485 0.673282 275.55 4.20 0.58 0.001724 0.000239 0.001485 0.673282 275.569 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 277.16 4.23 0.58 0.001724 0.000236 0.001487 0.672672 277.14 4.23 0.58 0.001724 0.000236 0.001489 0.672164 277.14 4.23 0.58 0.001724 0.000236 0.001489 0.672164 277.14 4.23 0.58 0.001724 0.000236 0.001489 0.672164 277.15 4.23 0.59 0.001629 0.000236 0.001489 0.672164 277.55 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.001680 0.001680 0.001680 0.672164 0.000237 0.001487 0.672618 0.001680 0.001680 0.672164 0.000237 0.001487 0.672618 0.001680 0.001680 0.672164 0.000237 0.001487 0.672618 0.001680 0.001680 0.672164 0.000237 0.001680 0.672164 0.000237 0.001680 0.672164 0.000237 0.001680 0.672164 0.000237 0.0							
271.81 4.15 0.58 0.001724 0.000241 0.001483 0.674230 271.95 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 273.28 4.17 0.58 0.001724 0.000240 0.001484 0.673965 273.28 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.28 4.18 0.58 0.001724 0.000240 0.001484 0.673705 273.28 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.00 4.18 0.58 0.001724 0.000239 0.001485 0.673444 0.74 0.74 0.74 0.74 0.74 0.74 0.74 0							
272.08 4.15 0.58 0.001724 0.000241 0.00183 0.674230 272.10 4.15 0.58 0.001724 0.000241 0.00183 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.89 4.18 0.58 0.001724 0.000240 0.001484 0.673965 0.733.28 4.17 0.58 0.001724 0.000240 0.001484 0.673705 0.734.69 4.18 0.58 0.001724 0.000239 0.001485 0.673444 0.74 0.000239 0.001485 0.673444 0.74 0.000239 0.001485 0.673444 0.74 0.000239 0.001485 0.673186 0.74 0.74 0.000239 0.001485 0.673186 0.74 0.74 0.000239 0.001485 0.673186 0.74 0.74 0.000239 0.001485 0.673186 0.74 0.000239 0.001485 0.673186 0.74 0.74 0.000239 0.001485 0.673186 0.74 0.000239 0.001485 0.672928 0.74 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.001487 0.672672 0.75 0.000239 0.000248 0.672164 0.77 0.74 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000487 0.672672 0.75 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.77 0.000239 0.000489 0.672164 0.000239 0.000489 0.000489 0.672164 0.000239 0.000489 0.000489 0.672164 0.000239 0.000489 0.000489 0.672164 0.000239 0	271.81	4.15	0.58	0.001724		0.001483	0.674230
272.10 4.15 0.58 0.001724 0.000241 0.001483 0.674230 272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.75 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.42 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.45 4.18 0.58 0.001724 0.000240 0.001484 0.673705 0.734.45 0.734.50 0.001485 0.673444 0.00239 0.001485 0.673444 0.74.20 0.19 0.58 0.001724 0.000239 0.001485 0.673444 0.74.20 0.19 0.58 0.001724 0.000239 0.001485 0.673186 0.74.45 0.000239 0.001485 0.673186 0.74.15 0.000239 0.001485 0.673186 0.74.75 0.000238 0.001486 0.672928 0.74.75 0.000238 0.001486 0.672928 0.75.59 0.001724 0.000238 0.001486 0.672928 0.75.69 0.000238 0.001486 0.672928 0.75.69 0.000238 0.001487 0.672672 0.76.45 0.20 0.58 0.001724 0.000238 0.001487 0.672672 0.76.45 0.20 0.58 0.001724 0.000238 0.001487 0.672672 0.76.45 0.20 0.58 0.001724 0.000238 0.001487 0.672672 0.76.45 0.20 0.58 0.001724 0.000238 0.001487 0.672672 0.76.45 0.20 0.58 0.001724 0.000237 0.001487 0.672672 0.77.16 0.20 0.58 0.001724 0.000237 0.001487 0.672672 0.77.16 0.20 0.58 0.001724 0.000237 0.001487 0.672618 0.77.16 0.72 0.000238 0.001487 0.672618 0.77.16 0.20 0.000238 0.001488 0.672164 0.77.14 0.20 0.58 0.001724 0.000237 0.001487 0.672618 0.77.16 0.77 0.000238 0.001487 0.672618 0.77.16 0.77 0.000238 0.001489 0.672164 0.77.14 0.20 0.000237 0.001487 0.672618 0.77.16 0.000238 0.001489 0.672164 0.77.14 0.000238 0.001489 0.672164 0.77.14 0.000238 0.001489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.77.15 0.000238 0.000489 0.672164 0.000238 0.000489 0.000489 0.672164 0.000238 0.000489 0.000489 0.672164 0.000							
272.35 4.16 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673965 273.28 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.45 4.18 0.58 0.001724 0.000240 0.001485 0.673444 274.02 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673186 0.744.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 0.774.65 4.20 0.58 0.001724 0.000239 0.001485 0.672928 275.55 4.20 0.58 0.001724 0.000239 0.001485 0.672928 275.59 4.21 0.58 0.001724 0.000239 0.001485 0.672928 275.69 4.21 0.58 0.001724 0.000239 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672672 277.14 4.23 0.58 0.001724 0.000237 0.001487 0.672672 277.14 4.23 0.58 0.001724 0.000237 0.001487 0.672618 277.14 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.59 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001488 0.672164 277.55 0.423 0.59 0.001629 0.000236 0.001488 0.672164 277.55 0.58 0.58 0.001724 0.000236 0.001488 0.672164 277.55 0.58 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.58 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.58 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.58 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.58 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.58 0.001724 0.000236 0.001489 0.672164 277.55 0.001648 0.672164 277.55 0.001648 0.672164 277.55 0.001648 0.000236 0.001489 0.685268 0.685268 0.001724 0.000236 0.001489 0.685268 0.685268 0.001724 0.000236 0.001489 0.685268 0.685268 0.001724 0.000236 0.001489 0.685268 0.001726 0.000268 0.001489 0.685268 0.001726 0.000268 0.001489 0.685268 0.001726 0.000268 0.001489 0.685268 0.001726 0.000268 0							
272.75 4.16 0.58 0.001724 0.000240 0.001484 0.6737966 272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.45 4.18 0.58 0.001724 0.000240 0.001484 0.673705 273.45 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673444 0.74.20 0.19 0.58 0.001724 0.000239 0.001485 0.673484 0.74.25 0.000239 0.001485 0.673346 0.74.25 0.000239 0.001485 0.673186 0.74.75 0.000239 0.001485 0.673186 0.74.75 0.000239 0.001485 0.673286 0.74.75 0.000239 0.001485 0.673286 0.74.75 0.000238 0.001486 0.672928 0.75.59 0.000240 0.000238 0.001486 0.672928 0.75.69 0.000238 0.001487 0.672672 0.76.45 0.000238 0.001487 0.672672 0.76.45 0.000238 0.000487 0.672672 0.76.45 0.000238 0.000487 0.672672 0.76.45 0.000238 0.000487 0.672672 0.77.16 0.42 0.000237 0.000487 0.672672 0.77.16 0.42 0.000237 0.000487 0.672618 0.77.16 0.000238 0.001487 0.672618 0.77.16 0.000238 0.001487 0.672618 0.77.16 0.000238 0.001487 0.672618 0.77.16 0.000238 0.001487 0.672618 0.77.16 0.000238 0.001487 0.672618 0.77.16 0.000238 0.001489 0.672164 0.77.14 0.000238 0.001489 0.672164 0.77.14 0.23 0.58 0.001724 0.000236 0.001488 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.672164 0.77.55 0.000238 0.000489 0.685639 0.000489 0.000489 0.000489 0.685639 0.000489 0.000489 0.000489 0.685639 0.00048							
272.88 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.28 4.17 0.58 0.001724 0.000240 0.001484 0.673705 273.45 4.18 0.58 0.001724 0.000249 0.001485 0.673444 274.02 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673444 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.20 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.63 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000238 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.55 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.55 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.55 4.23 0.59 0.001629 0.000238 0.001489 0.672164 277.55 0.58 0.58 0.001724 0.000238 0.001489 0.672164 277.55 0.58 0.001724 0.000238 0.001489 0.672164 277.55 0.001629 0.000248 0.000248 0.672164 277.55 0.000248 0.000248 0.000248 0.000248 0.672164							
273.45 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.18 0.58 0.001724 0.000239 0.001485 0.673444 274.02 4.19 0.58 0.001724 0.000239 0.001485 0.673486 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.20 0.58 0.001724 0.000239 0.001485 0.673186 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.14 4.23 0.58 0.001724 0.000237 0.001487 0.672612 277.15 4.23 0.59 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001488 0.672164							
274.08 4.18 0.58 0.001724 0.000239 0.001485 0.673144 277.55 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.75 4.20 0.58 0.001724 0.000238 0.001486 0.673292 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.15 4.23 0.59 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.59 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001489 0.672164				0.001724	0.000240	0.001484	0.673705
274.20 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.75 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.36 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.15 4.23 0.59 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001488 0.672164							
274.65 4.19 0.58 0.001724 0.000239 0.001485 0.673186 274.75 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.36 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672618 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.15 4.23 0.59 0.001248 0.000236 0.001488 0.672164 277.43 4.23 0.59 0.001249 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001489 0.672164							
274.75 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.36 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 275.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.15 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001689 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.00169 0.000236 0.001489 0.687636							
275.55 4.20 0.58 0.001724 0.000238 0.001486 0.672928 275.69 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.36 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.15 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.59 0.001629 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.001629 0.000236 0.001489 0.687639 0.00169 0.000259 0.000259 0.688639							
276.45 4.21 0.58 0.001724 0.000238 0.001487 0.672672 276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 276.48 4.23 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.00169 0.000236 0.001489 0.672164 0.000236 0.001459 0.685632							
276.45 4.22 0.58 0.001724 0.000237 0.001487 0.672418 276.89 4.22 0.58 0.001724 0.000237 0.001487 0.672418 277.16 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.55 4.23 0.59 0.00169 0.000236 0.001489 0.687532 0.001459 0.688532							
276.89         4.22         0.58         0.001724         0.000237         0.001487         0.672418           277.16         4.23         0.58         0.001724         0.000236         0.001488         0.672164           277.43         4.23         0.58         0.001724         0.000236         0.001488         0.672164           277.55         4.23         0.58         0.001729         0.000236         0.001489         0.685632							
277.16 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.43 4.23 0.59 0.001695 0.000236 0.001489 0.685632							
277.43 4.23 0.58 0.001724 0.000236 0.001488 0.672164 277.56 4.23 0.59 0.001695 0.000236 0.001459 0.685632							
277.56 4.23 0.59 0.001695 0.000236 0.001459 0.685632							
277.64 4.23 0.59 0.001695 0.000236 0.001459 0.685632	277.56	4.23	0.59	0.001695	0.000236	0.001459	0.685632
	277.64	4.23	0.59	0.001695	0.000236	0.001459	0.685632

Temp	$T_2$	$T_2^*$	1/T2*	$1/T_2$	$y=1/T_2^{\bullet}-1/T_2$	1/y
277.83	4.24	0.59	0.001695	0.000236	0.001459	0.685370
278.10	4.24	0.59	0.001695	0.000236	0.001459	0.685370
278.23	4.25	0.59	0.001695	0.000235	0.001460	0.685109
278.90	4.25	0.59	0.001695	0.000235	0.001460	0.685109
279.00	4.26	0.59	0.001695	0.000235	0.001460	0.684850
279.59	4.26	0.59	0.001695	0.000235	0.001460	0.684850
279.70	4.27	0.59	0.001695	0.000234	0.001461	0.684592
280.35	4.27	0.59	0.001695	0.000234	0.001461	0.684592
280.50	4.28	0.59	0.001695	0.000234	0.001461	0.684336
281.10 281.17	4.28	0.59	0.001695	0.000234	0.001461	0.684081
281.44	4.29	0.59	0.001695	0.000233	0.001462	0.684081
281.54	4.30	0.59	0.001695	0.000233	0.001462	0.683827
282.14	4.30	0.59	0.001695	0.000233	0.001462	0.683827
282.30	4.31	0.59	0.001695	0.000232	0.001463	0.683575
282.91	4.31	0.59	0.001695	0.000232	0.001463	0.683575
283.05	4.32	0.59	0.001695	0.000231	0.001463	0.683324
283.72	4.32	0.59	0.001695	0.000231	0.001463	0.683324
283.80	4.33	0.59	0.001695	0.000231	0.001464	0.683075
283.85	4.33	0.59	0.001695	0.000231	0.001464	0.683075
283.98 284.55	4.34	0.59	0.001695 0.001695	0.000230	0.001465	0.682827
284.65	4.35	0.59	0.001695	0.000230	0.001465	0.682580
285.30	4.35	0.59	0.001695	0.000230	0.001465	0.682580
285.45	4.36	0.59	0.001695	0.000229	0.001466	0.682334
285.85	4.36	0.59	0.001695	0.000229	0.001466	0.682334
286.05	4.37	0.60	0.001667	0.000229	0.001438	0.695491
286.25	4.37	0.60	0.001667	0.000229	0.001438	0.695491
286.35	4.38	0.60	0.001667	0.000228	0.001438	0.695238
287.11	4.38	0.60	0.001667	0.000228	0.001438	0.695238
287.19	4.39	0.60	0.001667	0.000228	0.001439	0.694987
287.59	4.39	0.60	0.001667	0.000228	0.001439	0.694737
287.71 288.26	4.40	0.60	0.001667	0.000227	0.001439	0.694737
288.39	4.41	0.60	0.001667	0.000227	0.001440	0.694488
288.60	4.41	0.60	0.001667	0.000227	0.001440	0.694488
288.79	4.42	0.60	0.001667	0.000226	0.001440	0.694241
289.46	4.42	0.60	0.001667	0.000226	0.001440	0.694241
289.66	4.43	0.60	0.001667	0.000226	0.001441	0.693995
290.41	4.43	0.60	0.001667	0.000226	0.001441	0.693995
290.66	4.44	0.60	0.001667	0.000225	0.001441	0.693750
290.86	4.44	0.60	0.001667	0.000225	0.001441	0.693750
291.07	4.45	0.60	0.001667	0.000225	0.001442	0.693506
291.47 291.60	4.45	0.60	0.001667	0.000223	0.001442	0.693264
292.07	4.46	0.60	0.001667	0.000224	0.001442	0.693264
292.14	4.47	0.60	0.001667	0.000224	0.001443	0.693023
292.68	4.47	0.60	0.001667	0.000224	0.001443	0.693023
292.81	4.48	0.60	0.001667	0.000223	0.001443	0.692784
293.27	4.48	0.60	0.001667	0.000223	0.001443	0.692784
293.57	4.49	0.60	0.001667	0.000223	0.001444	0.692545
294.42	4.49	0.60	0.001667	0.000223	0.001444	0.692545
294.63	4.50	0.60	0.001667	0.000222	0.001444	0.692308
294.78	4.50	0.60	0.001667	0.000222	0.001444	0.705656
294.82	4.50	0.61	0.001639	0.000222	0.001391	0.719072
295.23	4.50	0.62	0.001613	0.000222	0.001391	0.719072
295.49	4.51	0.62	0.001613	0.000222	0.001391	0.718817
295.76	4.51	0.62	0.001613	0.000222	0.001391	0.718817
295.83	4.52	0.62	0.001613	0.000221	0.001392	0.718564
296.43	4.52	0.62	0.001613	0.000221	0.001392	0.718564
296.70	4.53	0.62	0.001613	0.000221	0.001392	0.718312
296.97	4.53	0.62	0.001613	0.000221	0.001392	0.718312

Temp	$T_2$	$T_2^*$	$1/T_2^*$	1/T2	$y=1/T_2^*-1/T_2$	1/y
297.18	4.54	0.62	0.001613	0.000220	0.001393	0.718061
297.79	4.54	0.62	0.001613	0.000220	0.001393	0.718061
297.90	4.55	0.62	0.001613	0.000220	0.001393	0.717812
298.30	4.55	0.62	0.001613	0.000220	0.001393	0.717812
298.54	4.56	0.62	0.001613	0.000219	0.001394	0.717563
298.57	4.56	0.62	0.001613	0.000219	0.001394	0.717563
298.69	4.56	0.62	0.001613	0.000219	0.001394	0.717563 0.717563
298.84 298.84	4.56	0.62	0.001613	0.000219	0.001394	0.717563
298.97	4.57	0.62	0.001613	0.000219	0.001394	0.717316
299.14	4.57	0.62	0.001613	0.000219	0.001394	0.717316
299.37	4.58	0.62	0.001613	0.000218	0.001395	0.717071
299.78	4.58	0.62	0.001613	0.000218	0.001395	0.717071
299.90	4.59	0.62	0.001613	0.000218	0.001395	0.716826
300.44	4.59	0.62	0.001613	0.000218	0.001395	0.716826
300.71	4.60	0.62	0.001613	0.000217	0.001396	0.716583
300.84	4.61	0.62	0.001613	0.000217	0.001396	0.716341
301.51 301.64	4.61	0.62	0.001613	0.000217	0.001396	0.716100
301.04	4.62	0.62	0.001613	0.000216	0.001396	0.716100
302.05	4.63	0.62	0.001613	0.000216	0.001397	0.715860
302.31	4.63	0.62	0.001613	0.000216	0.001397	0.715860
302.44	4.64	0.62	0.001613	0.000216	0.001397	0.715622
302.71	4.64	0.62	0.001613	0.000216	0.001397	0.715622
302.98	4.65	0.62	0.001613	0.000215	0.001398	0.715385
303.38	4.65	0.62	0.001613	0.000215	0.001398	0.715385
303.51	4.66	0.62	0.001613	0.000215	0.001398	0.714914
303.78 304.32	4.67	0.62	0.001613	0.000214	0.001399	0.714914
304.45	4.68	0.62	0.001613	0.000214	0.001399	0.714680
304.58	4.68	0.62	0.001613	0.000214	0.001399	0.714680
304.85	4.69	0.62	0.001613	0.000213	0.001399	0.714563
305.12	4.69	0.62	0.001613	0.000213	0.001400	0.714447
305.25	4.70	0.62	0.001613	0.000213	0.001400	0.714216
305.65 305.92	4.71	0.62	0.001613	0.000213	0.001401	0.713985
306.05	4.71	0.62	0.001613	0.000212	0.001401	0.713985
306.32	4.72	0.62	0.001613	0.000212	0.001401	0.713756
306.59	4.72	0.62	0.001613	0.000212	0.001401	0.713756
306.85	4.73	0.62	0.001613	0.000211	0.001401	0.713528
307.39	4.73	0.62	0.001613	0.000211	0.001401	0.713528
307.66	4.74	0.62	0.001613	0.000211	0.001402	0.713301
307.92 308.46	4.75	0.63	0.001587 0.001587	0.000211	0.001377	0.726335
308.59	4.76	0.63	0.001587	0.000211	0.001377	0.726102
309.00	4.76	0.63	0.001587	0.000210	0.001377	0.726102
309.13	4.77	0.63	0.001587	0.000210	0.001378	0.725870
309.40	4.77	0.63	0.001587	0.000210	0.001378	0.725870
309.53	4.78	0.63	0.001587	0.000209	0.001378	0.725639
309.80	4.78	0.63	0.001587	0.000209	0.001378	0.725639
309.93 310.60	4.79	0.63	0.001587 0.001587	0.000209	0.001378	0.725523
310.73	4.80	0.63	0.001587	0.000208	0.001379	0.725180
311.28	4.80	0.63	0.001587	0.000208	0.001379	0.725180
311.67	4.81	0.63	0.001587	0.000208	0.001379	0.724952
312.21	4.81	0.63	0.001587	0.000208	0.001379	0.724952
312.34	4.82	0.63	0.001587	0.000207	0.001380	0.724726
312.61	4.83	0.63	0.001587	0.000207	0.001380	0.724500
313.42 313.69	4.83	0.63	0.001587 0.001587	0.000207	0.001380	0.724300
313.96	4.84	0.63	0.001587	0.000207	0.001381	0.724276
314.22	4.85	0.63	0.001587	0.000206	0.001381	0.724052
314.77	4.85	0.63	0.001587	0.000206	0.001381	0.724052

Temp	$T_2$	$T_2^{\bullet}$	1/T2*	1/T2	$y=1/T_2^*-1/T_2$	1/y
315.03	4.86	0.63	0.001587	0.000206	0.001382	0.723830
315.97	4.86	0.63	0.001587	0.000206	0.001382	0.723830
316.24	4.87	0.63	0.001587	0.000205	0.001382	0.723608
316.51	4.87	0.63	0.001587	0.000205	0.001382	0.723608
316.64 317.18	4.88	0.63	0.001587 0.001587	0.000205	0.001382	0.723388
317.45	4.89	0.63	0.001587	0.000204	0.001383	0.723169
318.12	4.89	0.63	0.001587	0.000204	0.001383	0.723169
318.39	4.90	0.63	0.001587	0.000204	0.001383	0.722951
319.06 319.19	4.90	0.63	0.001587 0.001587	0.000204	0.001383	0.722951
319.74	4.91	0.63	0.001587	0.000204	0.001384	0.722734
319.87	4.92	0.63	0.001587	0.000203	0.001384	0.722517
320.14	4.92	0.63	0.001587	0.000203	0.001384	0.722517
320.27	4.93	0.63	0.001587	0.000203	0.001384	0.722302
321.62 321.75	4.93	0.63	0.001587 0.001587	0.000203	0.001384	0.722088
322.29	4.94	0.63	0.001587	0.000202	0.001385	0.722088
322.42	4.95	0.63	0.001587	0.000202	0.001385	0.721875
322.69	4.95	0.63	0.001587	0.000202	0.001385	0.721875
322.83 322.96	4.95	0.63	0.001587	0.000202	0.001385	0.721875
323.23	4.95	0.63	0.001587	0.000202	0.001385	0.721875
323.37	4.95	0.63	0.001587	0.000202	0.001385	0.721875
323.64	4.95	0.63	0.001587	0.000202	0.001385	0.721875
323.91 324.04	4.95	0.63	0.001587	0.000202	0.001385	0.721875
325.66	4.96	0.63	0.001587	0.000202	0.001386	0.721663
325.93	4.97	0.63	0.001587	0.000201	0.001386	0.721452
326.61	4.97	0.63	0.001587	0.000201	0.001386	0.721452
326.87	4.98	0.63	0.001587	0.000201	0.001386	0.721241
327.68 328.22	4.98	0.63	0.001587 0.001587	0.000201	0.001386 0.001387	0.721241
329.30	4.99	0.63	0.001587	0.000200	0.001387	0.721032
329.57	5.00	0.63	0.001587	0.000200	0.001387	0.720824
329.98	5.00	0.63	0.001587	0.000200	0.001387	0.720824
330.38 331.19	5.01 5.01	0.63	0.001587	0.000200	0.001388	0.720616 0.720616
331.59	5.02	0.62	0.001613	0.000199	0.001414	0.707364
332.67	5.02	0.62	0.001613	0.000199	0.001414	0.707364
332.94	5.03	0.62	0.001613	0.000199	0.001414	0.707166
334.43	5.03	0.62	0.001613	0.000199	0.001414	0.707166
334.56 335.37	5.04	0.62	0.001613	0.000198	0.001414	0.706968
335.64	5.05	0.62	0.001613	0.000198	0.001415	0.706772
336.31	5.05	0.62	0.001613	0.000198	0.001415	0.706772
336.58	5.06	0.62	0.001613	0.000198	0.001415	0.706577
337.53 337.66	5.06 5.07	0.62	0.001613	0.000198	0.001415	0.706577
339.82	5.07	0.62	0.001613	0.000197	0.001416	0.706382
340.09	5.07	0.61	0.001639	0.000197	0.001442	0.693430
340.50	5.07	0.60	0.001667	0.000197	0.001469	0.680537
340.77	5.08	0.60	0.001667	0.000197	0.001470	0.680357
344.56 344.82	5.08	0.60	0.001667 0.001667	0.000197	0.001470 0.001470	0.680178
345.23	5.09	0.60	0.001667	0.000196	0.001470	0.680178
345.50	5.09	0.59	0.001695	0.000196	0.001498	0.667356
347.94	5.09	0.59	0.001695	0.000196	0.001498	0.667356
348.35 348.48	5.08	0.59	0.001695 0.001695	0.000197	0.001498	0.667528
348.89	5.08	0.58	0.001724	0.000197	0.001527	0.654756
349.97	5.08	0.58	0.001724	0.000197	0.001527	0.654756
350.38	5.09	0.58	0.001724	0.000196	0.001528	0.654590

Temp	$T_2$	$T_2^*$	$1/T_2^*$	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
350.65	5.09	0.58	0.001724	0.000196	0.001528	0.654590
351.06	5.08	0.58	0.001724	0.000197	0.001527	0.654756
351.73	5.08	0.58	0.001724	0.000197	0.001527 0.001558	0.654756
352.01 352.14	5.08	0.57	0.001754	0.000197	0.001589	0.629381
354.04	5.08	0.56	0.001786	0.000197	0.001589	0.629381
354.31	5.07	0.56	0.001786	0.000197	0.001588	0.629534
356.62	5.07	0.56	0.001786	0.000197	0.001588	0.629534
356.89	5.06	0.56	0.001786	0.000198	0.001588	0.629689
357.30	5.07	0.56	0.001786	0.000197	0.001588	0.629534
357.43	5.07	0.56	0.001786	0.000197	0.001588	0.629534
357.84 357.97	5.07	0.55	0.001818	0.000197	0.001621 0.001621	0.616925
358.25	5.06	0.55	0.001818	0.000197	0.001621	0.617073
360.28	5.06	0.55	0.001818	0.000198	0.001621	0.617073
360.69	5.06	0.54	0.001852	0.000198	0.001654	0.604513
362.18	5.06	0.54	0.001852	0.000198	0.001654	0.604513
362.32	5.05	0.54	0.001852	0.000198	0.001654	0.604656
362.72	5.05	0.52	0.001923	0.000198	0.001725	0.579691
363.67	5.05	0.52	0.001923	0.000198	0.001725	0.579691
363.81 364.35	5.04	0.52	0.001923	0.000198	0.001725 0.001725	0.579823
364.49	5.04	0.51	0.001923	0.000198	0.001723	0.567417
364.76	5.04	0.51	0.001961	0.000198	0.001762	0.567417
365.03	5.03	0.51	0.001961	0.000199	0.001762	0.567544
366.12	5.03	0.51	0.001961	0.000199	0.001762	0.567544
366.39	5.02	0.51	0.001961	0.000199	0.001762	0.567672
366.80	5.02	0.50	0.002000	0.000199	0.001801	0.555310
366.94	5.01	0.50	0.002000	0.000200	0.001800	0.555432
367.76 367.89	5.00	0.50	0.002000	0.000200	0.001800	0.555556
368.44	5.00	0.50	0.002000	0.000200	0.001800	0.555556
368.71	5.00	0.49	0.002041	0.000200	0.001841	0.543237
368.85	5.00	0.49	0.002041	0.000200	0.001841	0.543237
369.12	4.99	0.49	0.002041	0.000200	0.001840	0.543356
369.66	4.99	0.49	0.002041	0.000200	0.001840	0.543356
369.94	4.98	0.49	0.002041	0.000201	0.001840	0.543474
370.48	4.97	0.49	0.002041	0.000201	0.001840	0.543594
370.75	4.97	0.48	0.002083	0.000201	0.001882	0.531314
370.89	4.97	0.48	0.002083	0.000201	0.001882	0.531314
371.16	4.96	0.48	0.002083	0.000202	0.001882	0.531429
372.25	4.96	0.48	0.002083	0.000202	0.001882	0.531429
372.39	4.96	0.47	0.002128	0.000202	0.001926	0.519198
372.80 373.21	4.95	0.47	0.002128	0.000202	0.001926	0.519308
373.34	4.94	0.47	0.002128	0.000202	0.001925	0.519418
373.75	4.94	0.47	0.002128	0.000202	0.001925	0.519418
374.16	4.93	0.47	0.002128	0.000203	0.001925	0.519529
374.43	4.93	0.47	0.002128	0.000203	0.001925	0.519529
374.70	4.93	0.46	0.002174	0.000203	0.001971	0.507338
375.11 375.66	4.92	0.46	0.002174	0.000203	0.001971 0.001971	0.507444
375.80	4.91	0.46	0.002174	0.000203	0.001970	0.507551
376.21	4.90	0.46	0.002174	0.000204	0.001970	0.507658
376.62	4.90	0.46	0.002174	0.000204	0.001970	0.507658
376.89	4.89	0.45	0.002222	0.000204	0.002018	0.495608
377.30	4.89	0.45	0.002222	0.000204	0.002018	0.495608
377.71	4.88	0.45	0.002222	0.000205	0.002017	0.495711
378.12 378.67	4.87	0.44	0.002273	0.000205	0.002067 0.002067	0.483702 0.483801
379.08	4.85	0.44	0.002326	0.000206	0.002007	0.471833
379.49	4.84	0.43	0.002326	0.000207	0.002119	0.471927

Temp	$T_2$	$T_2^*$	1/T2*	1/T2	$y=1/T_2^*-1/T_2$	1/y
379.90	4.84	0.43	0.002326	0.000207	0.002119	0.471927
380.31 380.45	4.83	0.43	0.002326	0.000207	0.002119	0.472023
380.86	4.82	0.43	0.002326	0.000207	0.002118	0.472118
381.13	4.81	0.42	0.002381	0.000208	0.002173	0.460182
381.27	4.81	0.42	0.002381	0.000208	0.002173	0.460182
381.41	4.80	0.42	0.002381	0.000208	0.002173	0.460274
381.68	4.80	0.42	0.002381	0.000208	0.002173	0.460274
381.82	4.79	0.42	0.002381	0.000209	0.002172	0.460366
382.23 382.50	4.79	0.41	0.002381	0.000209	0.002172	0.460366
382.64	4.78	0.41	0.002439	0.000209	0.002230	0.448467
382.91	4.78	0.41	0.002439	0.000209	0.002230	0.448467
383.19	4.77	0.41	0.002439	0.000210	0.002229	0.448555
383.32	4.77	0.41	0.002439	0.000210	0.002229	0.448555
383.60 383.73	4.76	0.41	0.002439	0.000210	0.002229	0.448644
383.87	4.75	0.41	0.002439	0.000210	0.002228	0.448733
383.88	4.75	0.41	0.002439	0.000211	0.002228	0.448733
384.15	4.74	0.40	0.002500	0.000211	0.002289	0.436866
384.42	4.73	0.40	0.002500	0.000211	0.002289	0.436952
384.70 384.84	4.72	0.40	0.002500	0.000212	0.002288	0.437037
385.11	4.71	0.40	0.002500	0.000212	0.002288	0.437037
385.39	4.70	0.40	0.002500	0.000213	0.002287	0.437209
385.67	4.69	0.39	0.002564	0.000213	0.002351	0.425372
386.08	4.68	0.39	0.002564	0.000214	0.002350	0.425455
386.49	4.67	0.39	0.002564	0.000214	0.002350	0.425537
386.77 387.05	4.66	0.39	0.002564	0.000215	0.002350	0.425621
387.46	4.63	0.38	0.002632	0.000216	0.002416	0.413976
387.73	4.62	0.38	0.002632	0.000216	0.002415	0.414057
388.01	4.62	0.38	0.002632	0.000216	0.002415	0.414057
388.28	4.61	0.37	0.002703	0.000217	0.002486	0.402288
388.42 388.56	4.60	0.37	0.002703	0.000217	0.002485	0.402364
388.70	4.59	0.37	0.002703	0.000217	0.002485	0.402441
388.84	4.59	0.37	0.002703	0.000218	0.002485	0.402479
388.97	4.58	0.37	0.002703	0.000218	0.002484	0.402518
389.11	4.58	0.37	0.002703	0.000218	0.002484	0.402518
389.25 389.39	4.57	0.37	0.002703	0.000219	0.002484	0.402595
389.53	4.55	0.37	0.002703	0.000219	0.002483	0.402751
389.80	4.55	0.36	0.002778	0.000220	0.002558	0.390931
389.94	4.54	0.36	0.002778	0.000220	0.002558	0.391005
390.08	4.54	0.36	0.002778	0.000220	0.002558	0.391005
390.36 390.63	4.53	0.36	0.002778	0.000221	0.002557 0.002557	0.391079
390.63	4.52	0.36	0.002778	0.000221	0.002556	0.391134
391.32	4.50	0.35	0.002857	0.000222	0.002635	0.379518
391.46	4.49	0.35	0.002857	0.000223	0.002634	0.379589
391.87	4.49	0.35	0.002857	0.000223	0.002634	0.379625
392.01	4.48	0.35	0.002857	0.000223	0.002634	0.379661
392.15 392.29	4.47	0.35	0.002857 0.002857	0.000224	0.002633	0.379805
392.42	4.47	0.35	0.002857	0.000224	0.002633	0.379733
392.56	4.45	0.35	0.002857	0.000225	0.002632	0.379878
392.70	4.45	0.35	0.002857	0.000225	0.002632	0.379878
392.84	4.44	0.35	0.002857 0.002857	0.000225	0.002632 0.002632	0.379951
392.98 393.12	4.44	0.35	0.002857	0.000225	0.002632	0.380025
393.26	4.43	0.35	0.002857	0.000226	0.002631	0.380025
393.39	4.42	0.35	0.002857	0.000226	0.002631	0.380098

Temp	$T_2$	$T_2^*$	1/T2*	1/T2	$y=1/T_2^*-1/T_2$	1/y
393.40	4.42	0.35	0.002857	0.000227	0.002631	0.380135
393.54	4.41	0.35	0.002857	0.000227	0.002630	0.380172
393.68	4.40	0.35	0.002857	0.000228	0.002630	0.380284
393.82 393.96	4.39	0.35	0.002857 0.002857	0.000228	0.002629	0.380322
394.10	4.38	0.35	0.002857	0.000228	0.002629	0.380435
394.24	4.37	0.35	0.002857	0.000229	0.002628	0.380511
394.38	4.36	0.35	0.002857	0.000230	0.002628	0.380587
394.52 394.66	4.35	0.34	0.002941	0.000230	0.002711	0.368828
394.67	4.33	0.34	0.002941	0.000230	0.002711	0.368972
394.80	4.32	0.34	0.002941	0.000231	0.002710	0.369045
394.81	4.32	0.34	0.002941	0.000231	0.002710	0.369045
394.95	4.31	0.34	0.002941	0.000232	0.002709	0.369118
395.09 395.23	4.30	0.34	0.002941	0.000233	0.002708	0.369217
395.37	4.28	0.34	0.002941	0.000234	0.002707	0.369377
395.51	4.27	0.34	0.002941	0.000234	0.002707	0.369415
395.65	4.26	0.34	0.002941	0.000235	0.002706	0.369490
395.66 395.80	4.25	0.34	0.002941	0.000235	0.002706	0.369565
395.93	4.24	0.34	0.002941	0.000236	0.002705	0.369641
396.21	4.23	0.34	0.002941	0.000237	0.002704	0.369755
396.36	4.21	0.33	0.003030	0.000238	0.002793	0.358067
396.63 396.91	4.21	0.33	0.003030	0.000238	0.002793	0.358067
397.05	4.19	0.33	0.003030	0.000238	0.002792	0.358212
397.18	4.19	0.33	0.003030	0.000239	0.002792	0.358212
397.32	4.18	0.33	0.003030	0.000239	0.002791	0.358286
397.60	4.17	0.33	0.003030	0.000240	0.002790	0.358359
397.74 397.88	4.16	0.33	0.003030	0.000240	0.002790	0.358433
398.15	4.15	0.32	0.003125	0.000241	0.002884	0.346736
398.30	4.14	0.32	0.003125	0.000242	0.002883	0.346806
398.44	4.13	0.32	0.003125	0.000242	0.002883	0.346877
398.57 398.98	4.12	0.32	0.003125	0.000243	0.002882	0.346947
399.12	4.11	0.32	0.003125	0.000243	0.002882	0.347018
399.27	4.09	0.32	0.003125	0.000244	0.002881	0.347162
399.68	4.09	0.32	0.003125	0.000244	0.002881	0.347162
399.82 400.09	4.08	0.32	0.003125	0.000245	0.002880	0.347234
400.23	4.06	0.32	0.003125	0.000246	0.002879	0.347380
400.37	4.05	0.32	0.003125	0.000247	0.002878	0.347453
400.65	4.05	0.32	0.003125	0.000247	0.002878	0.347453
400.79 400.93	4.04	0.31	0.003226	0.000248	0.002978	0.335764
400.93	4.02	0.31	0.003226	0.000248	0.002977	0.335903
401.21	4.01	0.31	0.003226	0.000249	0.002976	0.335973
401.35	4.01	0.31	0.003226	0.000249	0.002976	0.335973
401.49	4.00	0.31	0.003226	0.000250	0.002976	0.336043
401.63 401.77	3.99 3.99	0.31	0.003226	0.000251	0.002975	0.336114
401.91	3.98	0.30	0.003333	0.000251	0.003082	0.324457
402.05	3.97	0.30	0.003333	0.000252	0.003081	0.324523
402.33	3.96	0.30	0.003333	0.000253	0.003081	0.324590
402.47	3.95	0.30	0.003333	0.000253	0.003080	0.324658
402.75	3.93	0.30	0.003333	0.000254	0.003079	0.324793
402.89	3.92	0.30	0.003333	0.000255	0.003078	0.324862
403.03	3.92	0.30	0.003333	0.000255	0.003078	0.324862
403.17	3.91	0.30	0.003333	0.000256	0.003077	0.324965
	5.70			,		

Temp	$T_2$	$T_2^*$	$1/T_2^*$	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
403.45	3.89	0.30	0.003333	0.000257	0.003076	0.325070
403.46	3.88	0.30	0.003333	0.000258	0.003076	0.325140
403.59	3.88	0.30	0.003333	0.000258	0.003076	0.325140
403.73	3.87	0.30	0.003333	0.000258	0.003075	0.325210
403.74	3.86	0.30	0.003333	0.000259	0.003074	0.325281
403.88 404.02	3.86	0.30	0.003333	0.000259	0.003074	0.325281
404.16	3.84	0.29	0.003448	0.000260	0.003188	0.313690
404.30	3.83	0.29	0.003448	0.000261	0.003187	0.313791
404.58	3.82	0.29	0.003448	0.000262	0.003186	0.313824
404.72	3.80	0.29	0.003448	0.000263	0.003185	0.313960
404.86	3.80	0.29	0.003448	0.000263	0.003185	0.313960
405.00 405.14	3.79 3.78	0.28	0.003571	0.000264	0.003308	0.302336
405.14	3.77	0.28	0.003571	0.000265	0.003307	0.302464
405.29	3.77	0.28	0.003571	0.000265	0.003306	0.302464
405.43	3.76	0.28	0.003571	0.000266	0.003305	0.302529
405.57	3.75	0.28	0.003571	0.000267	0.003305	0.302594
405.70	3.75	0.28	0.003571	0.000267	0.003305	0.302594
405.71	3.74	0.28	0.003571	0.000267	0.003304	0.302659
405.99 406.12	3.73	0.28	0.003571	0.000268	0.003303	0.302725
406.26	3.72	0.28	0.003571	0.000269	0.003303	0.302791
406.27	3.72	0.28	0.003571	0.000269	0.003303	0.302791
406.40	3.71	0.28	0.003571	0.000270	0.003302	0.302857
406.54	3.71	0.28	0.003571	0.000270	0.003302	0.302857
406.55	3.70	0.28	0.003571	0.000270	0.003301	0.302924
406.68 406.82	3.70	0.28	0.003571	0.000270	0.003301	0.302924
406.83	3.69 3.68	0.27 0.27	0.003704	0.000271	0.003433	0.291316 0.291378
406.97	3.68	0.27	0.003704	0.000272	0.003432	0.291378
407.11	3.67	0.27	0.003704	0.000272	0.003431	0.291441
407.25	3.66	0.27	0.003704	0.000273	0.003430	0.291504
407.39	3.66	0.27	0.003704	0.000274	0.003430	0.291536
407.53	3.65	0.26	0.003846	0.000274	0.003572	0.279941
407.67 407.81	3.64	0.26	0.003846	0.000275	0.003571 0.003570	0.280000
408.09	3.62	0.26	0.003846	0.000276	0.003570	0.280119
408.23	3.61	0.26	0.003846	0.000277	0.003569	0.280199
408.38	3.59	0.26	0.003846	0.000279	0.003568	0.280300
408.51	3.59	0.26	0.003846	0.000279	0.003568	0.280300
408.52	3.58	0.26	0.003846	0.000279	0.003567	0.280361
408.66	3.57	0.26	0.003846	0.000280	0.003566	0.280423
408.80 408.94	3.56	0.26	0.003846	0.000281	0.003565	0.280485
409.08	3.55	0.26	0.003846	0.000282	0.003564	0.280547
409.09	3.54	0.26	0.003846	0.000282	0.003564	0.280610
409.23	3.53	0.26	0.003846	0.000283	0.003563	0.280673
409.37	3.53	0.26	0.003846	0.000283	0.003563	0.280673
409.51	3.52	0.26	0.003846	0.000284	0.003562	0.280768
409.65	3.51	0.25	0.004000	0.000285	0.003715	0.269172
409.79 409.93	3.50	0.25	0.004000	0.000286	0.003714	0.269231
410.07	3.48	0.25	0.004000	0.000287	0.003713	0.269350
410.21	3.47	0.25	0.004000	0.000288	0.003712	0.269410
410.22	3.47	0.25	0.004000	0.000288	0.003712	0.269410
410.49	3.46	0.25	0.004000	0.000289	0.003711	0.269470
410.50	3.45	0.25	0.004000	0.000290	0.003710	0.269531
410.64 410.78	3.45	0.25	0.004000	0.000290	0.003710	0.269562
410.79	3.43	0.25	0.004000	0.000292	0.003708	0.269685
410.93	3.42	0.25	0.004000	0.000292	0.003708	0.269716
411.06	3.42	0.25	0.004000	0.000292	0.003708	0.269716

Temp	$T_2$	$T_2^*$	$1/T_2^*$	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
411.07	3.41	0.25	0.004000	0.000293	0.003707	0.269778
411.20	3.41	0.25	0.004000	0.000293	0.003707	0.269778
411.21	3.40	0.25	0.004000	0.000294	0.003706	0.269841
411.35	3.39	0.25	0.004000	0.000295	0.003705	0.258286
411.63	3.38	0.24	0.004167	0.000296	0.003871	0.258324
411.77	3.37	0.24	0.004167	0.000297	0.003870	0.258403
411.91	3.36	0.24	0.004167	0.000298	0.003869	0.258462
411.92	3.35	0.24	0.004167	0.000299	0.003868	0.258521
412.06	3.34	0.24	0.004167	0.000299	0.003868	0.258561
412.07	3.33	0.24	0.004167	0.000300	0.003866	0.258641
412.21 412.35	3.33	0.24	0.004167	0.000300	0.003866	0.258641
412.49	3.31	0.23	0.004348	0.000302	0.004046	0.247175
412.50	3.30	0.23	0.004348	0.000303	0.004045	0.247231
412.64	3.29	0.23	0.004348	0.000304	0.004044	0.247288
412.65	3.28	0.23	0.004348	0.000305	0.004043	0.247344
412.79	3.28	0.23	0.004348	0.000305	0.004043	0.247344
412.93	3.27	0.23	0.004348	0.000306	0.004042	0.247430
413.07 413.21	3.25	0.23	0.004348	0.000308	0.004040	0.247517
413.22	3.24	0.23	0.004348	0.000308	0.004039	0.247575
413.35	3.24	0.23	0.004348	0.000309	0.004039	0.247575
413.36	3.23	0.23	0.004348	0.000310	0.004038	0.247653
413.50	3.22	0.23	0.004348	0.000311	0.004037	0.247692
413.64	3.22	0.23	0.004348	0.000311	0.004037	0.247722
413.78	3.21	0.23	0.004348	0.000312	0.004036	0.247752
413.92 413.93	3.20	0.23	0.004348	0.000313	0.004035	0.247811
413.93	3.19	0.23	0.004348	0.000313	0.004034	0.247872
414.07	3.18	0.23	0.004348	0.000313	0.004033	0.247932
414.21	3.17	0.23	0.004348	0.000315	0.004032	0.247993
414.22	3.17	0.23	0.004348	0.000315	0.004032	0.247993
414.36	3.16	0.23	0.004348	0.000317	0.004031	0.248085
414.50	3.15	0.23	0.004348	0.000317	0.004030	0.248116
414.64	3.15	0.22	0.004545	0.000318	0.004227	0.236547
414.65 414.93	3.12	0.22	0.004545	0.000320	0.004225	0.236661
415.07	3.10	0.22	0.004545	0.000323	0.004223	0.236806
415.21	3.10	0.22	0.004545	0.000323	0.004223	0.236806
415.35	3.09	0.22	0.004545	0.000324	0.004222	0.236864
415.36	3.09	0.22	0.004545	0.000324	0.004222	0.236864
415.50	3.08	0.22	0.004545	0.000325	0.004221	0.236923
415.64	3.07 3.07	0.22	0.004545	0.000326	0.004220	0.236982
415.78 415.92	3.06	0.21	0.004762	0.000326	0.004436	0.225420
416.06	3.05	0.21	0.004762	0.000328	0.004434	0.225528
416.07	3.04	0.21	0.004762	0.000329	0.004433	0.225583
416.21	3.04	0.21	0.004762	0.000329	0.004433	0.225583
416.35	3.03	0.21	0.004762	0.000330	0.004432	0.225638
416.49	3.03	0.21	0.004762	0.000331	0.004431	0.225666
416.63	3.02	0.21	0.004762	0.000332	0.004430	0.225722
416.64 416.91	3.00	0.21	0.004762	0.000333	0.004429	0.225806
417.05	2.99	0.21	0.004762	0.000334	0.004427	0.225863
417.19	2.99	0.21	0.004762	0.000335	0.004427	0.225892
417.20	2.98	0.21	0.004762	0.000336	0.004426	0.225921
417.34	2.97	0.21	0.004762	0.000337	0.004425	0.225978
417.48	2.96	0.21	0.004762	0.000338	0.004424	0.226036
417.48 417.62	2.97	0.21	0.004762	0.000337	0.004425	0.225978
417.62	2.95	0.21	0.004762	0.000338	0.004424	0.226095
417.77	2.94	0.20	0.005000	0.000339	0.004660	0.214599

Temp	$T_2$	$T_2^*$	1/T2*	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
417.91	2.93	0.20	0.005000	0.000341	0.004659	0.214652
418.05	2.92	0.20	0.005000	0.000342	0.004658	0.214706
418.06	2.92	0.20	0.005000	0.000342	0.004658	0.214706
418.20	2.91	0.20	0.005000	0.000344	0.004656	0.214760
418.21 418.35	2.89	0.20	0.005000	0.000345	0.004655	0.214833
418.35	2.89	0.20	0.005000	0.000348	0.004652	0.214870
418.50	2.87	0.20	0.005000	0.000348	0.004652	0.214981
418.51	2.86	0.20	0.005000	0.000350	0.004650	0.215038
418.65	2.85	0.20	0.005000	0.000351	0.004649	0.215094
418.66	2.84	0.20	0.005000	0.000352	0.004648	0.215152
418.81	2.82	0.20	0.005000	0.000354	0.004646	0.215248
418.96	2.81	0.20	0.005000	0.000357	0.004643	0.215355
419.10	2.79	0.19	0.005263	0.000358	0.004905	0.203885
419.11	2.79	0.19	0.005263	0.000358	0.004905	0.203885
419.25 419.40	2.78 2.77	0.19	0.005263 0.005263	0.000360	0.004903	0.203965
419.54	2.76	0.19	0.005263	0.000363	0.004902	0.203992
419.55	2.75	0.19	0.005263	0.000364	0 0.0049	0.204102
419.69	2.74	0.19	0.005263	0.000365	0.004898	0.204157
419.83	2.73	0.19	0.005263	0.000366	0.004897	0.204213
419.97	2.72	0.19	0.005263	0.000368	0.004896	0.204269
419.98	2.72	0.19	0.005263	0.000368	0.004896	0.204269
420.12	2.71	0.19	0.005263	0.000369	0.004894	0.204325
420.13	2.70	0.19	0.005263	0.000370	0.004893	0.204382
420.27	2.70	0.19	0.005263	0.000370	0.004893	0.204382
420.41 420.55	2.69	0.19	0.005263	0.000372	0.004891	0.204469
420.56	2.67	0.19	0.005263	0.000375	0.004889	0.204556
420.70	2.67	0.19	0.005263	0.000375	0.004889	0.204556
420.84	2.66	0.18	0.005556	0.000376	0.005180	0.193065
420.98	2.65	0.18	0.005556	0.000377	0.005178	0.193117
420.99	2.65	0.18	0.005556	0.000377	0.005178	0.193117
421.13	2.64	0.18	0.005556	0.000380	0.005176	0.193198
421.14	2.62	0.18	0.005556	0.000382	0.005174	0.193279
421.28	2.62	0.18	0.005556	0.000382	0.005174	0.193279
421.42 421.56	2.61	0.18	0.005556	0.000383	0.005172	0.193333
421.50	2.60	0.18	0.005556	0.000385	0.005171	0.193388
421.58	2.58	0.18	0.005556	0.000388	0.005168	0.193500
421.72	2.58	0.18	0.005556	0.000388	0.005168	0.193500
421.73	2.57	0.18	0.005556	0.000389	0.005166	0.193556
421.87	2.56	0.18	0.005556	0.000391	0.005165	0.193613
421.88	2.55	0.18	0.005556	0.000392	0.005163	0.193671
422.02	2.54	0.18	0.005556	0.000394	0.005162	0.193729
422.16	2.54	0.18	0.005556	0.000394	0.005162	0.193729
422.17 422.18	2.53	0.18	0.005556	0.000395	0.005160	0.193787
422.18	2.52	0.18	0.005556	0.000397	0.005158 0.005157	0.193866
422.33	2.50	0.17	0.005882	0.000400	0.005482	0.182403
422.34	2.49	0.17	0.005882	0.000402	0.005481	0.182457
422.35	2.49	0.17	0.005882	0.000402	0.005481	0.182457
422.48	2.48	0.17	0.005882	0.000403	0.005479	0.182511
422.49	2.47	0.17	0.005882	0.000404	0.005478	0.182547
122.50	2.46	0.17	0.005882	0.000406	0.005476	0.182602
422.51	2.46	0.17	0.005882	0.000407	0.005475	0.182648
422.52	2.45	0.17	0.005882	0.000408	0.005474	0.182675
122.65 122.66	2.44	0.17	0.005882 0.005882	0.000410	0.005473 0.005473	0.182731
122.67	2.44	0.17	0.005882	0.000410	0.005473	0.182731
122.68	2.42	0.17	0.005882	0.000412	0.005469	0.182844
122.82	2.41	0.17	0.005882	0.000415	0.005467	0.182902
122.83	2.40	0.17	0.005882	0.000417	0.005466	0.182960

Temp	$T_2$	$T_2^*$	1/T2*	1/T2	$y=1/T_2^*-1/T_2$	1/y
422.97	2.40	0.17	0.005882	0.000418	0.005465	0.182989
422.98	2.39	0.17	0.005882	0.000418	0.005464	0.183018
423.12	2.38	0.17	0.005882	0.000420	0.005462	0.183077
423.13	2.37	0.17	0.005882	0.000422	0.005460	0.183136
423.14	2.36	0.17	0.005882	0.000424	0.005459	0.183196
423.15 423.29	2.35	0.17 0.17	0.005882	0.000426	0.005457	0.183257
423.29	2.34	0.17	0.005882	0.000428	0.005456	0.183287
423.31	2.33	0.17	0.005882	0.000428	0.005454	0.183411
423.45	2.32	0.17	0.005882	0.000431	0.005451	0.183442
423.46	2.31	0.17	0.005882	0.000433	0.005449	0.183505
423.60	2.30	0.17	0.005882	0.000435	0.005448	0.183568
423.61	2.29	0.17	0.005882	0.000436	0.005446	0.183611
423.75	2.29	0.17	0.005882	0.000437	0.005446	0.183632
423.76	2.28	0.17	0.005882	0.000439	0.005444	0.183697
423.90	2.27	0.17	0.005882	0.000441	0.005442	0.183762
423.91	2.27	0.17	0.005882	0.000442	0.005441	0.183795
424.05	2.26	0.17	0.005882	0.000442	0.005440	0.183828
424.06 424.20	2.25	0.17	0.005882	0.000444	0.005438	0.183894
424.20	2.24	0.17	0.005882	0.000446	0.005436	0.183961
424.35	2.23	0.17	0.005882	0.000448	0.005434	0.184029
424.49	2.23	0.16	0.006250	0.000448	0.005802	0.172367
424.50	2.22	0.16	0.006250	0.000450	0.005800	0.172427
424.64	2.21	0.16	0.006250	0.000452	0.005798	0.172488
424.78	2.21	0.16	0.006250	0.000454	0.005796	0.172518
424.79	2.20	0.16	0.006250	0.000455	0.005795	0.172549
424.92	2.20	0.16	0.006250	0.000455	0.005795	0.172549
424.93	2.19	0.16	0.006250	0.000457	0.005793	0.172611
425.07	2.19	0.16	0.006250	0.000458	0.005792	0.172642
425.08	2.18	0.16	0.006250	0.000459	0.005791	0.172673
425.22 425.23	2.17	0.16	0.006250	0.000461	0.005789	0.172736
425.23	2.17	0.16	0.006250 0.006250	0.000462	0.005788	0.172768
425.38	2.14	0.16	0.006250	0.000467	0.005783	0.172929
425.39	2.14	0.16	0.006250	0.000468	0.005782	0.172962
425.40	2.13	0.16	0.006250	0.000470	0.005780	0.173017
425.41	2.12	0.16	0.006250	0.000472	0.005778	0.173061
425.42	2.11	0.16	0.006250	0.000474	0.005776	0.173128
425.43	2.11	0.16	0.006250	0.000475	0.005775	0.173162
425.44	2.09	0.16	0.006250	0.000478	0.005772	0.173264
425.45	2.09	0.16	0.006250	0.000480	0.005770	0.173299
425.46	2.08	0.16	0.006250	0.000482	0.005768	0.173368
425.47	2.07	0.16	0.006250	0.000483	0.005767	0.173403
425.48	2.06	0.16	0.006250	0.000487	0.005763	0.173509
425.50	2.04	0.16	0.006250	0.000489	0.005761 0.005760	0.173581
425.51	2.03	0.16	0.006250	0.000493	0.005757	0.173690
425.64	2.03	0.16	0.006250	0.000493	0.005757	0.173690
425.65	2.03	0.16	0.006250	0.000493	0.005757	0.173690
425.66	2.02	0.16	0.006250	0.000495	0.005755	0.173763
425.67	2.01	0.16	0.006250	0.000498	0.005752	0.173838
425.68	2.00	0.16	0.006250	0.000500	0.005750	0.173913
425.69	1.99	0.16	0.006250	0.000503	0.005747	0.173989
425.70	1.98	0.16	0.006250	0.000505	0.005745	0.174066
425.84	1.97	0.15	0.006667	0.000508	0.006159	0.162363
425.85 425.86	1.97	0.15	0.006667	0.000508	0.006159	0.162363
425.86	1.96	0.15	0.006667 0.006667	0.000510	0.006156 0.006155	0.162431
426.00	1.95	0.15	0.006667	0.000512	0.006153	0.162465
426.02	1.94	0.15	0.006667	0.000514	0.006153	0.162535
426.03	1.93	0.15	0.006667	0.000518	0.006149	0.162640
426.04	1.92	0.15	0.006667	0.000521	0.006146	0.162712

Temp	$T_2$	$T_2^*$	$1/T_2^*$	1/T2	$y=1/T_2^*-1/T_2$	1/y
426.05	1.92	0.15	0.006667	0.000521	0.006146	0.162712
426.19	1.91	0.15	0.006667	0.000524	0.006143	0.162784
426.20	1.90	0.15	0.006667	0.000526	0.006140	0.162857
426.21	1.89	0.15	0.006667	0.000529	0.006138	0.162931
426.35	1.89	0.15	0.006667	0.000529	0.006138	0.162931
426.36	1.88	0.15	0.006667	0.000532	0.006135	0.163006
426.37	1.87	0.15	0.006667	0.000535	0.006132 0.006130	0.163132
426.38 426.39	1.86	0.15 0.15	0.006667	0.000537	0.006130	0.163196
426.53	1.85	0.15	0.006667	0.000541	0.006126	0.163235
426.54	1.84	0.15	0.006667	0.000542	0.006124	0.163287
426.55	1.84	0.15	0.006667	0.000543	0.006123	0.163314
426.69	1.83	0.15	0.006667	0.000546	0.006120	0.163393
426.70	1.82	0.15	0.006667	0.000549	0.006117	0.163473
426.84	1.82	0.15	0.006667	0.000549	0.006117	0.163473
426.85	1.81	0.15	0.006667	0.000552	0.006114	0.163554
426.99	1.81	0.15	0.006667	0.000554	0.006113	0.163595
427.00	1.80	0.15	0.006667	0.000556	0.006111	0.163720
427.01	1.79	0.15	0.006667	0.000559	0.006106	0.163761
427.02 427.03	1.79 1.78	0.15	0.006667	0.000563	0.006103	0.163846
427.03	1.77	0.15	0.006667	0.000567	0.006100	0.163932
427.08	1.64	0.15	0.006667	0.000610	0.006057	0.165101
427.09	1.63	0.15	0.006667	0.000613	0.006053	0.165203
427.10	1.62	0.15	0.006667	0.000616	0.006051	0.165271
427.11	1.62	0.15	0.006667	0.000617	0.006049	0.165306
427.12	1.61	0.15	0.006667	0.000621	0.006046	0.165411
427.13	1.61	0.15	0.006667	0.000623	0.006044	0.165464
427.14	1.60	0.15	0.006667	0.000624	0.006043	0.165482
427.18	1.59 1.58	0.15	0.006667	0.000629	0.006034	0.165734
427.19 427.31	1.58	0.15	0.006667	0.000633	0.006034	0.165734
427.32	1.57	0.15	0.006667	0.000638	0.006028	0.165882
427.32	1.57	0.15	0.006667	0.000638	0.006028	0.165882
427.33	1.56	0.15	0.006667	0.000641	0.006026	0.165957
427.34	1.55	0.15	0.006667	0.000645	0.006022	0.166071
427.34	1.55	0.15	0.006667	0.000645	0.006022	0.166071
427.35	1.54	0.15	0.006667	0.000648	0.006019	0.166148
427.36	1.54	0.15	0.006667	0.000649	0.006017	0.166187
427.37	1.53	0.15	0.006667 0.006667	0.000654	0.006013	0.166304
427.51 427.52	1.53	0.15	0.006667	0.000658	0.006009	0.166423
427.52	1.51	0.15	0.006667	0.000662	0.006004	0.166544
427.54	1.51	0.15	0.006667	0.000664	0.006003	0.166585
427.55	1.50	0.15	0.006667	0.000667	0.006000	0.166667
427.69	1.50	0.15	0.006667	0.000667	0.006000	0.166667
427.70	1.49	0.15	0.006667	0.000671	0.005996	0.166791
427.71	1.48	0.15	0.006667	0.000676	0.005991	0.166917
427.85	1.48	0.14	0.007143	0.000676	0.006467	0.154627
427.86	1.47	0.14	0.007143	0.000680	0.006463	0.154737
427.87	1.46	0.14	0.007143	0.000690	0.006453	0.154962
427.88 427.88	1.45	0.14	0.007143	0.000690	0.006453	0.154962
427.89	1.44	0.14	0.007143	0.000694	0.006448	0.155077
427.89	1.44	0.14	0.007143	0.000694	0.006448	0.155077
427.90	1.42	0.14	0.007143	0.000704	0.006439	0.155313
427.90	1.42	0.14	0.007143	0.000704	0.006439	0.155313
427.91	1.41	0.14	0.007143	0.000709	0.006434	0.155433
427.91	1.41	0.14	0.007143	0.000709	0.006434	0.155433
427.92	1.40	0.14	0.007143	0.000714	0.006429	0.155556 0.155556
427.92	1.40	0.14	0.007143	0.000714	0.006429	0.15568
427.93 427.93	1.39	0.14	0.007143	0.000719	0.006423	0.15568
421.73	1.39	3.14	0.00/143	2.000/19		

Тетр	$T_2$	$T_2^*$	$1/T_2^*$	1/T2	$y=1/T_2^*-1/T_2$	1/y
27.94	1.38	0.14	0.007143	0.000725	0.006418	0.155806
27.94	1.38	0.14	0.007143	0.000725	0.006418	0.155806
27.95	1.37	0.14	0.007143	0.000730	0.006413	0.155935
27.95	1.37	0.14	0.007143	0.000730	0.006413	0.155935
27.96	1.36	0.14	0.007143	0.000735	0.006408	0.156066
127.96	1.36	0.14	0.007143	0.000735	0.006408	0.156066
27.97	1.35	0.14	0.007143	0.000741	0.006402	0.156198
27.97	1.35	0.14	0.007143	0.000741	0.006402	0.156198
127.98	1.33	0.14	0.007143	0.000752	0.006391	0.156471
127.98	1.33	0.14	0.007143	0.000752	0.006391	0.156471
127.99	1.32	0.14	0.007143	0.000758	0.006385	0.156610
127.99	1.32	0.14	0.007143	0.000758	0.006385	0.156610
127.99	1.32	0.14	0.007143	0.000758	0.006385	0.156752
128.00 128.00	1.31	0.14	0.007143	0.000763	0.006379	0.156752
28.00	1.30	0.14	0.007143	0.000767	0.006376	0.156848
28.02	1.30	0.14	0.007143	0.000771	0.006372	0.156945
428.03	1.29	0.14	0.007143	0.000775	0.006368	0.157043
128.17	1.29	0.14	0.007143	0.000775	0.006368	0.157043
128.18	1.28	0.14	0.007143	0.000781	0.006362	0.157193
128.19	1.28	0.14	0.007143	0.000781	0.006362	0.157193
128.20	1.27	0.14	0.007143	0.000787	0.006355	0.157345
128.21	1.27	0.14	0.007143	0.000791	0.006352	0.157422
428.35	1.26	0.14	0.007143	0.000794	0.006349	0.157500
428.36	1.26	0.14	0.007143	0.000794	0.006349	0.157500
428.37	1.25	0.14	0.007143	0.000800	0.006343	0.157658
428.38	1.25	0.14	0.007143	0.000800	0.006343	0.157658
428.39	1.24	0.14	0.007143	0.000806	0.006336	0.157818
428.40	1.24	0.14	0.007143	0.000810	0.006333	0.157900
428.41	1.23	0.14	0.007143	0.000813	0.006330	0.157982
428.42	1.23	0.14	0.007143	0.000815	0.006328	0.158037
428.43	1.22	0.14	0.007143	0.000820	0.006323	0.158148
428.44 428.45	1.21	0.14	0.007143	0.000826	0.006316	0.158318
428.45	1.20	0.14	0.007143	0.000831	0.006312	0.158433
428.47	1.20	0.14	0.007143	0.000833	0.006310	0.158491
428.48	1.19	0.14	0.007143	0.000840	0.006303	0.158667
428.49	1.19	0.14	0.007143	0.000840	0.006303	0.158667
428.50	1.18	0.14	0.007143	0.000847	0.006295	0.158846
428.51	1.18	0.14	0.007143	0.000847	0.006295	0.158846
428.52	1.17	0.14	0.007143	0.000855	0.006288	0.159029
428.53	1.17	0.14	0.007143	0.000855	0.006288	0.159029
428.54	1.16	0.14	0.007143	0.000862	0.006281	0.159216
428.55	1.16	0.14	0.007143	0.000862	0.006281	0.159216
428.69	1.15	0.14	0.007143	0.000870	0.006273	0.159406
428.70	1.15	0.14	0.007143	0.000870	0.006273	0.159406
428.71	1.14	0.14	0.007143	0.000877	0.006266	0.159600
428.72	1.14	0.14	0.007143	0.000877	0.006266	0.159600
428.73	1.13	0.14	0.007143	0.000882	0.006261	0.159732
428.74	1.13	0.14	0.007143	0.000885	0.006250 0.006805	0.146957
428.88 428.89	1.13	0.13	0.007692	0.000893	0.006799	0.147071
428.90	1.12	0.13	0.007692	0.000893	0.006799	0.147071
428.90	1.11	0.13	0.007692	0.000901	0.006791	0.147245
429.19	1.11	0.13	0.007692	0.000901	0.006791	0.147245
429.20	1.10	0.13	0.007692	0.000909	0.006783	0.147423
429.21	1.10	0.13	0.007692	0.000909	0.006783	0.147423
429.35	1.09	0.13	0.007692	0.000917	0.006775	0.147604
429.50	1.09	0.13	0.007692	0.000917	0.006775	0.147604
429.51	1.08	0.13	0.007692	0.000926	0.006766	0.147789
429.65	1.08	0.13	0.007692	0.000926	0.006766	0.147789
429.66	1.07	0.13	0.007692	0.000932	0.006761	0.147915
429.81	1.07	0.13	0.007692	0.000935	0.006758	0.147979

Temp	$T_2$	$T_2^*$	1/T2*	1/T2	$y = 1/T_2^* - 1/T_2$	1/y
129.82	1.06	0.13	0.007692	0.000943	0.006749	0.148172
129.97	1.06	0.13	0.007692	0.000946	0.006746	0.148237
130.11	1.05	0.13	0.007692	0.000952	0.006740	0.148370
430.12	1.05	0.13	0.007692	0.000952	0.006740	0.148370
430.26	1.04	0.13	0.007692	0.000958	0.006734	0.148504
430.28	1.04	0.13	0.007692	0.000962	0.006731	0.148571
430.42	1.03	0.13	0.007692	0.000968	0.006725	0.148708
430.57	1.03	0.13	0.007692	0.000974	0.006718	0.148989
430.58	1.02	0.13	0.007692	0.000980	0.007353	0.136000
430.59 430.73	1.02	0.12	0.008333	0.000990	0.007343	0.136180
430.73	1.01	0.12	0.008333	0.000990	0.007343	0.136180
430.89	1.00	0.12	0.008333	0.001000	0.007333	0.136364
431.18	1.00	0.12	0.008333	0.001003	0.007330	0.136426
431.32	0.99	0.12	0.008333	0.001010	0.007323	0.136552
431.33	0.99	0.12	0.008333	0.001010	0.007323	0.136552
431.34	0.98	0.12	0.008333	0.001020	0.007313	0.136744
431.48	0.98	0.11	0.009091	0.001020	0.008071	0.123908
431.49	0.98	0.11	0.009091	0.001020	0.008071	0.123908
431.63	0.97	0.11	0.009091	0.001031	0.008060	0.124070
431.78	0.97	0.11	0.009091	0.001031	0.008060	0.124070
431.79	0.96	0.11	0.009091	0.001042	0.008049	0.124235
431.94 431.95	0.95	0.11	0.009091	0.001053	0.008038	0.124405
432.10	0.95	0.11	0.009091	0.001058	0.008033	0.124491
432.11	0.94	0.11	0.009091	0.001064	0.008027	0.124578
432.26	0.94	0.11	0.009091	0.001070	0.008021	0.124667
432.27	0.93	0.11	0.009091	0.001075	0.008016	0.124756
432.28	0.93	0.11	0.009091	0.001075	0.008016	0.124756
432.29	0.92	0.11	0.009091	0.001087	0.008004	0.124938
432.30	0.92	0.11	0.009091	0.001087	0.008004	0.124938
432.31	0.91	0.11	0.009091	0.001095	0.007996	0.125062 0.125125
432.33	0.91	0.11	0.009091	0.001099	0.007992	0.125125
432.34	0.90	0.11	0.009091	0.001111	0.007980 0.007980	0.125316
432.35	0.90	0.11	0.009091	0.001111	0.007972	0.125447
432.36 432.38	0.89	0.11	0.009091	0.001128	0.007963	0.125579
432.39	0.88	0.11	0.009091	0.001136	0.007955	0.125714
432.54	0.88	0.11	0.009091	0.001136	0.007955	0.125714
432.55	0.87	0.11	0.009091	0.001149	0.007941	0.125921
432.56	0.87	0.11	0.009091	0.001149	0.007941	0.125921
432.57	0.86	0.11	0.009091	0.001163	0.007928	0.126133
432.73	0.86	0.11	0.009091	0.001163	0.007928	0.126133
432.74	0.85	0.11	0.009091	0.001176	0.007914	0.126351
432.75	0.85	0.11	0.009091	0.001176	0.007914	0.126351
432.89	0.84	0.10	0.010000	0.001190	0.008810	0.113514
433.05	0.84	0.10	0.010000	0.001190	0.008795	0.113699
433.06	0.83	0.10	0.010000	0.001203	0.008790	0.113761
433.21 433.22	0.82	0.10	0.010000	0.001210	0.008780	0.113889
433.37	0.82	0.10	0.010000	0.001220	0.008780	0.113889
433.38	0.81	0.10	0.010000	0.001235	0.008765	0.114085
433.40	0.81	0.10	0.010000	0.001235	0.008765	0.114085
433.54	0.80	0.10	0.010000	0.001250	0.008750	0.114286
433.56	0.80	0.10	0.010000	0.001250	0.008750	0.114286
433.57	0.79	0.10	0.010000	0.001266	0.008734	0.114493
433.73	0.79	0.10	0.010000	0.001266	0.008734	0.114493
433.86	0.78	0.10	0.010000	0.001282	0.008718 0.008718	0.114706
434.02	0.78	0.10	0.010000	0.001282	0.008718	0.114706
434.03	0.77	0.10	0.010000	0.001299	0.008693	0.115038
434.32	0.76	0.10	0.010000	0.001307	0.008684	0.115152
434.35	0.76	0.09	0.011111	0.001316	0.009795	0.102090
.54.55	00	,				

Temp	$T_2$	$T_2^*$	$1/T_2^*$	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
434.36	0.75	0.09	0.011111	0.001333	0.009778	0.102273
434.51	0.75	0.09	0.011111	0.001333	0.009778	0.102273
434.52	0.74	0.09	0.011111	0.001345	0.009766	0.102398
434.68	0.74	0.09	0.011111	0.001357	0.009754	0.102526
434.69	0.73	0.09	0.011111	0.001370	0.009741	0.102656
434.71	0.73	0.09	0.011111	0.001370	0.009741	0.102656
434.72	0.72	0.09	0.011111	0.001389	0.009722	0.102926
434.74 434.75	0.72 0.71	0.09	0.011111	0.001408	0.009703	0.103065
434.77	0.71	0.09	0.011111	0.001408	0.009703	0.103065
434.78	0.70	0.09	0.011111	0.001429	0.009683	0.103279
434.80	0.70	0.09	0.011111	0.001429	0.009683	0.103279
434.81	0.69	0.09	0.011111	0.001442	0.009669	0.103425
434.84	0.69	0.09	0.011111	0.001456	0.009655	0.103575
434.98	0.68	0.09	0.011111	0.001471	0.009633	0.103729
435.14	0.68	0.09	0.011111	0.001478	0.009619	0.103966
435.15	0.67	0.09	0.011111	0.001493	0.009619	0.103966
435.18	0.66	0.09	0.011111	0.001515	0.009596	0.104211
435.45	0.66	0.09	0.011111	0.001515	0.009596	0.104211
435.47	0.70	0.09	0.011111	0.001429	0.009683	0.103279
435.48	0.69	0.09	0.011111	0.001449	0.009662	0.103500
435.49	0.69	0.09	0.011111	0.001449	0.009662	0.103500
435.49	0.69	0.09	0.011111	0.001449	0.009662	0.103500
435.50 435.51	0.68	0.09	0.011111	0.001463	0.009648	0.103652
435.51	0.69	0.09	0.011111	0.001449	0.009662	0.103500
435.52	0.68	0.09	0.011111	0.001471	0.009641	0.103729
435.58	0.66	0.09	0.011111	0.001508	0.009604	0.104128
435.59	0.70	0.09	0.011111	0.001429	0.009683	0.103279
435.60	0.70	0.09	0.011111	0.001429	0.009683	0.103279
435.65	0.68	0.09	0.011111	0.001471	0.009641	0.103729
435.66 435.70	0.68	0.09	0.011111	0.001471	0.009619	0.103966
435.70	0.67	0.09	0.011111	0.001493	0.009619	0.103966
435.80	0.68	0.09	0.011111	0.001471	0.009641	0.103729
435.81	0.68	0.09	0.011111	0.001471	0.009641	0.103729
435.82	0.67	0.09	0.011111	0.001493	0.009619	0.103966
435.82	0.67	0.09	0.011111	0.001493	0.009619	0.103966
435.83	0.67	0.09	0.011111	0.001493	0.009619	0.103966 0.103065
435.83	0.71	0.09	0.011111	0.001408	0.009676	0.103352
435.84	0.70	0.09	0.011111	0.001429	0.009683	0.103279
435.94	0.72	0.10	0.010000	0.001389	0.008611	0.116129
435.95	0.72	0.10	0.010000	0.001399	0.008601	0.116260
435.96	0.71	0.10	0.010000	0.001408	0.008592	0.116393
436.05	0.72	0.10	0.010000	0.001389	0.008611	0.116129
436.06	0.72	0.10	0.010000	0.001389	0.008611	0.116129
436.07	0.72	0.10	0.010000	0.001389	0.008611	0.116129 0.115625
436.15	0.74	0.10	0.010000	0.001331	0.008630	0.115873
436.16	0.73	0.10	0.010000	0.001370	0.008630	0.115873
436.17	0.73	0.10	0.010000	0.001370	0.008630	0.115873
436.18	0.73	0.10	0.010000	0.001370	0.008630	0.115873
436.26	0.74	0.10	0.010000	0.001351	0.008649	0.115625
436.27	0.74	0.10	0.010000	0.001351	0.008649	0.115625
436.28	0.74	0.11	0.009091	0.001351	0.007740	0.129206 0.128906
436.39	0.75	0.11	0.009091	0.001333	0.007758	0.129206
436.40	0.74	0.11	0.009091	0.001331	0.007758	0.128906
436.50	0.75	0.11	0.009091	0.001333	0.007758	0.128906
436.52	0.75	0.11	0.009091	0.001333	0.007758	0.128906
436.57	0.78	0.11	0.009091	0.001290	0.007801	0.128195

Temp	$T_2$	$T_2^*$	1/T2*	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
436.58	0.77	0.11	0.009091	0.001299	0.007792	0.128333
436.59	0.77	0.11	0.009091	0.001299	0.007792	0.128333 0.128426
436.60	0.77 0.76	0.11	0.009091	0.001304	0.007775	0.128615
436.62	0.76	0.11	0.009091	0.001316	0.007775	0.128615
436.63	0.76	0.11	0.009091	0.001325	0.007766	0.128760
436.69	0.78	0.11	0.009091	0.001282	0.007809	0.128060
436.70	0.78	0.11	0.009091	0.001282	0.007809	0.128060
436.82 436.94	0.78 0.79	0.11	0.009091	0.001282	0.007825	0.127794
436.95	0.78	0.11	0.009091	0.001282	0.007809	0.128060
437.04	0.80	0.11	0.009091	0.001250	0.007841	0.127536
437.05	0.80	0.11	0.009091	0.001258	0.007833	0.127664
437.06	0.79	0.11	0.009091	0.001266	0.007825	0.127794
437.14	0.81	0.11	0.009091	0.001235	0.007856	0.127286
437.16	0.80	0.11	0.009091	0.001245	0.007846	0.127452
437.24	0.82	0.11	0.009091	0.001220	0.007871	0.127042
437.25	0.82	0.11	0.009091	0.001220	0.007871	0.127042
437.26	0.82	0.11	0.009091	0.001227	0.007864	0.127163 0.127286
437.27	0.82	0.11	0.009091	0.001219	0.007872	0.127029
437.31	0.82	0.12	0.008333	0.001213	0.007120	0.140452
437.32	0.83	0.12	0.008333	0.001208	0.007125	0.140350
437.33	0.83	0.12	0.008333	0.001203	0.007130	0.140249
437.37	0.82	0.12	0.008333	0.001220	0.007114	0.140571
437.40	0.86	0.12	0.008333	0.001164	0.007170	0.139477
437.42	0.86	0.12	0.008333	0.001159	0.007174	0.139385
437.43	0.87	0.12	0.008333	0.001154	0.007179	0.139294
437.47	0.88	0.12	0.008333	0.001136	0.007198	0.138936
437.48	0.88	0.12	0.008333	0.001131	0.007202	0.138849
437.50	0.88	0.12	0.008333	0.001132	0.007201	0.138865
437.50	0.89	0.12	0.008333	0.001122	0.007211	0.138676
437.51	0.89	0.12	0.008333	0.001118	0.007215	0.138592
437.53	0.90	0.12	0.008333	0.001109	0.007224	0.138424
437.62	0.93	0.12	0.008333	0.001071	0.007262	0.137706
437.66	0.95	0.12	0.008333	0.001056	0.007278	0.137404
437.67	0.97	0.12	0.008333	0.001031	0.007302	0.136941
437.74	0.98	0.12	0.008333	0.001025	0.007308	0.136831
437.75	0.98	0.12	0.008333	0.001021	0.007312	0.136762
437.77	0.99	0.12	0.008333	0.001014	0.007319	0.136626 0.136558
437.78	0.97	0.12	0.008333	0.001010	0.007302	0.136941
437.82	0.97	0.12	0.008333	0.001031	0.007302	0.136941
437.83	1.01	0.12	0.008333	0.000993	0.007341	0.136230
437.85	1.01	0.12	0.008333	0.000986	0.007347	0.136102 0.136038
437.86 437.88	1.02	0.12	0.008333	0.000982	0.007351	0.135914
437.89	1.03	0.12	0.008333	0.000972	0.007361	0.135852
437.90	1.03	0.12	0.008333	0.000969	0.007364	0.135791
437.91	1.04	0.12	0.008333	0.000966	0.007368	0.13573
437.96	1.05	0.12	0.008333	0.000950	0.007384	0.135433
437.98	1.06	0.12	0.008333	0.000943	0.007393	0.13526
438.00	1.07	0.12	0.008333	0.000937	0.007396	0.135203
438.01	1.07	0.12	0.008333	0.000934	0.007399	0.135147
438.02	1.07	0.12	0.008333	0.000931	0.007402	0.135091
438.02 438.03	1.06	0.12	0.008333	0.000943	0.007390	0.135319
438.04	1.08	0.12	0.008333	0.000925	0.007408	0.13498

Temp	$T_2$	$T_2^*$	1/T2*	$1/T_2$	$y=1/T_2^{\bullet}-1/T_2$	1/y
438.05	1.08	0.12	0.008333 0.008333	0.000922	0.007411	0.134926
438.05	1.09	0.12	0.008333	0.000919	0.007411	0.134926
438.07	1.10	0.12	0.008333	0.000909	0.007424	0.134694
438.08	1.10	0.12	0.008333	0.000913	0.007420	0.134764
438.08	1.10	0.12	0.008333	0.000913	0.007420	0.134764
438.09	1.10	0.12	0.008333	0.000910	0.007423	0.134711
438.09	1.10	0.12	0.008333	0.000910	0.007423	0.134711
438.10	1.10	0.12	0.008333	0.000907	0.007416	0.134658
438.10	1.09	0.12	0.008333	0.000917	0.007416	0.134845
438.11	1.11	0.12	0.008333	0.000904	0.007429	0.134606
438.11	1.08	0.12	0.008333	0.000926	0.007407	0.135000
438.12	1.11	0.12	0.008333	0.000901	0.007432	0.134554
438.15	1.12	0.12	0.008333	0.000893	0.007440	0.134502
438.16	1.12	0.12	0.008333	0.000893	0.007440	0.134400
438.26	1.14	0.12	0.008333	0.000877	0.007456	0.134118
438.27	1.13	0.12	0.008333	0.000885	0.007448	0.134257
438.28	1.13	0.12	0.008333	0.000885	0.007448	0.134257
438.38	1.15	0.12	0.008333	0.000873	0.007460	0.134049
438.49	1.16	0.12	0.008333	0.000862	0.007471	0.133846
438.50	1.15	0.12	0.008333	0.000870	0.007464	0.133981
438.51	1.15	0.13	0.007692	0.000870	0.006823	0.146569
438.61	1.16	0.12	0.008333	0.000862	0.007471	0.133846
438.62	1.16	0.12	0.008333	0.000862	0.007471 0.006838	0.133846
438.73	1.17	0.13	0.007692	0.000855	0.006838	0.146250
438.85	1.18	0.13	0.007692	0.000847	0.006845	0.146095
438.86	1.18	0.13	0.007692	0.000850	0.006842	0.146146
438.98	1.18	0.13	0.007692	0.000847	0.006845	0.146095
439.10	1.19	0.13	0.007692	0.000840	0.006852	0.145943
439.11	1.18	0.13	0.007692	0.000845	0.006847	0.146044
439.35	1.20	0.13	0.007692	0.000833	0.006859	0.145794
439.36	1.19	0.13	0.007692	0.000838	0.006854	0.145893
439.48	1.20	0.13	0.007692	0.000833	0.006859	0.145794
439.49	1.20	0.13	0.007692	0.000833	0.006859	0.145794
439.61	1.20	0.13	0.007692 0.007692	0.000833	0.006859	0.145794
439.75	1.20	0.13	0.007143	0.000833	0.006310	0.158491
440.01	1.20	0.14	0.007143	0.000833	0.006310	0.158491
440.15	1.20	0.14	0.007143	0.000833	0.006310	0.158491
440.28	1.20	0.14	0.007143	0.000833	0.006310	0.158491
440.42	1.20	0.14	0.007143	0.000833	0.006310	0.158491
440.55	1.20	0.14	0.007143	0.000833	0.006310	0.158491
440.82	1.20	0.15	0.006667	0.000833	0.005833	0.171429
440.96	1.20	0.15	0.006667	0.000833	0.005833	0.171429
441.09	1.20	0.15	0.006667	0.000833	0.005833	0.171429
441.23	1.20	0.15	0.006667	0.000833	0.005833	0.171429
441.36	1.20	0.15	0.006667	0.000833	0.005833	0.171429
441.77	1.20	0.15	0.006667 0.006667	0.000833	0.005833	0.171429
442.04	1.20	0.15	0.006667	0.000833	0.005833	0.171429
442.31	1.20	0.15	0.006667	0.000833	0.005833	0.171429
442.58	1.20	0.15	0.006667	0.000833	0.005833	0.171429
442.71	1.20	0.15	0.006667	0.000833	0.005833	0.171429
443.12	1.20	0.16	0.006250	0.000833	0.005417	0.184615
443.26	1.19	0.16	0.006250	0.000840	0.005410	0.184854
443.39	1.19	0.16	0.006250	0.000840	0.005410	0.184854

Temp	$T_2$	$T_2^*$	1/T2*	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
443.40	1.19	0.16	0.006250	0.000840	0.005410	0.184854
443.53	1.19	0.16	0.006250	0.000840	0.005410	0.184854
443.67	1.19	0.16	0.006250	0.000840	0.005410	0.184854
443.81	1.19	0.16	0.006250	0.000840	0.005410	0.184854
444.08	1.19	0.16	0.006250	0.000840	0.005410	0.184854
444.22	1.18	0.16	0.006250	0.000847	0.005403	0.185098
444.36	1.18	0.16	0.006250	0.000847	0.005403	0.185098
444.63	1.18	0.16	0.006250	0.000847	0.005395	0.185098
445.05	1.17	0.16	0.006250	0.000855	0.005395	0.185347
445.32	1.17	0.16	0.006250	0.000855	0.005395	0.185347
445.47	1.16	0.16	0.006250	0.000862	0.005388	0.185600
445.87	1.16	0.16	0.006250	0.000862	0.005388	0.185600
445.88	1.16	0.16	0.006250	0.000862	0.005388	0.185600
446.15	1.15	0.16	0.006250	0.000870	0.005380	0.185859
446.43	1.15	0.16	0.006250	0.000870	0.005380	0.185859
446.71	1.14	0.16	0.006250	0.000877	0.005373	0.186122
446.98	1.14	0.16	0.006250	0.000877	0.005373	0.186122
447.12	1.14	0.16	0.006250	0.000877	0.005373	0.186122
447.27	1.13	0.16	0.006250 0.006250	0.000885	0.005365	0.186392
447.68	1.13	0.16	0.006250	0.000885	0.005365	0.186392
447.96	1.13	0.16	0.006250	0.000885	0.005365	0.186392
448.10	1.12	0.16	0.006250	0.000893	0.005357	0.186667
448.24	1.12	0.16	0.006250	0.000893	0.005357	0.186667
448.38	1.12	0.16	0.006250	0.000893	0.005357	0.186667
448.52	1.11	0.16	0.006250	0.000901	0.005349	0.186947
448.66	1.11	0.16	0.006250	0.000901	0.005349	0.186947
448.80	1.11	0.16	0.006250	0.000901	0.005349	0.186947
448.94	1.11	0.16	0.006250	0.000901	0.005349	0.186947
449.08	1.10	0.16	0.006250	0.000909	0.005341	0.187234
449.21 449.36	1.10	0.16	0.006250 0.006250	0.000909	0.005341 0.005337	0.187234
449.50	1.09	0.16	0.006250	0.000917	0.005333	0.187527
449.64	1.09	0.16	0.006250	0.000917	0.005333	0.187527
449.78	1.08	0.16	0.006250	0.000926	0.005324	0.187826
449.92	1.08	0.16	0.006250	0.000926	0.005324	0.187826
449.93	1.08	0.16	0.006250	0.000926	0.005324	0.187826
450.07	1.08	0.16	0.006250	0.000930	0.005320	0.187978
450.21	1.07	0.16	0.006250	0.000935	0.005315	0.188132
450.35	1.07	0.16	0.006250	0.000935	0.005315	0.188132
450.49	1.07	0.16	0.006250	0.000935	0.005315	0.188132
450.63	1.06	0.16	0.006250	0.000943	0.005307 0.005307	0.188444
450.78	1.05	0.15	0.006250	0.000943	0.005714	0.175000
450.92	1.05	0.15	0.006667	0.000952	0.005714	0.175000
450.93	1.05	0.15	0.006667	0.000952	0.005714	0.175000
451.08	1.04	0.15	0.006667	0.000962	0.005705	0.175281
451.21	1.04	0.15	0.006667	0.000962	0.005705	0.175281
451.22	1.04	0.15	0.006667	0.000962	0.005705	0.175281
451.37	1.03	0.15	0.006667	0.000971	0.005696	0.175568
451.38	1.03	0.15	0.006667	0.000976	0.005691	0.175714
451.52	1.02	0.15	0.006667	0.000980	0.005686	0.175862
451.53	1.02	0.15	0.006667	0.000980	0.005686	0.175862
451.67 451.81	1.02	0.15	0.006667 0.006667	0.000985	0.005681 0.005677	0.176012
451.82	1.01	0.15	0.006667	0.000990	0.005677	0.176163
451.83	1.00	0.15	0.006667	0.001000	0.005667	0.176471
451.84	1.00	0.15	0.006667	0.001000	0.005667	0.176471
451.85	1.00	0.15	0.006667	0.001005	0.005662	0.176627
451.86	0.99	0.15	0.006667	0.001010	0.005657	0.176786
451.87	0.99	0.15	0.006667	0.001015	0.005651	0.176946
452.01	0.98	0.15	0.006667	0.001020	0.005646	0.177108

Temp	Т,	$T_2^*$	1/T2*	1/T <sub>2</sub>	$y=1/T_2^*-1/T_2$	1/y
Temp	12	-2	1/12	1/12	y-412 412	117
452.02	0.98	0.15	0.006667	0.001020	0.005646	0.177108
452.16	0.98	0.15	0.006667	0.001026	0.005641	0.177273
452.31	0.97 0.97	0.15	0.006667	0.001031	0.005636	0.177439
452.45 452.59	0.96	0.15	0.006667 0.006667	0.001031	0.005636	0.177778
452.73	0.96	0.15	0.006667	0.001042	0.005625	0.177778
452.87	0.96	0.15	0.006667	0.001042	0.005625	0.177778
453.01	0.95	0.15	0.006667	0.001053	0.005614	0.178125
453.15	0.95	0.15	0.006667	0.001053	0.005614	0.178125
453.29	0.95	0.15	0.006667	0.001053	0.005614	0.178125 0.178125
453.43 453.57	0.95	0.15	0.006667	0.001053	0.005614	0.178125
453.71	0.94	0.15	0.006667	0.001064	0.005603	0.178481
453.85	0.94	0.15	0.006667	0.001064	0.005603	0.178481
453.99	0.94	0.15	0.006667	0.001064	0.005603	0.178481
454.13	0.94	0.15	0.006667	0.001064	0.005603	0.178481
454.27 454.41	0.93	0.15	0.006667 0.006667	0.001075	0.005591	0.178846
454.41	0.93	0.15	0.006667	0.001075	0.005591	0.178846
454.69	0.93	0.14	0.007143	0.001081	0.006062	0.164968
454.83	0.92	0.14	0.007143	0.001087	0.006056	0.165128
454.97	0.92	0.14	0.007143	0.001087	0.006056	0.165128
455.11	0.92	0.14	0.007143	0.001087	0.006056	0.165128
455.25 455.39	0.92 0.91	0.14	0.007143	0.001087	0.006056	0.165128
455.53	0.91	0.14	0.007143	0.001099	0.006044	0.165455
455.67	0.91	0.14	0.007143	0.001099	0.006044	0.165455
455.80	0.91	0.14	0.007143	0.001099	0.006044	0.165455
455.94	0.91	0.14	0.007143	0.001099	0.006044	0.165455
456.08	0.90	0.14	0.007143	0.001111	0.006032	0.165789
456.22 456.36	0.90	0.14	0.007143	0.001111	0.006032 0.006032	0.165789
456.50	0.90	0.14	0.007143	0.001111	0.006032	0.165789
456.64	0.89	0.14	0.007143	0.001124	0.006019	0.166133
456.78	0.89	0.14	0.007143	0.001124	0.006019	0.166133
457.05	0.89	0.14	0.007143	0.001124	0.006019	0.166133
457.06 457.20	0.89	0.14	0.007143	0.001124	0.006019	0.166133
457.20	0.88	0.14	0.007143	0.001124	0.006006	0.166486
457.48	0.88	0.14	0.007143	0.001136	0.006006	0.166486
457.75	0.88	0.14	0.007143	0.001136	0.006006	0.166486
457.89	0.88	0.14	0.007143	0.001136	0.006006	0.166486
457.90	0.87	0.14	0.007143	0.001149	0.005993	0.166849
458.04 458.17	0.87	0.14	0.007143	0.001149	0.005993	0.166849
458.31	0.87	0.14	0.007143	0.001149	0.005993	0.166849
458.45	0.87	0.14	0.007143	0.001149	0.005993	0.166849
458.59	0.86	0.14	0.007143	0.001163	0.005980	0.167222
458.73	0.86	0.14	0.007143	0.001163	0.005980	0.167222
458.87	0.86	0.14	0.007143	0.001163	0.005980	0.167222
459.01 459.14	0.86	0.14	0.007143	0.001163	0.005980	0.167222
459.28	0.86	0.14	0.007143	0.001163	0.005980	0.167222
459.56	0.85	0.14	0.007143	0.001176	0.005966	0.167606
459.70	0.85	0.13	0.007692	0.001176	0.006516	0.153472
459.84	0.85	0.13	0.007692	0.001176	0.006516	0.153472
460.11 460.25	0.85	0.13	0.007692	0.001176	0.006516	0.153472
460.23	0.84	0.13	0.007692	0.001190	0.006502	0.153803
460.66	0.84	0.13	0.007692	0.001190	0.006502	0.153803
460.80	0.84	0.13	0.007692	0.001190	0.006502	0.153803
461.07	0.84	0.13	0.007692	0.001190	0.006502	0.153803
461.21	0.84	0.13	0.007692	0.001190	0.006502	0.153803

Temp	$T_2$	$T_2^*$	$1/T_{2}^{*}$	$1/T_2$	$y=1/T_2^*-1/T_2$	1/y
•	-	-		. 2		
461.35	0.83	0.13	0.007692	0.001205	0.006487	0.154143
461.49	0.83	0.13	0.007692	0.001205	0.006487	0.154143
461.63	0.83	0.13	0.007692	0.001205	0.006487	0.154143
461.77	0.83	0.13	0.007692	0.001205	0.006487	0.154143
461.90	0.83	0.13	0.007692	0.001205	0.006487	0.154143
462.18	0.82	0.13	0.007692	0.001220	0.006473	0.154493
462.31	0.82	0.13	0.007692	0.001220	0.006473	0.154493
462.45	0.82	0.13	0.007692	0.001220	0.006473	0.154493
462.59	0.82	0.13	0.007692	0.001220	0.006473	0.154493
462.86	0.82	0.13	0.007692	0.001220	0.006473	0.154493
463.01	0.82	0.13	0.007692	0.001220	0.006473	0.154493
463.28	0.81	0.13	0.007692	0.001235	0.006458	0.154853
464.10	0.81	0.13	0.007692	0.001235	0.006458	0.154853
464.38	0.80	0.13	0.007692	0.001250	0.006442	0.155224
465.34	0.80	0.13	0.007692	0.001258	0.006434	0.155414
465.61	0.79	0.13	0.007692	0.001266	0.006426	0.155606
466.59	0.79	0.13	0.007692	0.001266	0.006426	0.155606

Final Result

The final form of the data after smoothing and parameterization is given here.

As in the previous data record,  $y = 1/T_2^* - 1/T_2$ .

Temp	y(v_)	error	y(v_)	еггог
(K)	(ms)	(ms)	(ms)	(ms)
(11)	(1113)	(1115)	(1110)	(1115)
77.00000	2.71953	0.08369	1.38910	1.35183
78.97487	2.71057	0.08379	1.39287	1.34382
80.94974	2.70167	0.08392	1.39649	1.33588
82.92461	2.69106	0.08406	1.40011	1.32643
84.89948	2.67531	0.08419	1.40376	1.31243
86.87434	2.66661	0.08432	1.40741	1.30476
88.84921	2.65796	0.08446	1.41108	1.29717
90.82409	2.64937	0.08442	1.41224	1.28963
92.79896	2.63934	0.08452	1.41524	1.28086
94.77383	2.62391	0.08466	1.41892	1.26739
96.74870	2.61551	0.08465	1.42002	1.26011
98.72356	2.60709	0.08475	1.42293	1.25290
100.69843	2.59750	0.08489	1.42665	1.24465
102.67331	2.58234	0.08487	1.42802	1.23160
104.64818	2.57417	0.08496	1.43085	1.22463
106.62305	2.56487	0.08497	1.43212	1.21676
108.59792	2.54990	0.08506	1.43489	1.20404
110.57278	2.54186	0.08507	1.43623	1.19730
112.54765	2.53293	0.08513	1.43911	1.18979
114.52252	2.51813	0.08515	1.44052	1.17739
116.49740	2.51030	0.08523	1.44317	1.17088
118.47227	2.50164	0.08523	1.44482	1.16371
120.44714	2.48704	0.08531	1.44741	1.15162
122,42200	2.47858	0.08534	1.44896	1.14470
124.39687	2.46412	0.08540	1.45165	1.13284
126.37174	2.45658	0.08543	1.45329	1.12669
128.34662	2.44844	0.08548	1.45591	1.12009

Temp	y(v_)	error	y(v,)	error
130.32149	2.43418	0.08552	1.45762	1.10851
132.29636 134.27122	2.42621 2.41210	0.08557	1.46018	1.10213
136.24609	2.40434	0.08566	1.46446	1.08459
138.22096	2.39042	0.08569	1.46646	1.07345
140.19583	2.38288	0.08562	1.46696	1.06748
142.17070	2.36874	0.08567	1.46937	1.05627
144.14557	2.35507	0.08572	1.47134	1.04547
146.12044	2.34783	0.08576	1.47366	1.03982
148.09531	2.33427	0.08580	1.47585	1.02921
150.07018	2.32713	0.08584	1.47812	1.02374
152.04504	2.31352	0.08589	1.48039	1.01322
154.01993	2.30012	0.08582	1.48088	1.00294
155.99480	2.29315	0.08575	1.48137	0.99776
157.96967 159.94453	2.27976	0.08569 0.08562	1.48186 1.48235	0.97765
161.91940	2.25324	0.08546	1.48127	0.96783
163.89427	2.24009	0.08518	1.47825	0.95815
165.86914	2.22699	0.08490	1.47523	0.94861
167.84401	2.21397	0.08462	1.47223	0.93922
169.81888	2.20108	0.08425	1.46784	0.92997
171.79375	2.18826	0.08377	1.46142	0.92085
173.76862	2.17556	0.08329	1.45506	0.91187
175.74348 177.71835	2.16300 2.15061	0.08283	1.44861	0.90302
179.69324	2.13835	0.08166	1.43126	0.88570
181.66811	2.12626	0.08103	1.42167	0.87722
183.64297	2.11433	0.08043	1.41207	0.86887
185.61784	2.09727	0.07982	1.40265	0.85680
187.59271	2.08532	0.07918	1.39226	0.84848
189.56758	2.06881	0.07848	1.38087	0.83687
191.54245	2.05214	0.07784	1.37103	0.82524
193.51732 195.49219	2.03079	0.07708	1.35920 1.34846	0.81040
197.46706	1.99357	0.07572	1.33941	0.78489
199.44193	1.97291	0.07495	1.32845	0.77084
201.41679	1.95263	0.07417	1.31780	0.75716
203.39168	1.92841	0.07337	1.30756	0.74092
205.36655	1.90846	0.07256	1.29767	0.72767
207.34142	1.88954	0.07170	1.28828	0.71512
209.31628	1.87105	0.07083	1.27926	0.70289
211.29115	1.85303	0.06996	1.27050	0.69098
213.26602 215.24089	1.83936 1.82655	0.06907 0.06818	1.26212 1.25393	0.68185 0.67329
217.21576	1.81406	0.06732	1.24575	0.66488
219.19063	1.80182	0.06647	1.23773	0.65663
221.16550	1.78988	0.06567	1.23003	0.64853
223.14037	1.77817	0.06502	1.22441	0.64058
225.11523	1.77026	0.06440	1.21870	0.63494
227.09010	1.75973	0.06381	1.21328	0.62767
229.06499	1.75216	0.06334	1.21001	0.62217
231.03986 233.01472	1.74211 1.73160	0.06288 0.06243	1.20670	0.61514
234.98959	1.72129	0.06201	1.20340	0.60058
236.96446	1.71118	0.06169	1.19916	0.59349
238.93933	1.70132	0.06126	1.19582	0.58653
240.91420	1.69173	0.06084	1.19253	0.57970
242.88907	1.67926	0.06041	1.18931	0.57123
244.86394	1.66930	0.05999	1.18610	0.56418
246.83881	1.65456	0.05956	1.18297	0.55442
248.81367 250.78854	1.64138	0.05912 0.05856	1.17998 1.17482	0.54559
250.78854	1.62928	0.05856	1.17482	0.53743
	T.07403	2.03000		

Temp	y(v_)	error	y(v <sub>+</sub> )	error
254.73830	1.59725	0.05744	1.16493	0.51682
256.71317	1.58185	0.05676	1.15802	0.50698
258.68802	1.56518	0.05609	1.15125	0.49652
260.66290	1.54811	0.05541	1.14461	0.48595
262.63776	1.53141	0.05465	1.13607	0.47570
264.61264	1.51511	0.05389	1.12759	0.46578
266.58749	1.49704	0.05314	1.11929	0.45502
268.56238	1.48066	0.05240	1.11117	0.44531
270.53723	1.46342	0.05167	1.10322	0.43527
272.51212	1.44777	0.05096	1.09538	0.42616
274.48697	1.43322	0.05018	1.08591	0.41774
276.46185	1.41898	0.04948	1.07812	0.40957
278.43671	1.40495	0.04880	1.07068	0.40163
280.41159	1.39122	0.04807	1.06169	0.39393
282.38647	1.37768	0.04741	1.05418	0.38644
284.36133	1.36609	0.04685	1.04855	0.37998
286.33621	1.35544	0.04625	1.04174	0.37405
288.31107	1.34488	0.04571	1.03616	0.36826
290.28595	1.33446	0.04520	1.03088	0.36260
292.26080	1.32568	0.04471	1.02559	0.35780
294.23569 296.21054	1.31926	0.04428	1.02173	0.35416
	1.30713	0.04388	1.01819	
298.18542 300.16028	1.30713	0.04356	1.01587	0.34740
302.13516	1.30022	0.04302	1.01393	0.34324
304.11002	1.29807	0.04281	1.01317	0.34324
306.08490	1.29809	0.04267	1.01347	0.34145
308.05978	1.29882	0.04261	1.01574	0.34145
310.03464	1.30222	0.04258	1.01839	0.34272
312.00952	1.30725	0.04262	1.02216	0.34478
313.98438	1.31219	0.04274	1.02747	0.34687
315.95926	1.31982	0.04295	1.03443	0.35025
317.93411	1.32926	0.04320	1.04202	0.35453
319.90900	1.34011	0.04345	1.04962	0.35955
321.88385	1.35196	0.04373	1.05718	0.36513
323.85873	1.36535	0.04401	1.06485	0.37153
325.83359	1.37991	0.04419	1.07033	0.37858
327.80847	1.39612	0.04431	1.07444	0.38655
329.78336	1.41221	0.04443	1.07864	0.39459
331.75821	1.42893	0.04459	1.08408	0.40305
333.73309	1.44864	0.04488	1.09266	0.41315
335.70795	1.46845	0.04530	1.10410	0.42346
337.68283	1.48740	0.04586	1.11887	0.43351
339.65768	1.50511	0.04659	1.13683	0.44310
341.63257	1.52342	0.04745	1.15730	0.45315
343.60742	1.54348	0.04840	1.17931	0.46429
345.58231	1.56233	0.04947	1.20307	0.47495
347.55716	1.58017	0.05067	1.22858	0.48517
349.53204	1.60020	0.05195	1.25490	0.49665
351.50690	1.62253	0.05332	1.28207	0.50944
353.48178	1.64743	0.05471	1.30887	0.52372
355.45667	1.67487	0.05611	1.33518	0.53959
357.43152 359.40640	1.72611	0.05760	1.36229	0.55514
		0.05917		
361.38126 363.35614	1.75156	0.06234	1.41784	0.58603
365.33099	1.80973	0.06234	1.44475 1.47247	0.60245
367.30588	1.84934	0.06576	1.50104	0.62197
369.28073	1.89324	0.06771	1.53170	0.67394
371.25562	1.94348	0.06990	1.56539	0.70603
373.23047	2.00133	0.07232	1.60177	0.74395
375.20535	2.06176	0.07506	1.64171	0.78502
377.18021	2.12269	0.07800	1.68306	0.82781
		0.07000	1.00000	0.02/01

Temp	y(v_)	error	y(v <sub>↓</sub> )	error	16
379.15509	2.18643	0.08139	1.72867	0.87381	
381.12997	2.25460	0.08545	1.78134	0.92423	
383.10483	2.32906	0.08999	1.83832	0.98078	
385.07971	2.41275	0.09518	1.90174	1.04639	
387.05457	2.50098	0.10103	1.97057	1.11804	
389.02945	2.60314	0.10766	2.04514	1.20402	
391.00430	2.71461	0.11451	2.11869	1.30142	
392.97919	2.83381	0.12185	2.19418	1.40982	
394.95404	2.96450	0.13023	2.27692	1.53394	
396.92892	3.09554	0.13904	2.36022	1.66421	
398.90378	3.23023	0.14879	2.44920	1.80446	
400.87866	3.37044	0.15941	2.54219	1.95760	
402.85352	3.49244	0.16979	2.63100	2.09699	
404.82840	3.61452	0.17858	2.70448	2.23650	
406.80328	3.79443	0.18672	2.77113	2.44515	
408.77814	4.01106	0.19337	2.82388	2.70708	
410.75302	4.26331	0.19941	2.87009	3.03007	
412.72787	4.53597	0.20600	2.91873	3.40238	
414.70276	4.80554	0.21456	2.97980	3.79558	
416.67761	5.04787	0.22637	3.06137	4.17307	
418.65250	5.22926	0.24166	3.16219	4.47708	
420.62735		0.26541	3.31357	4.60914	
422.60223	5.28578	0.29802	3.50790	4.64241	
424.57709	5.31163	0.34858	3.79148	4.76383	
426.55197	5.30460	0.42912	4.20250	4.85756	
428.52682	5.22367	0.53700	4.69689	4.87099	
430.50171	5.42970	0.74236	5.66242	5.38637	
432.47659	6.90695	1.54949	8.28763	8.50566	
434.45145	8.59154	1.13574	6.79950	13.40893	
436.42633	7.03196	0.95107	5.96991	10.08016	
438.40118	6.85806	1.01048	6.43197	9.34710	
440.37607	6.58980	0.78845	5.51359	8.55358	
442.35092	6.22964	0.70402	5.14628	7.65463	
444.32581	6.13478	0.64676	4.88276	7.43908	
446.30066	5.63787	0.61840	4.70541	6.45051	
448.27554	5.65882	0.64816	4.79434	6.51676	
450.25040	5.75241	0.72497	5.08521	6.73374	
452.22528	5.78912	0.80525	5.38815	6.87041	
454.20013	5.88565	0.92126	5.82146	7.15564	
456.17502	5.96927	1.02512	6.17718	7.40876	
458.14990	6.00217	1.10161	6.41411	7.53802	
460.12476	6.06735	1.16907	6.61097	7.72910	
462.09964	6.10555	1.25948	6.87507	7.86571	
464.07449	6.18175	1.36188	7.16536	8.09659	
466.04938	6.25734	1.47744	7.48114	8.33779	
468.02423	6.33087	1.60845	7.82544	8.58993	
469.99911	6.39180	1.75797	8.20135	8.82610	

Refer to Figs. 4-1, 4-2, 4-3, 4-4, 4-5, 4-6, 4-7, 4-8, 5-1 and 5-2 for graphs of these data.

#### APPENDIX D HIGGINS' UREA-WATER DATA

A search of the laboratory records revealed five original data sets taken on urea-water by Higgins [1990]. The five data sets are labelled by this author as H307000 - urea-water standard, H311047 - 46.7 Gy, H312073 - 72.9 Gy, H313130 - 129.6 Gy and H306292 - 291.7 Gy. The labels are not random. The H3 stands for Higgins' third data disk. The second and third numbers are between one and twenty, inclusive, and are the record number on the disk. The last three numbers give the appproximate dose in Gy, as per Higgins' notes. The original FIDs are illustrated in the five graphs that follow.

The results of analyzing this data with nonlinear least squares methods is given graphically in Fig. 5-4. The following are the fit of files for these data sets.

```
H307000.prn

4.520591110488192E-002

4674.239909083890000

-3.225104101660158

5.399570182234144E-004
```

CHISQ = 7.296774898809715E-003

alpha	covar
146.787165795069800	2.517243557192191E-002
6.516362263841919E-005	94.352010331398970
3.936498396815731E-001	-6.658807383607045E-002
9907.075260872778000	-2.700016238427062E-004
7.785780193701891E-008	4.778276231816261E+007
1.281891243273161E-004	-21257.353723120680000
1.668509778349226E-003	-8.676029972964042E-001
2.894812854049731E-001	12.936886850625870
10.103737765177400	6.123782464525720E-004
921734.651014549300000	3.981825679220425E-006
35T134.03T0T4343300000	0.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,

```
H311047.prn
 5.069683276839258E-002
   4687.731977405945000
      2.884462506267060
 3 002926345499809E-004
CHISO =
          4.012654724578882E-003
        alpha
                                  covar
                           1.245087734669910E-001
     48.115494391086140
                             1021.220061313626000
 4.310751714507418E-005
                          -4.894423787076335E-001
 2.500609583256638E-001
   8734.463070783528000
                          -5.624195766378685E-004
 1.518804559558481E-008
                           3.858812596282219E+008
 3.795413125974999E-005
                          -128815.583609613900000
 4.091679506429544E-003
                               -3.842152928110857
 1.149553489029661E-001
                               51,904826562938840
     24.235081101806370
                           1.845941897487347E-003
1919979.599118864000000
                           3.064312418700144E-006
H312073.prn
 5.053842655811746E-002
   4699.473904927140000
     -2.866502250698467
 5.705481424903584E-004
CHISO =
          2.464791871599152E-002
        alpha
                                  covar
                           2.054934280612495E-002
    167.136703056491300
                               55.291284639487930
 5.507563176143528E-005
 3.665936875997666E-001
                          -3.981329173546847E-002
  11374.597975212190000
                          -2.130184568169568E-004
 1.150638611224113E-007
                           3.149734927418510E+007
                           -14488.131990009210000
 1.812936829528240E-004
                          -4.980115967336476E-001
 1.295185634576994E-003
                                9.204892322412517
 3.952394687506329E-001
      8.550600436277502
                           3.584961797629789E-004
1096016.286527734000000
                          3.120919834416422E-006
H313130.prn
 6.260460293894482E-002
   4664.109456813673000
     -3.043055224530246
4.383617853965778E-004
          1.594514558091109E-002
CHISQ =
        alpha
                                  COVAT
    106.068560966220500
                           3.885627789911571E-002
 7.325821594274412E-005
                              147.394356494475700
```

-8.877664612283782E-002

-2.357109350534046E-004

5.334216151156351E+007

-20962.329070208780000

4.565809055191926E-004

1.894491812929767E-006

-7.569459792970354E-001 10.823069131036250

4.586220988714317E-001

7.858503698313117E-008

1.526488013612077E-004

3.724409024849346E-003

3.908033927854068E-001 23.866966819011910

2155424.660233004000000

13115.693577743930000

```
H306292.prn
4.4836047809007590E-02
 4641.412374532357
-3.023119669483421
6.0036610242618829E-04
CHISO =
          1.4043250407697847E-02
     alpha
                         1.9447844284283272E-02
 176,6002022176529
5.8546275405065102E-05
                          58.04008103019307
0.3693125952999622
                        -4.3935827567207267E-02
                        -2.3980095035310034E-04
 10098.64725639763
1.0554274438526976E-07
                          33798719.04302709
1.5907995383223229E-04
                         -16154.74718594504
1.1467797037305404E-03 -0.6201352905429013
                          10.73076849013346
0.3338719731933741
 7.282730990020938
                         4.6955480568528532E-04
 817942.9873377983
                         4.1799450322602822E-06
```

It was mentioned in Appendix B that the frequency was the easiest NQR parameter to measure. Higgins made all of his measurements at the same applied frequency and the difference frequency varied from 4641 - 4699 Hz. This is well within the 0.05 kHz that the spectrometer was known to vary.

Data Set	Higgins' Results (µs)	Higgins' Errors (μs)	Updated Results (μs)	Updated Errors (μs)
Н307000	607	180	540	2000
H311047	342	100	300	1800
H312073	480	140	570	1800
Н313130	379	110	440	1400
H306292	215	65	600	2000

Table D-1 Comparison of Higgins' analysis and nonlinear least squares analysis.




Figure D-1 Data set H307000.




Figure D-2 Data set H311047.




Figure D-3 Data set H312073.




Figure D-4 Data set H313130.




Figure D-5 Data set H306292.

## REFERENCES

- Barkhusian, H.; de Beer, R.; Bovée, W.M.M.J.; van Ormondt, D. Retrieval of frequencies, amplitudes, damping factors, and phases from time-domain signals using a linear least-squares procedure. J. Magn. Reson. 61:465-481; 1985.
- Barkhusian, H.; de Beer, R.; van Ormondt, D. Improved algorithm for noniterative time-domain model fitting exponentially damped magnetic resonance signals. J. Magn. Reson. 73:553-557; 1987.
- Blakeley, R.L.; Trestor, A.; Andrews, R.K.; Zerner, B. Nickel(II)-promoted ethanolysis and hydrolysis of N-(2-pyridylmethyl)urea. A model for urease. J. Am. Chem. Soc. 104:612-614; 1982.
- Box, H.C. Radiation effects: ESR and ENDOR analysis. New York: Academic Press;
- Buxton, G.V. Radiation chemistry of the liquid state: (1) water and homogeneous aqueous solutions. Farhataziz; Rodgers, M.A.J. Radiation chemistry: principles and applications. New York: VCH Publishers; 1987.
- Caron, A.; Donohue, J. Three-Dimensional Refinement of Urea. Acta. Cryst. 17:544-546: 1964.
- Chen, C.H.; Dodgen, H.W. Nuclear quadrupole resonance of nitrogen-14 in guanidine complexes, cyanoguanidine, and substituted ureas. J. Magn. Reson. 22:139-147; 1976.
- Chiba, T.; Toyama, M.; Morino, Y. Nuclear quadrupole resonance spectra of N<sup>14</sup> in urea crystal. J. Phys. Soc. Japan 14:379-380; 1959.
- Cleveland, W.S.; Devlin, S.J. Locally weighted regression: An approach to regression analysis by local fitting. J. Am. Stat. Assn. 83:596-610;1988.
- Conner, C.; Chang J.; Pines, A. Magnetic resonance spectrometer with a dc SQUID detector. Rev. Sci. Instrum. 61:1059-1063; 1990.

- Cramér, H. Mathematical methods of statistics. Princeton, NJ: Princeton Univ. Press;
- Darmois, G. Sur les limites de la dispersion de certaines estimations. Rev. Inst. Internat. Statist. 13:9-5: 1945. (in French)
- Davies, M.; Whitting, I. J. A modified form of Levenberg's correction. Lootsma, F. A., Numerical methods for non-linear optimization. New York: Academic Press; 1972.
- de Beer, R.; van Ormondt, D. Analysis of NMR data using time domain fitting procedures. Rudin, M. and Seelig, J. NMR 26 In vivo magnetic resonance spectroscopy. New York: Springer Verlag Berlin; 1992.
- Dehmelt, H-G.; Krüger, H. Kernquadrupolfrequenzen in festen dichloräthylen. Naturwiss. 37:111-112; 1950. (in German)
- Dinesh; Rogers, M.T. Nuclear quadrupole resonances in 1,3-dimethylurea and tetramethylurea. J. Chem. Phys. 57:3726-3728; 1972.
- Duchesne, J.; Monfils, A.; Garson J. Nuclear quadrupole resonance of γ-irradiated para-dichlorobenze. J. Chem. Phys. 23:1969; 1955.
- Duchesne, J.; Monfils, A.; Depireux, J. Résonance nucléaire. Compt. Rend. 243:259-261; 1956. (in French)
- Ewing, D. Synergistic damage from H<sub>2</sub>O<sub>2</sub> and OH radicals in irradiated cells. Radiat. Res. 94:171-189: 1983.
- Farrar, T.C.; Becker, E.D. Pulse and fourier transform NMR: introduction to theory and methods. New York: Academic Press; 1971.
- Fréchet, M. Sur l'extension de certains évaluations statistiques au cas des petites échantillons. Rev. Inst. Internat. Statist. 11:185-205; 1943.
- Fritchie, C.J., Jr.; McMullan, R.K. Neutron diffraction study of the 1:1 urea:hydrogen peroxide complex at 81 K. Acta Cryst. B37:1086-1091; 1981.
- Fukushima, E.; Roeder, S.B.W. Experimental pulse NMR: a nuts and bolts approach. Reading, MA: Addison-Wesley; 1981.
- Guibé, L. Résonance magnétique nucléaire sur la résonance quadrupolaire des noyaux d'azote dans l'uree. Compt. Rend. 250:1635-1636; 1960. (in French)

- Hanrahan, R.J. A Co<sup>60</sup> gamma irradiator for chemical research. Int. J. Appl. Rad. Isot. 13:254-255; 1962.
- Heaton, N.J.; Vold, R.L.; Vold, R.R. Deuterium quadrupole echo study of urea motion in urea/n-alkane inclusion compounds. J. Am. Chem. Soc. 111:3211; 1989.
- Higgins, G.A. Biochemical model dosimetry system based on nuclear quadrupole resonance of crystallized hydrated urea. Gainesville: Univ. of Florida; 1990. Unpublished M.S. Project.
- Hintenlang, D.E.; Higgins, G.A. Radiation response of hydrated urea evaluated using <sup>14</sup>N nuclear quadrupole resonance. Nuc. Sci. Eng. 112:181-184; 1992.
- Hintenlang, D.E.; Iselin, L.H.; Jamil, K. Biologically-equivalent dosimetry from nitrogen-14 nuclear quadrupole resonance. IRPA8 The 8th Meeting of the International Radiation Protection Association, Montréal, Canada, July, 1992.
- Hintenlang, D.E.; Jamil, K. Neutron damage studies of organic materials with NQR spectroscopy. American Nuclear Society Annual Meeting Abstracts, Boston, MA:169, 1992.
- Hill, R.O., Jr. Elementary linear algebra. Orlando, FL: Academic Press; 1986.
- Hunt, M.J.; Mackay, A.L. Deuterium and nitrogen pure quadrupole resonance in deuterated amino acids. J. Magn. Reson. 15:401-414; 1974.
- Iselin, L.H. An analytical method for estimating the <sup>14</sup>N nuclear quadrupole resonance parameters of organic compounds with complex free induction decays for radiation effects studies. Gainesville: Univ. of Florida; 1992. M.Eng. Thesis.
- Iselin, L.H.; Hintenlang, D.E. Feasibility of nuclear quadrupole resonance as a novel dosimetry tool. Health Physics Society Annual Meeting abstracts, Anaheim, CA, Health Phys. 60 Supplement 2:S97; June, 1990
- Iselin, L.H.; Hintenlang, D.E. Energy dependence of gamma-ray effects on hydrated urea using pulsed <sup>14</sup>N nuclear quadrupole resonance techniques. Health Physics Society Annual Meeting Abstracts, Columbus, OH, Health Phys. 62(6) Supplement33; June, 1992.

- Jackson, J.D. Classical electrodynamics. 2nd ed. New York: Wiley; 1975.
- Jamil, K. Effects of ionizing radiation on the environment of nitrogen-14 in organic compounds by nuclear quadrupole resonance. Gainesville: Univ. of Florida; 1992. Ph.D. Thesis.
- Koizumi, M.; Tachibana, A.; Yamabe, T. Reaction ergodography for the hydrolysis of urea. THEOCHEM. 164:37-47; 1988.
- Kung, S.Y.; Arun, K.S.; Bhaskar Rao, D.V. State-space and singular-value decomposition-based approximation methods for the harmonic retrieval problem, J. Opt. Soc. Am. 73:1799-1811; 1983.
- Lawson, C.L.; Hanson, R.J. Solving least squares problems. Prentice-Hall series in automatic computation. Englewood Cliffs, NJ: Prentice-Hall; 1974.
- Leppelmeier, G.W.; Hahn, E.L. Nuclear dipole field quenching of integer spins. Phys. Rev. 141:724-731; 1966.
- Levenberg, K. A method for the solution of certain non-linear problems in least squares, O. Appl. Math. 2:164-168; 1944.
- Lu, C-S; Hughes, E.W.; Giguère, P.A. The Crystal Structure of the Urea-Hydrogen Peroxide Addition Compound CO(NH<sub>2</sub>)<sub>2</sub>\*H<sub>2</sub>O<sub>2</sub>. J. Am. Chem. Soc. 63:1507-1513: 1941.
- Marino R.A. A study of the bonding of nitrogen by nuclear quadrupole resonance. Providence, RI: Brown Univ.; 1969. Ph.D. Thesis.
- Marquart, D. An algorithm for least-square estimation of nonlinear parameters. J. Soc. Ind. Appl. Math. 11:431-441; 1963.
- Maybeck, P.S. Stochastic models estimation and control. New York: Academic Press; 1979.
- Milia, F.K., Hadjoudis, E.K. Crystal structure effect in the  $\gamma$  radiation of p-dichlorobenzene. J. Chem. Phys. 72:4707-4708; 1968.
- Minematsu, M. Nuclear quadrupole resonances of nitrogen in amino and amido compounds. J. Phys. Soc. Jpn. 14:1030-1038; 1959.
- Murgich, J.; Santana R., M. Effect of the oxygen protonation on the electronic structure of urea in the solid state: A <sup>14</sup>N NQR Study. J. Chem. Phys. 74(7):3788-3790: 1981.

- Negita, H.; Kubo, T.; Maekawa, M. <sup>14</sup>N nuclear quadrupole resonances of the molecular complexes of urea. Bull. Chem. Soc. Jpn. 50:2215-2216; 1977.
- Negita, H.; Kubo, T.; Kato, H. <sup>14</sup>N nuclear quadrupole resonances of the molecular complexes of urea. Bull. Chem. Soc. Jpn. 54:391-393; 1981.
- Norton J.P. An Introduction to identification. New York: Academic Press: 1986.
- Oja, T. N<sup>14</sup> NOR in quanidines. Bull. Amer. Phys. Soc. 14:31; 1969a.
- Oja, T. <sup>14</sup>N nuclear quadrupole resonance in ferroelectric guanidines. Phys. Letters 30A:343; 1969b.
- Oja, T. Nitrogen-14 nuclear quadrupole resonance study of the guanidinium ion. J. Chem. Phys. 59:2668-2675: 1973.
- Oja, T.; Petersen, G. Pulsed nuclear quadrupole resonance instrumentation. 1973; 17 p. An application note AN-115. Available from: Matec, Inc., Warwick, RI.
- O'Konski C.T.; Torizuka, K. Relaxation times and saturation of nuclear quadrupole resonance of <sup>14</sup>N in asymmetric field gradients. J. Chem. Phys. 51:461-463; 1969.
- Panin, V.I. Study of kinetics of accumulation of products of  $\gamma$  radiolysis of aliphatic peptides by H NMR method. Khim. Vys. Energ. 19:14-19; 1985.
- Panin, V.I.; Sidorov, P.S.; Usatyi, A.F. Analysis of gamma radiolysis products of aqueous solutions of esters of aliphatic amino acids by PMR method. Khim. Vys. Energ. 21:127-133; 1987.
- Petersen, G. Pulsed nuclear quadrupole resonance instrumentation and study of the nitrogen-14 spectrum and relaxation in sodium-nitrite. Providence: Brown Univ.; 1975. Ph.D. Thesis.
- Petersen, G. Bray, P.J. <sup>14</sup>N nuclear quadrupole resonance and relaxation measurements of sodium nitrite. J. Chem. Phys. 64:522-530; 1976.
- Petersen, G.; Oja, T. A pulsed nuclear quadrupole resonance spectrometer. Smith, J. A. S. Advances in nuclear quadrupole resonance. Vol. 1. New York: Heyden & Sons; 1974: 179-184.
- Pijnappel, W.W.F.; van den Boogaart, A.; de Beer, R.; van Ormondt, D. SVD-based quantification of magnetic resonance signals. J. Magn. Reson. 97:122-134; 1992.

- Poole, C.P., Jr.; Farach, H.A. Theory of magnetic resonance. 2nd ed. New York: Wiley: 1987.
- Press, W.H.; Flannery, B.P.; Teukolsky, S.A.; Vetterling, W.T. Numerical recipes: the art of scientific computing (Fortran version). New York: Cambridge University Press; 1989.
- Randall, J.L. Effects of Crystalline Defects on Pure Quadrupole Resonances.

  Birmingham: Univ. of Alabama; 1959. Ph.D. Thesis.
- Rao, C.R. Information and accuracy obtainable in one estimation of a statistical parameter. Bull. Calcutta Math. Soc. 37:81-91; 1945.
- Rao, C.R. Linear statistical inference and its applications. 2nd. ed. New York: John Wiley & Sons; 1973.
- Rogers, M.T.; Kispert, L.D. Some effects of crystal structure on production of radicals in irradiated organic crystals. Hart, Edwin J. Radiation chemistry. Vol. II. Gases, solids, organic liquids. Advances in chemistry series 82. Washington, DC: American Chemical Society; 1968.
- Sanctuary, B.C.; Krishnan, M.S. Theory of NQR pulses. Z. Naturforsh. 49a:71-79; 1994.
- Sauer, E.G.; Bray, P.J. N-14 nuclear quadrupole resonance in compounds containing N-O bonds. II. hydroxyurea. J. Chem. Phys. 58:2662-2663; 1973.
- Shannon, T.G. An annealing study of gamma-irradiated sodium chlorate using nuclear quadrupole resonance spectroscopy. Troy, NY: Rensselaer Polytechnic Institute; 1971. Ph.D. thesis.
- Slichter, C.P. Principles of magnetic resonance with examples from solid state physics. 2nd ed. Seitz, E. Harper's physics series. New York: Harper and Row: 1990.
- Smith, F.L., editor. The radiotron designer's handbook. 3rd ed. Sydney, Australia: The Wireless Press; 1941.
- Smith, D.H.; Cotts, R.M. Nuclear electric quadrupole and proton magnetic resonances in thiourea. J. Chem. Phys. 41:2403-2416; 1964.
- Subbarao, S.N. Nitrogen-14 nuclear quadrupole resonance study of organic molecular crystals. Providence, RI: Brown Univ.; 1978. Ph.D. Thesis.

- Swallow, A.J. Radiation chemistry of organic compounds. Charlesby, A. International series of monographs on radiation effects in materials. Vol. 2. New York: Pergamon Press; 1960.
- Swaminathan, S.; Craven, B.M. The crystal structure and molecular thermal motion of urea at 12, 60 and 123 K from neutron diffraction. Acta Cryst. B40:300-306: 1984.
- Taylor, J.R. An introduction to error analysis. Mill Valley, CA: University Science Books: 1982.
- Thomasson, D.M. Development and initial characterization of a nuclear magnetic resonance dosimetry system. Madison: Univ. of Wisconsin; 1990. Ph.D. Thesis.
- Tolkachev, V.A. On free radical decay in γ-irradiated organic crystals. Dobó, J.; Hedvig, P. Proceedings of the Third Tihany Symposium on Radiation Chemistry. Budapest: Akadémiai Kiadó; 1972.
- Townes, C.H. Electrostatic field strengths in molecules and nuclear quadrupole moments. Phys. Rev. 2nd Ser. 71:909-910; 1948.
- Townes, C.H.; Daily, B.P. Determination of electronic structure of molecules from nuclear quadrupole effects. J. Chem. Phys. 17:782-796; 1949.
- Vargas, H.; Pelzl, J.; Dimitropoulos, C. <sup>35</sup>Cl NQR studies of irradiation defects in chlorates. J. Magn. Reson. 30:423-429; 1978.
- Watkins, G.D.; Pound, P.V. Phys. Rev. 85:1062; 1952.
- Wheeler, H.A. Simple inductance formulas for radio coils. Proc. IRE 16:1398-1400; 1928.
- Widman, R.H. Shifts of the nuclear quadrupole resonance spectra of <sup>14</sup>N in urea, cyanuric acid, and melamine. J. Chem. Phys. 40:2922-2923; 1963.
- Wong, S. Introductory nuclear physics. Englewood Cliffs, NJ: Prentice-Hall; 1990.
- Willard, J.E. The radiation chemistry of organic solids. Farhataziz; Rodgers, M.A.J. Radiation chemistry: principles and applications. New York: VCH Publishers; 1987.
- Zussman, A. Effect of molecular reorientation in urea on the <sup>14</sup>N PNQR linewidth and relaxation time. J. Chem. Phys. 58:1514-1519; 1973.

## BIOGRAPHICAL SKETCH

Louis Henry Iselin was born 8 February 1966, in Casa Grande, Arizona, the son of William Albin Iselin and Mary Corine (Trinkaus) Iselin. In May, 1984, he was an honor graduate of distinction from Jonesboro Senior High School in Jonesboro, Arkansas. Louis attended The University of Tulsa in Tulsa, Oklahoma, starting August 1984, as a National Merit Scholar and University Honors Scholar. After his freshman year, Louis was awarded the LaFortune Engineering Scholarship, as well. He graduated from The University of Tulsa on 7 May 1988, with a Bachelor of Science in Engineering Physics (cum laude). He was awarded membership in Sigma Pi Sigma National Physics Honorary Society and Tau Beta Pi National Engineering Honor Society (OK B) while at Tulsa. He is a registered Engineer Intern in the State of Oklahoma.

Louis Iselin was offered both of the Department of Energy Nuclear Science and Engineering Fellowships: Nuclear Engineering and Health Physics. He accepted the DOE Health Physics Fellowship and attended graduate school at the University of Florida starting in August 1988. He was elected to membership in the Alpha Nu Sigma National Nuclear Science and Engineering Honor Society in 1989 and served as the President of the Florida Alpha chapter in the 1993-1994 school year.

In May, 1989, Louis married the former Huong Vuong of Tulsa, Oklahoma.

On their honeymoon, the newlyweds spent the summer in New Mexico at Los Alamos National Laboratory's Clinton P. Anderson Meson Physics Facility (LAMPF) where Louis spent his fellowship practicum working with the Accelerator Health Protection Group (then HSE-11).

Louis H. Iselin was awarded the degree of Master of Engineering from the Nuclear Engineering Sciences Department at the University of Florida on 11 May 1992 with a concentration in health physics and engineering physics and a minor in engineering science (applied mathematics). He continued his graduate work at the University of Florida for the Ph.D. On 2 December 1993, Huong gave birth to their first child, Megan Rochelle, at Shands Hospital at the University of Florida. On 27 January 1995, the faculty of the Department of Nuclear Engineering Sciences recognized Louis by naming him as the department's outstanding graduate student for 1995 and bestowing the James E. Swander Memorial Scholarship. Both Huong and Megan are relieved that Louis will be awarded the degree of Doctor of Philosophy on 16 December 1995. After graduation, Dr. Louis H. Iselin will join the physics faculty at Bloomsburg University of Pennsylvania as Assistant Professor.

I certify that I have read this study and that in my opinion it conforms to acceptable standards of scholarly presentation and is fully adequate, in scope and quality, as a dissertation for the degree of Doctor of Philosophy.

David E. Hintenlang, Chairman Associate Professor of Nuclear Engineering Sciences

I certify that I have read this study and that in my opinion it conforms to acceptable standards of scholarly presentation and is fully adequate, in scope and quality, as a dissertation for the degree of Doctor of Philosophy.

Samin Anghaire

Professor of Nuclear Engineering Sciences

I certify that I have read this study and that in my opinion it conforms to acceptable standards of scholarly presentation and is fully adequate, in scope and quality, as a dissertation for the degree of Doctor of Philosophy.

F. Raymond Andrew

Graduate Research Professor of Physics and Nuclear Engineering Sciences

I certify that I have read this study and that in my opinion it conforms to acceptable standards of scholarly presentation and is fully adequate, in scope and quality, as a dissertation for the degree of Doctor of Philosophy.

Ulrich H. Kurzweg

Professor of Aerospace Engineering, Mechanics, and

Ulrich Kurzweg

Engineering Science

I certify that I have read this study and that in my opinion it conforms to acceptable standards of scholarly presentation and is fully adequate, in scope and quality, as a dissertation for the degree of Doctor of Philosophy.

Michael T. Olexa

Professor of Food and Resource

Economics

I certify that I have read this study and that in my opinion it conforms to acceptable standards of scholarly presentation and is fully adequate, in scope and quality, as a dissertation for the degree of Doctor of Philosophy.

Pohert A Marino

Professor and Chairman of Physics

and Astronomy Hunter College

City University of New York

This dissertation was submitted to the Graduate Faculty of the College of Engineering and to the Graduate School and was accepted as partial fulfillment of the requirements for the degree of Doctor of Philosophy.

December, 1995

Winfred M. Phillips

Dean, College of Engineering

Karen A. Holbrook

Dean, Graduate School